

## Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply Automatic Transmission Fluid.



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③, ..... :

①, ②, ③, ..... :Sequence for removal or installation.

## Abbreviation



2WS	Two Wheel Steering
4WS	Four Wheel Steering
ABS	Anti-lock Brake System
A/C	Air Conditioner
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
B or BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	PGM-FI Electronic Control Unit
EGR	Exhaust Gas Recirculation
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV	Positive Crankcase Ventilation
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid Valve
TDC	Top Dead Center

P	Parking
R	Reverse
N	Neutral
D <sub>4</sub>	Drive Position (1st~4th)
D <sub>3</sub>	Drive Position (1st~3rd)
2	Fixed 2nd speed
1	Fixed 1st speed
S	S mode (D4 or D3)