



## Clutch Adjustment

1. Measure the clutch pedal disengagement height.
2. Measure the clutch pedal free play.
3. Adjust the clutch free play by turning the adjusting nut.
4. Make sure that there is 4.0–5.0 mm (5/32–13/64 in) free play at the tip of release arm after the adjustment.

