

Clutch

Index

NOTE: Whenever the transmission is removed the release bearing sliding surface should be cleaned and greased.

