


DTC	P0141/27	OXYGEN SENSOR HEATER CIRCUIT (BANK 1 [SENSOR 2])
-----	----------	--

CIRCUIT DESCRIPTION

Refer to DTC P0136/27 on page 05-83.

HINT:

The ECM provides a pulse width modulated control circuit to adjust current through the heater. The heated oxygen sensor heater circuit uses a relay on the B+ side of the circuit.



DTC No.	DTC Detection Condition	Trouble Area
P0141/27	Voltage of HT1B (ECM terminal) is low for 0.5 second when heated oxygen sensor heater is turned OFF	<ul style="list-style-type: none">• Open or short in heater circuit of the heated oxygen sensor• Heated oxygen sensor heater• EFI relay• ECM

WIRING DIAGRAM

Refer to DTC P0136/27 on page 05-83.


INSPECTION PROCEDURE

HINT:

Read freeze frame data using the intelligent tester II. Freeze frame data record the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

1 INSPECT HEATED OXYGEN SENSOR (HEATER RESISTANCE)

Component Side:



- (a) Disconnect the H10 heated oxygen sensor connector.
- (b) Measure the resistance between the terminals of the heated oxygen sensor connector.
- Standard (Bank 1, 2 sensor 2):**


Tester Connection	Specified Condition
1 (HT) - 2 (+B)	5 to 10 Ω at 20°C (68°F)
1 (HT) - 4 (E1)	10 k Ω or higher

- (c) Reconnect the heated oxygen sensor connector.

NG **REPLACE HEATED OXYGEN SENSOR**

OK

2 INSPECT EFI RELAY



- (a) Remove the EFI relay from the engine room R/B.
- (b) Check the EFI relay resistance.
- Standard:**


Tester Connection	Specified Condition
3 - 5	10 k Ω or higher
3 - 5	Below 1 Ω (Apply battery voltage to terminals 1 and 2)

- (c) Reinstall the EFI relay.

NG **REPLACE EFI RELAY**

OK

3 INSPECT ECM (HT1B VOLTAGE)



- (a) Turn the ignition switch to ON.
- (b) Measure the voltage between the applicable terminals of the E9 and E10 ECM connectors.
- Standard:**

Tester Connection	Specified Condition
HT1B (E10-21) - E1 (E9-1)	9 to 14 V

OK **REPLACE ECM (See page 10-30)**

NG

4

CHECK HARNESS AND CONNECTOR (HEATED OXYGEN SENSOR - ECM, HEATED OXYGEN SENSOR - EFI RELAY)

Wire Harness Side:

H10

Heated Oxygen Sensor Connector

Front View

A72895

Y

HT1B

ECM Connector

A55005

Engine Room R/B:

O

EFI Relay

A88192

- (a) Check the harness and the connectors between the ECM and heated oxygen sensor.
- (1) Disconnect the H10 heated oxygen sensor connector.
- (2) Disconnect the E10 ECM connector.
- (3) Check the resistance.
- Standard (Check for open):**

Tester Connection	Specified Condition
HT (H10-1) - HT1B (E10-21)	Below 1 Ω

Standard (Check for short):

Tester Connection	Specified Condition
HT (H10-1) or HT1B (E10-21) - Body ground	10 kΩ or higher

- (4) Reconnect the heated oxygen sensor connector.
- (5) Reconnect the ECM connector.
- (b) Check the harness and the connectors between the heated oxygen sensor and EFI relay.
- (1) Disconnect the H10 heated oxygen sensor connector.
- (2) Remove the EFI relay from the engine room R/B.
- (3) Check the resistance.
- Standard (Check for open):**

Tester Connection	Specified Condition
+B (H10-2) - EFI relay (3)	Below 1 Ω

Standard (Check for short):

Tester Connection	Specified Condition
+B (H10-2) or EFI relay (3) - Body ground	10 kΩ or higher

- (4) Reconnect the heated oxygen sensor connector.
- (5) Reinstall the EFI relay.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE ECM (See page 10-30)