



1MZ-FE ENGINE

ENGINE MECHANICAL



DESCRIPTION

The 1MZ-FE engine is a V-6, 3.0 liter 24 valve DOHC engine.

E00P0-04

OPERATION

E00P1-01



The 1 MZ-FE engine has 6 cylinders in a V arrangement at a bank angle of 60°. From the front of the RH bank cylinders are numbered 1-3-5, and from the front of the LH bank cylinders are numbered 2-4-6. The crankshaft is supported by 4 bearings inside the crankcase. These bearings are made of copper and lead alloy.

The crankshaft is integrated with 9 semi counterweights for balance. Oil holes are placed in the center of the crankshaft for supply oil to the connecting rods, bearings, pistons and other components.

This engine's firing order is 1-2-3-4-5-6. The cylinder head is made of aluminum alloy, with a cross flow type intake and exhaust layout and with pent-roof type combustion chambers. The spark plugs are located in the center of the combustion chambers.

At the front and rear of the intake manifold, a water passage has been provided which connects the RH and LH cylinder heads.

Exhaust and intake valves are equipped with irregular pitch springs made of special valve spring carbon steel which are capable of following the cam profile at all engine speeds.

The RH and LH exhaust camshafts are driven by a single timing belt, and a gear on the exhaust camshaft engages with a gear on the intake camshaft to drive it. The camshaft journal is supported at 5 places between the valve lifters of each cylinder and on the front end of the cylinder head. Lubrication of the cam journals and gears is accomplished by oil being supplied through the oiler port in the center of the camshaft.

Adjustment of the valve clearance is done by means of an outer shim type system, in which valve adjusting shims are located above the valve lifters. This permits replacement of the shims without removal of the camshafts.

The timing belt covers consist of the resin type No.2 and No.1 above and below the engine RH mounting bracket.

Pistons are made of high temperature-resistant aluminum alloy, and a depression is built into the piston head to prevent interference with the valves.

Piston pins are the full-floating type, with the pins fastened to neither the piston boss nor the connecting rods. Instead, snap rings are fitted on both ends of the pins, preventing the pins from falling out.

The No.1 compression ring is made of steel and the No.2 compression ring is made of cast iron. The oil ring also is made of a combination of steel and stainless steel. The outer diameter of each piston ring is slightly larger than the diameter of the piston and the flexibility of the rings allows them to hug the cylinder walls when they are mounted on the piston. Compression rings No. 1 and No.2 work to prevent gas leakage from the cylinder and the oil ring works to clear oil off the cylinder walls to prevent it from entering the combustion chambers.

The cylinder block is made of aluminum alloy with a bank angle of 60°. It has 6 cylinders which are approximately 1.6 times the length of the piston stroke. The top of the cylinders is closed off by the cylinder heads and the lower end of the cylinders becomes the crankcase, in which the crankshaft is installed. In addition, the cylinder block contains a water jacket, through which coolant is pumped to cool the cylinders.














The No. 1 and No.2 oil pans are bolted onto the bottom of the cylinder block. The No. 1 oil pan is made of aluminum alloy. The No.2 oil pan is an oil reservoir made of pressed sheet steel. An oil pan baffle plate keeps sufficient oil in the bottom of the No.2 oil pan even when the vehicle is tilted. This dividing plate also prevents the oil from sloshing when the vehicle is stopped suddenly and the oil shifts away from the oil pump suction pipe.













Plastic region tightening bolts are used for the cylinder head, main bearing caps and connecting rods.

PREPARATION






SST (SPECIAL SERVICE TOOLS)

15000-28

	09201-01055 Valve Guide Bushing Remover & Replacer 5.5	
	09201-41020 Valve Stem Oil Seal Replacer	
	09202-70010 Valve Spring Compressor	
	09213-54015 Crankshaft Pulley Holding Tool	
	09213-60017 Crankshaft Pulley & Gear Puller Set	
	(09213-00020) Body With Bolt	
	(09213-00030) Handle	
	(09213-00050) Bolt set	Crankshaft timing pulley
	(09213-00060) Bolt set	Crankshaft pulley
	08223-00010 Cover & Seal Replacer	Crankshaft front oil seal
	09223-15030 Oil Seal & Bearing Replacer	Crankshaft rear oil seal
	09223-46011 Crankshaft Front Oil Seal Replacer	Crankshaft timing pulley
	09248-55040 Valve Clearance Adjust Tool set	

	(09248-05410) Valve Lifter Press	
	(09248-05420) Valve Lifter Stopper	
	09249-63010 Torque Wrench Adaptor	RH camshaft timing pulley
	09330-00021 Companion Flange Holding Tool	Crankshaft pulley
	09608-20012 Front Hub & Drive Pinion Bearing Tool Set	
	(09608-03020) Handle	Crankshaft rear oil seal Valve guide bushing
	(09608-03070) Replacer	Spark plug tube gasket
	09631-22020 Power Steering Hose Nut 14 x 17 mm Wrench Set	
	09816-30010 Oil Pressure Switch Socket	Knock sensor Oil pressure switch
	09843-18020 Diagnosis Check Wire	
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	Camshaft timing pulley

RECOMMENDED TOOLS

	09040-00010 Hexagon Wrench Set	
	09090-04010 Engine Sling Device	For suspending engine
	09200-00010 Engine Adjust Kit	
	09258-00030 Hose Plug set	Plug for the vacuum hose, fuel hose etc.
	09904-00010 Expander Set	

EQUIPMENT

Battery specific gravity gauge	
Caliper gauge	
CO/HC meter	
Connecting rod aligner	
Cylinder gauge	
Dial indicator	
Dye penetrant	
Engine tune-up tester	
Heater	
Micrometer	
Piston ring compressor	
Piston ring expander	
Plastigage	
Precision straight edge	
Magnetic finger	

Soft brush	
Spring tester	Valve spring
Steel square	Valve spring
Thermometer	
Torque wrench	
Valve seat cutter	
Vernier calipers	

B027M-01

COOLANT

Item	Capacity	Classification
Engine coolant	8.7 liters (9.2 US qts, 7.7 Imp. qts)	Ethylene-glycol base

B027M-01


LUBRICANT

Item	Capacity	Classification
Engine oil Dry fill Drain and refill w/ Oil filter change w/o Oil filter change	5.5 liters (5.8 US qts, 4.8 Imp. qts) 4.7 liters (5.0 US qts, 4.1 Imp. qts) 4.5 liters (4.8 US qts, 4.0 Imp. qts)	API grade SG or SH, Energy-Conserving II or ILSC multigrade and recommended viscosity oil with SAE 5W-30 being the preferred engine oil

B027M-02

SSM (SERVICE SPECIAL MATERIALS)

08826-00080 Seal packing or equivalent	Camshaft bearing cap Semi-circular plug Spark plug tube Cylinder head cover
08826-00080 Seal packing or equivalent	Intake air control valve Rear oil seal retainer No. 1 oil pan No.2 oil pan
08826-00100 Seal Packing 1282B, THREE BOND 1282B or equivalent	Engine coolant drain cock Water seal plate Water inlet housing
08833-00070 Adhesive 1311, THREE BOND 1311 or equivalent	Drive plate bolt TVV
08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Oil pressure switch



TUNE-UP


80479-01

ENGINE COOLANT INSPECTION

1. CHECK ENGINE COOLANT LEVEL AT RESERVOIR TANK

The engine coolant level should be between the "LOW" and "FULL" lines.


If low, check for leaks and add engine coolant up to the "FULL" line.



2. CHECK ENGINE COOLANT QUALITY

(a) Remove the radiator cap from the water outlet.

CAUTION: To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.



(b) There should not be any excessive deposits of rust or scale around the radiator cap or water outlet filler hole, and the coolant should be free from oil.

If excessively dirty, clean the coolant passages and replace the coolant.

Capacity:


8.7 liters (9.2 US qts, 7.7 Imp. qts)

HINT:


- Use a good brand of ethylene-glycol base coolant and mix it according to the manufacturer's directions.
- Using coolant which includes more than 50 % ethylene-glycol (but not more than 70 %) is recommended.

NOTICE:

- **Do not use an alcohol type coolant.**
- **The coolant should be mixed with demineralized water or distilled water.**



(c) Reinstall the radiator cap.



ENGINE OIL INSPECTION

1. CHECK OIL QUALITY

Check the oil for deterioration, entry of water, discoloring or thinning.

If oil quality is visibly poor, replace the oil.

Oil grade:

API grade SG or SH, Energy – Conserving H or ILSAC multigrade engine oil. Recommended viscosity is as shown in the illustration, with SAE 5W-30 being the preferred engine oil.


Drain and refill capacity:

w/ Oil filter change

4.7 liters (5.0 US qts, 4.1 Imp. qts)

w/o Oil filter change

4.5 liters (4.8 US qts, 4.0 Imp. qts)




2. CHECK ENGINE OIL LEVEL

The oil level should be between the "L" and "F" marks on the dipstick.


If low, check for leakage and add oil up to the "F" mark.

NOTICE:

- Do not fill with engine oil above the 'F' mark.



- Install the oil dipstick facing the direction shown in the illustration.



BATTERY INSPECTION


1. Except Delco Battery:

CHECK BATTERY ELECTROLYTE LEVEL

Check the electrolyte quantity of each cell.


A. Maintenance Free Battery

If under the lower level, replace the battery (or add distilled water if possible). Check the charging system.



B. Except Maintenance Free Battery

If under the "LOWER" or "MIN" line, add distilled water.



2. Except Delco Battery:

CHECK BATTERY VOLTAGE AND SPECIFIC GRAVITY

A. Maintenance Free Battery

Measure the battery voltage between the terminals negative (-) and positive (+) of the battery.

Standard voltage:


12.7 – 12.9 V at 20°C (68°F)


HINT:

- Before measuring the voltage, turn the ignition switch to LOCK and turn off the electrical systems (headlight, blower motor, rear defogger etc.; for 60 seconds to remove the surface charge.
- If the vehicle has been running, wait 5 minutes or more after the vehicle stops before measuring the battery voltage.

If the voltage is less than specification, charge the battery.

HINT: Check the indicator as shown in the illustration.





B. Except Maintenance Free Battery

Check the specific gravity of each cell.

Standard specific gravity:

55D23L battery for GNB Incorporated

1.25 – 1.27 at 20°C (60°F)

5513231- battery for JOHNSON CONTROLS

1.26 – 1.28 at 27°C (81°F)

80D26L battery for GNB Incorporated



1.27 – 1.29 at 20°C (68°F)

80D26L battery for JOHNSON CONTROLS

1.28 – 1.30 at 27°C (80°F)

If the gravity is less than specification, charge the battery.

HINT: Check the indicator as shown in the illustration.



3. Delco Battery:

CHECK HYDROMETER

Green Dot visible:

Battery is adequately charged

Dark (Green Dot not visible):

Battery must be charged

Clear or Light Yellow:



Replace battery

HINT: There is no need to add water during the entire service life of the battery.

4. CHECK BATTERY TERMINALS, FUSIBLE LINK AND FUSES


(a) Check that the battery terminals are not loose or corroded.

(b) Check the fusible link and fuses for continuity.



AIR FILTER INSPECTION AND CLEANING

1. REMOVE AIR FILTER



2. INSPECT AND CLEAN AIR FILTER


(a) Visually check that the air filter is not excessively dirty, damaged or oily.

If necessary, replace the air filter.

(b) Clean the air filter with compressed air.

First blow from the inside thoroughly, then blow from the outside of the air filter.

3. REINSTALL AIR FILTER



GENERATOR DRIVE BELT INSPECTION

INSPECT DRIVE BELT

(a) Visually check the belt for excessive wear, frayed cords etc.

If necessary, replace the drive belt.

HINT: Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.

(b) Using a belt tension gauge, measure the drive belt tension.

Belt tension gauge:

Nippondenso BTG – 20 (95506-00020)

Borroughs No. BT-33-73F

Drive belt tension:

New belt

175 ± 5 lbf



Used belt


115 ± 20 lbf

If the belt tension is not as specified, adjust it.

HINT:

- "New belt" refers to a belt which has been used less than 5 minutes on a running engine.
- "Used belt" refers to a belt which has been used on a running engine for 5 minutes or more.
- After installing the belt, check that it fits properly in the ribbed grooves.
- Check by hand to confirm that the belt has not slipped out of the groove on the bottom of the pulley.
- After installing a new belt, run the engine for about 5 minutes and recheck the belt tension.





VALVE CLEARANCE INSPECTION AND ADJUSTMENT



HINT: Inspect and adjust the valve clearance when the engine is cold.

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.


2. DRAIN ENGINE COOLANT

3. DISCONNECT RADIATOR INLET HOSE



4. DISCONNECT ACCELERATOR CABLE

5. DISCONNECT THROTTLE CABLE



6. REMOVE AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE

(a) Disconnect the volume air flow meter connector and wire clamp.

(b) Disconnect the accelerator cable clamp.

(c) Disconnect the PCV hose.


(d) Loosen the air cleaner hose clamp bolt.


(e) Disconnect the 4 air cleaner cap clips.

(f) Remove the air cleaner cap and volume air flow meter together with the air cleaner hose.

7. REMOVE V-BANK COVER

Using a 5 mm hexagon wrench, remove the 2 nuts and V-bank cover.






8. REMOVE EMISSION CONTROL VALVE SET


(a) Disconnect the following vacuum hoses:

- (1) Vacuum hose from fuel pressure control VSV
- (2) Vacuum hose from fuel pressure regulator
- (3) Vacuum hose from cylinder head rear plate
- (4) Vacuum hose from intake air control valve VSV
- (5) Vacuum hose from EGR vacuum modulator
- (6) Vacuum hose from EGR valve




(b) Disconnect the following connectors:

- (1) Intake air control valve connector
- (2) Fuel pressure connector
- (3) EGR VSV connector




(c) Remove the 2 nuts and emission control valve set.




9. REMOVE AIR INTAKE CHAMBER

(a) Disconnect the following hoses:


- (1) Brake booster vacuum hose
- (2) PCV hose
- (3) Intake air control valve vacuum hose
- (b) Disconnect the data link connector 1.
- (c) Remove the nut and disconnect the 2 ground straps.




- (d) Remove the bolt and disconnect the hydraulic motor pressure hose from the air intake chamber.
- (e) Remove the bolt, and disconnect the ground strap.
- (f) Disconnect the RH oxygen sensor connector clamp from the PS pressure tube.




- (g) Remove the 2 nuts, and disconnect the PS pressure tube.
- (h) Disconnect the 2 PS air hoses.




- (i) Remove the 2 bolts and No.1 engine hanger.
- (j) Remove the 2 bolts and air intake chamber stay.




- (k) Remove the 4 nuts, EGR pipe and 2 gaskets.




- (l) Disconnect the following connectors:
- (1) Throttle position sensor connector
 - (2) IAC valve connector
 - (3) EGR gas temperature sensor connector
 - (4) A/C idle-up connector




- (m) Disconnect the following vacuum hoses:
- (1) 2 vacuum hoses from TVV
 - (2) Vacuum hose from cylinder head rear plate




- (3) Vacuum hose from charcoal canister



- (n) Disconnect the following hoses:
- (1) 2 water bypass hoses
 - (2) Air assist hose



- (o) Using an 8 mm hexagon wrench, remove the 2 bolts, 2 nuts, air intake chamber and gasket.



10. DISCONNECT ENGINE WIRE FROM ENGINE LH SIDE

(a) Disconnect the following connectors:


- (1) 3 injector connectors
- (2) 3 ignition coil connectors

(b) Remove the 2 nuts, and disconnect the engine wire.




11. DISCONNECT ENGINE WIRE FROM NO.3 TIMING BELT COVER

Remove the bolt and 3 clamps, and disconnect the engine wire.



12. DISCONNECT ENGINE WIRE FROM ENGINE REAR SIDE

Remove the 2 nuts, and disconnect the engine wire.




13. DISCONNECT ENGINE WIRE FROM ENGINE RH SIDE

(a) Disconnect the following connectors:

- (1) 3 injector connectors
- (2) 3 ignition coil connectors


(b) Remove the 5 nuts, and disconnect the engine wire.



14. REMOVE IGNITION COILS


Remove the 6 bolts and 6 ignition coils from the RH and LH cylinder heads.

HINT: Arrange the ignition coils in the correct order.




15. REMOVE SPARK PLUGS

Using a 16 mm plug wrench, remove the 6 spark plugs from the RH and LH cylinder heads.




16. REMOVE CYLINDER HEAD COVERS


Remove the 8 bolts, cylinder head cover and gasket. Remove the 2 cylinder head covers.



17. SET NO.1 CYLINDER TO TDC/COMPRESSION

- (a) Turn the crankshaft pulley, and align its groove with the timing mark "0" of the No.1 timing belt cover.
- (b) Check that the valve lifters on the No.1 (IN) are loose and valve lifters on the No.1 (EX) are tight. If not, turn the crankshaft 1 revolution (360°) and align the mark as above.





18. INSPECT VALVE CLEARANCE

(a) Check only those valves indicated in the illustration.

- Using a feeler gauge, measure the clearance between the valve lifter and camshaft.
- Record out of specification valve clearance measurements. They will be used later to determine the required replacement adjusting shim.


Valve clearance (Cold):

Intake

0.15 – 0.25 mm (0.006 – 0.010 in.)

Exhaust


0.25 – 0.35 mm (0.010 – 0.014 in.)



(b) Turn the crankshaft $\frac{2}{3}$ of a revolution (240°), and check only the valves indicated in the illustration.

Measure the valve clearance.


(See procedure step (a))



(c) Turn the crankshaft a further $\frac{2}{3}$ of a revolution (240°), and check only the valves indicated in the illustration.

Measure the valve clearance.


(See procedure step (a))



19. ADJUST VALVE CLEARANCE

(a) Remove the adjusting shim.

- Turn the camshaft so that the cam lobe for the valve to be adjusted faces up.
- Turn the valve lifter with a screwdriver so that the notches would be perpendicular to the camshaft.




- Using SST (A), press down the valve lifter and place SST (B) between the camshaft and valve lifter. Remove SST (A).


SST 09248-55040 (09248-05410, 09248-05420)

HINT:

- Apply SST (B) at a slight angle on the side marked with "9" or "7", at the position shown in the illustration.
- When SST (B) is inserted too deeply, it will get pinched by the shim. To prevent it from being stuck, insert it gently from the intake side, at a slight angle.



- Using a small screwdriver and a magnetic finger, remove the adjusting shim.



(b) Determine the replacement adjusting shim size according to the following Formula or Charts on the next 2 pages:

- Using a micrometer, measure the thickness of the removed shim.
- Calculate the thickness of a new shim so the valve clearance comes within specified value.

T Thickness of used shim

A Measured valve clearance

N Thickness of new shim

Intake


$$N = T + (A - 0.20 \text{ mm (0.008 in.)})$$

Exhaust

$$N = T + (A - 0.30 \text{ mm (0.012 in.)})$$

- Select a new shim with a thickness as close as possible to the calculated values.

HINT: Shims are available in 17 sizes in increments of 0.050 mm (0.0020 in.), from 2.500 mm (0.0984 in.) to 3.300 mm (0.1299 in.).



(c) Install a new adjusting shim.


- Place a new adjusting shim on the valve lifter, with imprinted numbers facing down.
- Press down the valve lifter with SST (A), and remove SST (B).

SST 09248-55040 (09248-05410, 09248-05420)

(d) Recheck the valve clearance.

Adjusting Shim Selection Chart (Exhaust)

Installed shim thickness mm (in.)	2.500 (0.0984)	2.550 (0.1004)	2.600 (0.1024)	2.650 (0.1044)	2.700 (0.1063)	2.750 (0.1083)	2.800 (0.1102)	2.850 (0.1122)	2.900 (0.1142)	2.950 (0.1161)	3.000 (0.1181)	3.050 (0.1201)	3.100 (0.1220)	3.150 (0.1240)	3.200 (0.1260)	3.250 (0.1279)	3.300 (0.1299)	3.350 (0.1318)	3.400 (0.1338)	3.450 (0.1357)	3.500 (0.1377)	3.550 (0.1396)	3.600 (0.1416)	3.650 (0.1436)	3.700 (0.1455)	3.750 (0.1475)	3.800 (0.1494)	3.850 (0.1514)	3.900 (0.1533)	3.950 (0.1553)	4.000 (0.1572)	4.050 (0.1592)	4.100 (0.1611)	4.150 (0.1631)	4.200 (0.1650)	4.250 (0.1670)	4.300 (0.1689)	4.350 (0.1709)	4.400 (0.1728)	4.450 (0.1748)	4.500 (0.1767)	4.550 (0.1787)	4.600 (0.1806)	4.650 (0.1826)	4.700 (0.1845)	4.750 (0.1865)	4.800 (0.1884)	4.850 (0.1904)	4.900 (0.1923)	4.950 (0.1943)	5.000 (0.1962)	5.050 (0.1982)	5.100 (0.2001)	5.150 (0.2021)	5.200 (0.2040)	5.250 (0.2060)	5.300 (0.2079)	5.350 (0.2099)	5.400 (0.2118)	5.450 (0.2138)	5.500 (0.2157)	5.550 (0.2177)	5.600 (0.2196)	5.650 (0.2216)	5.700 (0.2235)	5.750 (0.2255)	5.800 (0.2274)	5.850 (0.2294)	5.900 (0.2313)	5.950 (0.2333)	6.000 (0.2352)	6.050 (0.2372)	6.100 (0.2391)	6.150 (0.2411)	6.200 (0.2430)	6.250 (0.2450)	6.300 (0.2469)	6.350 (0.2489)	6.400 (0.2508)	6.450 (0.2528)	6.500 (0.2547)	6.550 (0.2567)	6.600 (0.2586)	6.650 (0.2606)	6.700 (0.2625)	6.750 (0.2645)	6.800 (0.2664)	6.850 (0.2684)	6.900 (0.2703)	6.950 (0.2723)	7.000 (0.2742)	7.050 (0.2762)	7.100 (0.2781)	7.150 (0.2801)	7.200 (0.2820)	7.250 (0.2840)	7.300 (0.2859)	7.350 (0.2879)	7.400 (0.2898)	7.450 (0.2918)	7.500 (0.2937)	7.550 (0.2957)	7.600 (0.2976)	7.650 (0.2996)	7.700 (0.3015)	7.750 (0.3035)	7.800 (0.3054)	7.850 (0.3074)	7.900 (0.3093)	7.950 (0.3113)	8.000 (0.3132)	8.050 (0.3152)	8.100 (0.3171)	8.150 (0.3191)	8.200 (0.3210)	8.250 (0.3230)	8.300 (0.3249)	8.350 (0.3269)	8.400 (0.3288)	8.450 (0.3308)	8.500 (0.3327)	8.550 (0.3347)	8.600 (0.3366)	8.650 (0.3386)	8.700 (0.3405)	8.750 (0.3425)	8.800 (0.3444)	8.850 (0.3464)	8.900 (0.3483)	8.950 (0.3503)	9.000 (0.3522)	9.050 (0.3542)	9.100 (0.3561)	9.150 (0.3581)	9.200 (0.3600)	9.250 (0.3620)	9.300 (0.3639)	9.350 (0.3659)	9.400 (0.3678)	9.450 (0.3698)	9.500 (0.3717)	9.550 (0.3737)	9.600 (0.3756)	9.650 (0.3776)	9.700 (0.3795)	9.750 (0.3815)	9.800 (0.3834)	9.850 (0.3854)	9.900 (0.3873)	9.950 (0.3893)	10.000 (0.3912)	10.050 (0.3932)	10.100 (0.3951)	10.150 (0.3971)	10.200 (0.3990)	10.250 (0.4010)	10.300 (0.4029)	10.350 (0.4049)	10.400 (0.4068)	10.450 (0.4088)	10.500 (0.4107)	10.550 (0.4127)	10.600 (0.4146)	10.650 (0.4166)	10.700 (0.4185)	10.750 (0.4205)	10.800 (0.4224)	10.850 (0.4244)	10.900 (0.4263)	10.950 (0.4283)	11.000 (0.4302)	11.050 (0.4322)	11.100 (0.4341)	11.150 (0.4361)	11.200 (0.4380)	11.250 (0.4400)	11.300 (0.4419)	11.350 (0.4439)	11.400 (0.4458)	11.450 (0.4478)	11.500 (0.4497)	11.550 (0.4517)	11.600 (0.4536)	11.650 (0.4556)	11.700 (0.4575)	11.750 (0.4595)	11.800 (0.4614)	11.850 (0.4634)	11.900 (0.4653)	11.950 (0.4673)	12.000 (0.4692)	12.050 (0.4712)	12.100 (0.4731)	12.150 (0.4751)	12.200 (0.4770)	12.250 (0.4790)	12.300 (0.4809)	12.350 (0.4829)	12.400 (0.4848)	12.450 (0.4868)	12.500 (0.4887)	12.550 (0.4907)	12.600 (0.4926)	12.650 (0.4946)	12.700 (0.4965)	12.750 (0.4985)	12.800 (0.5004)	12.850 (0.5024)	12.900 (0.5043)	12.950 (0.5063)	13.000 (0.5082)	13.050 (0.5102)	13.100 (0.5121)	13.150 (0.5141)	13.200 (0.5160)	13.250 (0.5180)	13.300 (0.5199)	13.350 (0.5219)	13.400 (0.5238)	13.450 (0.5258)	13.500 (0.5277)	13.550 (0.5297)	13.600 (0.5316)	13.650 (0.5336)	13.700 (0.5355)	13.750 (0.5375)	13.800 (0.5394)	13.850 (0.5414)	13.900 (0.5433)	13.950 (0.5453)	14.000 (0.5472)	14.050 (0.5492)	14.100 (0.5511)	14.150 (0.5531)	14.200 (0.5550)	14.250 (0.5570)	14.300 (0.5589)	14.350 (0.5609)	14.400 (0.5628)	14.450 (0.5648)	14.500 (0.5667)	14.550 (0.5687)	14.600 (0.5706)	14.650 (0.5726)	14.700 (0.5745)	14.750 (0.5765)	14.800 (0.5784)	14.850 (0.5804)	14.900 (0.5823)	14.950 (0.5843)	15.000 (0.5862)	15.050 (0.5882)	15.100 (0.5901)	15.150 (0.5921)	15.200 (0.5940)	15.250 (0.5960)	15.300 (0.5979)	15.350 (0.5999)	15.400 (0.6018)	15.450 (0.6038)	15.500 (0.6057)	15.550 (0.6077)	15.600 (0.6096)	15.650 (0.6116)	15.700 (0.6135)	15.750 (0.6155)	15.800 (0.6174)	15.850 (0.6194)	15.900 (0.6213)	15.950 (0.6233)	16.000 (0.6252)	16.050 (0.6272)	16.100 (0.6291)	16.150 (0.6311)	16.200 (0.6330)	16.250 (0.6350)	16.300 (0.6369)	16.350 (0.6389)	16.400 (0.6408)	16.450 (0.6428)	16.500 (0.6447)	16.550 (0.6467)	16.600 (0.6486)	16.650 (0.6506)	16.700 (0.6525)	16.750 (0.6545)	16.800 (0.6564)	16.850 (0.6584)	16.900 (0.6603)	16.950 (0.6623)	17.000 (0.6642)	17.050 (0.6662)	17.100 (0.6681)	17.150 (0.6701)	17.200 (0.6720)	17.250 (0.6740)	17.300 (0.6759)	17.350 (0.6779)	17.400 (0.6798)	17.450 (0.6818)	17.500 (0.6837)	17.550 (0.6857)	17.600 (0.6876)	17.650 (0.6896)	17.700 (0.6915)	17.750 (0.6935)	17.800 (0.6954)	17.850 (0.6974)	17.900 (0.6993)	17.950 (0.7013)	18.000 (0.7032)	18.050 (0.7052)	18.100 (0.7071)	18.150 (0.7091)	18.200 (0.7110)	18.250 (0.7130)	18.300 (0.7149)	18.350 (0.7169)	18.400 (0.7188)	18.450 (0.7208)	18.500 (0.7227)	18.550 (0.7247)	18.600 (0.7266)	18.650 (0.7286)	18.700 (0.7305)	18.750 (0.7325)	18.800 (0.7344)	18.850 (0.7364)	18.900 (0.7383)	18.950 (0.7403)	19.000 (0.7422)	19.050 (0.7442)	19.100 (0.7461)	19.150 (0.7481)	19.200 (0.7500)	19.250 (0.7520)	19.300 (0.7539)	19.350 (0.7559)	19.400 (0.7578)	19.450 (0.7598)	19.500 (0.7617)	19.550 (0.7637)	19.600 (0.7656)	19.650 (0.7676)	19.700 (0.7695)	19.750 (0.7715)	19.800 (0.7734)	19.850 (0.7754)	19.900 (0.7773)	19.950 (0.7793)	20.000 (0.7812)	20.050 (0.7832)	20.100 (0.7851)	20.150 (0.7871)	20.200 (0.7890)	20.250 (0.7910)	20.300 (0.7929)	20.350 (0.7949)	20.400 (0.7968)	20.450 (0.7988)	20.500 (0.8007)	20.550 (0.8027)	20.600 (0.8046)	20.650 (0.8066)	20.700 (0.8085)	20.750 (0.8105)	20.800 (0.8124)	20.850 (0.8144)	20.900 (0.8163)	20.950 (0.8183)	21.000 (0.8202)	21.050 (0.8222)	21.100 (0.8241)	21.150 (0.8261)	21.200 (0.8280)	21.250 (0.8300)	21.300 (0.8319)	21.350 (0.8339)	21.400 (0.8358)	21.450 (0.8378)	21.500 (0.8397)	21.550 (0.8417)	21.600 (0.8436)	21.650 (0.8456)	21.700 (0.8475)	21.750 (0.8495)	21.800 (0.8514)	21.850 (0.8534)	21.900 (0.8553)	21.950 (0.8573)	22.000 (0.8592)	22.050 (0.8612)	22.100 (0.8631)	22.150 (0.8651)	22.200 (0.8670)	22.250 (0.8690)	22.300 (0.8709)	22.350 (0.8729)	22.400 (0.8748)	22.450 (0.8768)	22.500 (0.8787)	22.550 (0.8807)	22.600 (0.8826)	22.650 (0.8846)	22.700 (0.8865)	22.750 (0.8885)	22.800 (0.8904)	22.850 (0.8924)	22.900 (0.8943)	22.950 (0.8963)	23.000 (0.8982)	23.050 (0.9002)	23.100 (0.9021)	23.150 (0.9041)	23.200 (0.9060)	23.250 (0.9080)	23.300 (0.9099)	23.350 (0.9119)	23.400 (0.9138)	23.450 (0.9158)	23.500 (0.9177)	23.550 (0.9197)	23.600 (0.9216)	23.650 (0.9236)	23.700 (0.9255)	23.750 (0.9275)	23.800 (0.9294)	23.850 (0.9314)	23.900 (0.9333)	23.950 (0.9353)	24.000 (0.9372)	24.050 (0.9392)	24.100 (0.9411)	24.150 (0.9431)	24.200 (0.9450)	24.250 (0.9470)	24.300 (0.9489)	24.350 (0.9509)	24.400 (0.9528)	24.450 (0.9548)	24.500 (0.9567)	24.550 (0.9587)	24.600 (0.9606)	24.650 (0.9626)	24.700 (0.9645)	24.750 (0.9665)	24.800 (0.9684)	24.850 (0.9704)	24.900 (0.9723)	24.950 (0.9743)	25.000 (0.9762)	25.050 (0.9782)	25.100 (0.9801)	25.150 (0.9821)	25.200 (0.9840)	25.250 (0.9860)	25.300 (0.9879)	25.350 (0.9899)	25.400 (0.9918)	25.450 (0.9938)	25.500 (0.9957)	25.550 (0.9977)	25.600 (0.9996)	25.650 (1.0016)	25.700 (1.0035)	25.750 (1.0055)	25.800 (1.0074)	25.850 (1.0094)	25.900 (1.0113)	25.950 (1.0133)	26.000 (1.0152)	26.050 (1.0172)	26.100 (1.0191)	26.150 (1.0211)	26.200 (1.0230)	26.250 (1.0250)	26.300 (1.0269)	26.350 (1.0289)	26.400 (1.0308)	26.450 (1.0328)	26.500 (1.0347)	26.550 (1.0367)	26.600 (1.0386)	26.650 (1.0406)	26.700 (1.0425)	26.750 (1.0445)	26.800 (1.0464)	26.850 (1.0484)	26.900 (1.0503)	26.950 (1.0523)	27.000 (1.0542)	27.050 (1.0562)	27.100 (1.0581)	27.150 (1.0601)	27.200 (1.0620)	27.250 (1.0640)	27.300 (1.0659)	27.350 (1.0679)	27.400 (1.0698)	27.450 (1.0718)	27.500 (1.0737)	27.550 (1.0757)	27.600 (1.0776)	27.650 (1.0796)	27.700 (1.0815)	27.750 (1.0835)	27.800 (1.0854)	27.850 (1.0874)	27.900 (1.0893)	27.950 (1.0913)	28.000 (1.0932)	28.050 (1.0952)	28.100 (1.0971)	28.150 (1.0991)	28.200 (1.1010)	28.250 (1.1030)	28.300 (1.1049)	28.350 (1.1069)	28.400 (1.1088)	28.450 (1.1108)	28.500 (1.1127)	28.550 (1.1147)	28.600 (1.1166)	28.650 (1.1186)	28.700 (1.1205)	28.750 (1.1225)	28.800 (1.1244)	28.850 (1.1264)	28.900 (1.1283)	28.950 (1.1303)	29.000 (1.1322)	29.050 (1.1342)	29.100 (1.1361)	29.150 (1.1381)	29.200 (1.1400)	29.250 (1.1420)	29.300 (1.1439)	29.350 (1.1459)	29.400 (1.1478)	29.450 (1.1498)	29.500 (1.1517)	29.550 (1.1537)	29.600 (1.1556)	29.650 (1.1576)	29.700 (1.1595)	29.750 (1.1615)	29.800 (1.1634)	29.850 (1.1654)	29.900 (1.1673)	29.950 (1.1693)	30.000 (1.1712)	30.050 (1.1732)	30.100 (1.1751)	30.150 (1.1771)	30.200 (1.1790)	30.250 (1.1810)	30.300 (1.1829)	30.350 (1.1849)	30.400 (1.1868)	30.450 (1.1888)	30.500 (1.1907)	30.550 (1.1927)	30.600 (1.1946)	30.650 (1.1966)	30.700 (1.1985)	30.750 (1.2005)	30.800 (1.2024)	30.850 (1.2044)	30.900 (1.2063)	30.950 (1.2083)	31.000 (1.2102)	31.050 (1.2122)	31.100 (1.2141)	31.150 (1.2161)	31.200 (1.2180)	31.250 (1.2200)	31.300 (1.2219)	31.350 (1.2239)	31.400 (1.2258)	31.450 (1.2278)	31.500 (1.2297)	31.550 (1.2317)	31.600 (1.2336)	31.650 (1.2356)	31.700 (1.2375)	31.750 (1.2395)	31.800 (1.2414)	31.850 (1.2434)	31.900 (1.2453)	31.950 (1.2473)	32.000 (1.2492)	32.050 (1.2512)	32.100 (1.2531)	32.150 (1.2551)	32.200 (1.2570)	32.250 (1.2590)	32.300 (1.2609)	32.350 (1.2629)	32.400 (1.2648)	32.450 (1.2668)	32.500 (1.2687)	32.550 (1.2707)	32.600 (1.2726)	32.650 (1.2746)	32.700 (1.2765)	32.750 (1.2785)	32.800 (1.2804)	32.850 (1.2824)	32.900 (1.2843)	32.950 (1.2863)	33.000 (1.2882)	33.050 (1.2902)	33.100 (1.2921)	33.150 (1.2941)	33.200 (1.2960)	33.250 (1.2980)	33.300 (1.3000)	33.350 (1.3019)	33.400 (1.3039)	33.450 (1.3058)	33.500 (1.3078)	33.550 (1.3097)	33.600 (1.3117)	33.650 (1.3136)	33.700 (1.3156)	33.750 (1.3175)	33.800 (1.3195)	33.850 (1.3214)	33.900 (1.3234)	33.950 (1.3253)	34.000 (1.3273)	34.050 (1.3292)	34.100 (1.3312)	34.150 (1.3331)	34.200 (1.3351)	34.250 (1.3370)	34.300 (1.3390)	34.350 (1.3409)	34.400 (1.3429)	34.450 (1.3448)	34.500 (1.3468)	34.550 (1.3487)	34.600 (1.3507)	34.650 (1.3526)	34.700 (1.3546)	34.750 (1.3565)	34.800 (1.3585)	34.850 (1.3604)	34.900 (1.3624)	34.950 (1.3643)	35.000 (1.3663)	35.050 (1.3682)	35.100 (1.3702)	35.150 (1.3721)	35.200 (1.3741)	35.250 (1.3760)	35.300 (1.3780)	35.350 (1.3800)	35.400 (1.3819)	35.450 (1.3839)	35.500 (1.3858)	35.550 (1.3878)	35.600 (1.3897)	35.650 (1.3917)	35.700 (1.3936)	35.750 (1.3956)	35.800 (1.3975)	35.850 (1.3995)	35.900 (1.4014)	35.950 (1.4034)	36.000 (1.4053)	36.050 (1.4073)	36.100 (1.4092)	36.150 (1.4112)	36.200 (1.4131)	36.250 (1.4151)	36.300 (1.4170)	36.350 (1.4190)	36.400 (1.4210)	36.450 (1.4229)	36.500 (1.4249)	36.550 (1.4268)	36.600 (1.4288)	36.650 (1.4307)	36.700 (1.4327)	36.750 (1.4346)	36.800 (1.4366)	36.850 (1.4385)	36.900 (1.4405)	36.950 (1.4424)	37.000 (1.4444)	3
--------------------------------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	---




20. REINSTALL CYLINDER HEAD COVERS

(a) Apply seal packing to the cylinder heads as shown in the illustration.

Seal packing:


Part No. 08826-00080 or equivalent



(b) Install the gasket to the cylinder head cover.

(c) Install the cylinder head cover with the 8 bolts. Uniformly tighten the bolts in several passes. Install the 2 cylinder head covers.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



21. REINSTALL SPARK PLUGS

Using a 16 mm plug wrench, install the 6 spark plugs to the RH and LH cylinder heads.


Torque: 18 N-m (180 kgf-cm, 13 ft-lbf)




22. REINSTALL IGNITION COILS

Install the 6 ignition coils to the RH and LH cylinder heads.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)

**23. RECONNECT ENGINE WIRE TO ENGINE RH SIDE**


- (a) Connect the engine wire with the 5 nuts.
- (b) Connect the following connectors:
 - (1) 3 injector connectors
 - (2) 3 ignition coil connectors

**24. RECONNECT ENGINE WIRE TO ENGINE REAR SIDE**


Connect the engine wire with the 2 nuts.

**25. RECONNECT ENGINE WIRE TO ENGINE LH SIDE**

- (a) Connect the engine wire with the 2 nuts.
- (b) Connect the following connectors:
 - (1) 3 injector connectors
 - (2) 3 ignition coil connectors

**26. RECONNECT ENGINE WIRE TO NO.3 TIMING BELT COVER**


- (a) Connect the 3 clamps.
- (b) Connect the engine wire with the bolt.



27. REINSTALL AIR INTAKE CHAMBER


(a) Using an 8 mm hexagon wrench, install a new gasket and the air intake chamber with the 2 bolts and 2 nuts.

Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)




(b) Connect the following hoses:

- (1) 2 water bypass hoses
- (2) Air assist hose




(c) Connect the following vacuum hoses:

- (1) 2 vacuum hoses to TVV
- (2) Vacuum hose to cylinder head rear plate



(3) Vacuum hose to charcoal canister




(d) Connect the following connectors:

- (1) Throttle position sensor connector
- (2) IACV valve connector
- (3) EGR gas temperature sensor connector
- (4) A/C idle-up connector



(e) Install 2 new gaskets and EGR pipe with the 4 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)




(f) install the No. 1 engine hanger with the 2 bolts.

Torque: 39 N-m (400 kgf-cm, 19 ft-lbf)


(g) Install the air intake chamber stay with the 2 bolts.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)



(h) Connect the 2 PS air hoses.


(i) Connect the PS pressure tube with the 2 nuts.




(j) Connect the RH oxygen sensor connector clamp to the PS pressure tube.

(k) Connect the ground strap with the bolt.

(l) Connect the hydraulic pressure pipe to the air intake chamber with the bolt.




- (m) Connect the following hoses:
- (1) Brake booster vacuum hose
 - (2) PCV hose
 - (3) Intake air control valve vacuum hose
- (n) Connect the data link connector 1.
- (o) Connect the 2 ground straps with the nut.




28. REINSTALL EMISSION CONTROL VALVE SET

- (a) Install the emission control valve set with the 2 bolts.


Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



- (b) Connect the following connectors:
- (1) Intake control valve connector
 - (2) Fuel pressure connector
 - (3) EGR VSV connector




- (c) Connect the following vacuum hoses:
- (1) Vacuum hose to fuel pressure control VSV
 - (2) Vacuum hose to fuel pressure regulator
 - (3) Vacuum hose to cylinder head rear plate
 - (4) Vacuum hose to intake air control valve
 - (5) Vacuum hose to EGR vacuum modulator
 - (6) Vacuum hose to EGR valve




28. REINSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V- bank cover with the 2 nuts.




29. REINSTALL AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE

- (a) Connect the air cleaner hose, and install the air cleaner cap and volume air flow meter with the 4 clips.
- (b) Tighten the air cleaner hose clamp bolt.
- (c) Connect the PCV hose.
- (d) Connect the accelerator cable clamp.
- (e) Connect the volume air flow meter connector and wire clamp.



30. RECONNECT THROTTLE CABLE

31. RECONNECT ACCELERATOR CABLE



32. RECONNECT RADIATOR INLET HOSE

33. FILL WITH ENGINE COOLANT

Capacity:


8.7 liters (9.2 US qts, 7.7 Imp. qts)

34. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

IGNITION TIMING INSPECTION

1. WARM UP ENGINE

Allow the engine to warm up to normal operating temperature.



2. CONNECT TACHOMETER TO ENGINE



Connect the tester probe of a tachometer to terminal IG(-) of the data link connector 1.

NOTICE:

- Never allow the tachometer terminal to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your unit before use.


3. CONNECT TIMING LIGHT TO ENGINE

(a) Using a 5 mm hexagon wrench, remove the 2 cap nuts and V- bank cover.




(b) Connect the timing light pickup clip to the the green lead wire for the No.4 ignition coil.

HINT: Use a timing light that can detect the primary signal.



4. CHECK IDLE SPEED


(a) Race the engine speed at 2,500 rpm for approx. 90 seconds.



(b) Check the idle speed.

Idle speed:


700 ± 60 rpm



5. INSPECT IGNITION TIMING

(a) Using SST, connect terminals TE1 and E1 of the data link connector 1.

SST 09843-18020



(b) Using a timing light, check the ignition timing.

Ignition timing:

8 – 12₂ BTDC @ idle



(Transmission in neutral position)

If the ignition timing is not as specified, check that following conditions are normal:

- Throttle valve fully closed
- Continuity between terminals IDL1 and E2 of the throttle position sensor.
- Valve timing

(c) Remove the SST from the data link connector 1.

SST 09843-18020




6. FURTHER CHECK IGNITION TIMING

Ignition timing:

7 – 17₂ BTDC @ idle

(Transmission in neutral position)

HINT: The timing mark moves in a range between 7₂ and 17₂.

**7. DISCONNECT TIMING LIGHT FROM ENGINE**


- (a) Remove the timing light.
- (b) Using a 5 mm hexagon wrench, install the V-bank cover with the 2 cap nuts.

8. DISCONNECT TACHOMETER FROM ENGINE

IDLE SPEED INSPECTION

1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
 - (b) Air cleaner installed
 - (c) All pipes and hoses of air induction system connected
 - (d) All accessories switched OFF
 - (e) All vacuum lines properly connected
- HINT: All vacuum hoses for EGR system, etc. should be properly connected.
- (f) SFI system wiring connectors fully plugged
 - (g) Ignition timing set correctly
 - (h) Transmission, in neutral position



2. CONNECT TACHOMETER



Connect the tester probe of a tachometer to terminal IG(–) of the data link connector 1.

NOTICE:

- Never allow the tachometer terminal to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your unit before use.

3. INSPECT IDLE SPEED

- (a) Race the engine speed at 2,500 rpm for approx. 90 seconds.



- (b) Check the idle speed.

Idle speed:

700 ± 50 rpm

If the idle speed is not as specified, check the IAC valve and air intake system.


4. DISCONNECT TACHOMETER

IDLE AND OR 2500 RPM CO HC CHECK

HINT: This check is used only to determine whether or not the idle CO/HC complies with regulations.


1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
 - (b) Air cleaner installed
 - (c) All pipes and hoses of air induction system connected
 - (d) All accessories switched OFF
 - (e) All vacuum lines properly connected
- HINT: All vacuum hoses for EGR systems, etc. should be properly connected.
- (f) SFI system wiring connectors fully plugged
 - (g) Ignition timing set correctly
 - (h) Transmission in neutral position
 - (i) Tachometer and CO/HC meter calibrated by hand



2. START ENGINE

3. RACE ENGINE AT 2,500 RPM FOR APPROX. 180 SECONDS



4. INSERT CO/NC METER TESTING PROBE AT LEAST 40 cm (1.3 ft) INTO TAILPIPE DURING IDLING

5. IMMEDIATELY CHECK CO/HC CONCENTRATION AT IDLE AND/OR 2,500 RPM

HINT: When performing the 2 mode (2,500 rpm and idle) test, follow the measurement order prescribed by the applicable local regulations.

Troubleshooting

If the CO/HC concentration does not comply with regulations, perform troubleshooting in the order given below.

See the table below for possible causes, and then inspect and correct the applicable causes if necessary.


CO	HC	Phenomenon	Causes
Normal	High	Rough idle	1. Faulty ignitions: <ul style="list-style-type: none"> • Incorrect timing • Fouled, shorted or improperly gapped plugs • Open or crossed high-tension cords • Cracked distributor cap 2. Incorrect valve clearance 3. Leaky EGR valve 4. Leaky intake and exhaust valves 5. Leaky cylinder
Low	High	Rough idle (Fluctuating HC reading)	1. Vacuum leaks: <ul style="list-style-type: none"> • PCV hose • EGR valve • Intake manifold • Air intake chamber • Throttle body • IAC valve • Brake booster line 2. Lean mixture causing misfire
High	High	Rough idle (Black smoke from exhaust)	1. Restricted air filter 2. Faulty SFI systems: <ul style="list-style-type: none"> • Faulty fuel pressure regulator • Clogged fuel return line • Defective ECT switch • Faulty ECM • Faulty injector • Faulty throttle position sensor • Faulty volume air flow meter

COMPRESSION CHECK

HINT: If there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.


1. WARM UP AND STOP ENGINE

Allow the engine to warm up to normal operating temperature.




2. REMOVE V-BANK COVER

Using a 5 mm hexagon wrench, remove the 2 cap nuts and V-bank cover.




3. REMOVE IGNITION COILS


(a) Disconnect the 6 connectors from the RH and LH cylinder heads.



(b) Remove the 6 bolts and 6 ignition coils from the RH and LH cylinder heads.




HINT: Arrange the ignition coils in the correct order.



4. REMOVE SPARK PLUGS

Using a 16 mm plug wrench, remove the 6 spark plugs from the RH and LH cylinder heads.



5. CHECK CYLINDER COMPRESSION PRESSURE

- (a) Insert a compression gauge into the spark plug hole.
- (b) Fully open the throttle.
- (c) While cranking the engine, measure the compression pressure.

HINT: Always use a fully charged battery to obtain engine speed of 250 rpm or more.

- (d) Repeat steps (a) through (c) for each cylinder.

NOTICE: This measurement must be done in as short a time as possible.

Compression pressure:

1,226 kPa (12.5 kgf/cm², 178 psi) or more

Minimum pressure:


981 kPa (10.0 kgf/cm², 142 psi)

Difference between each cylinder:

98 kPa (1.0 kgf/cm², 14 psi) or less

- (e) If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat steps (a) through (c) for cylinders with low compression.


- If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
- If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.



6. REINSTALL SPARK PLUGS

Using a 16 mm plug wrench, install the 6 spark plugs to the RH and LH cylinder heads.


Torque: 18 N-m (180 kgf-cm, 13 ft-lbf)




7. INSTALL IGNITION COILS

(a) Install the 6 ignition coil to the RH and LH cylinder heads with the 6 bolts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



(b) Connect the 6 ignition coil connectors.




8. REINSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V –bank cover with the 2 cap nuts.


TIMING BELT COMPONENTS FOR REMOVAL AND INSTALLATION


8087X-61



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part





TIMING BELT REMOVAL


(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY



CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.

2. REMOVE ENGINE COOLANT RESERVOIR TANK

(a) Disconnect the reservoir hose.




(b) Using a screwdriver, remove the reservoir tank.




3. REMOVE GENERATOR DRIVE BELT

Loosen the pivot bolt and adjusting lock bolt, and remove the drive belt.




4. REMOVE RH FRONT WHEEL


5. REMOVE RH FENDER APRON SEAL

**6. REMOVE PS DRIVE BELT**


Loosen the 2 bolts, and remove the drive belt.

**7. DISCONNECT GROUND STRAPS**


Disconnect the 2 straps.

**8. REMOVE RH ENGINE MOUNTING STAY**


Remove the 3 bolts and RH engine mounting stay.

**9. REMOVE ENGINE MOVING CONTROL ROD AND NO.2 RH ENGINE MOUNTING BRACKET**


Remove the 3 bolts, control rod and mounting bracket.

**10. REMOVE NO.2 GENERATOR BRACKET**



- (a) Loosen the generator pivot bolt.
- (b) Remove the nut and bracket.

**11. REMOVE CRANKSHAFT PULLEY**


- (a) Using SST, remove the pulley bolt.
SST 09213-54016, 09330-00021




- (b) Using SST, remove the pulley.
SST 09213-00060

**12. REMOVE No.1 TIMING BELT COVER**
Remove the 4 bolts and timing belt cover.**13. DISCONNECT ENGINE WIRE**



- (a) Remove the bolt holding the engine wire to the No.3 timing belt cover.
(b) Disconnect the engine wire from the clamp.

**14. REMOVE NO.2 TIMING BELT COVER**

- Remove the 5 bolts and timing belt cover.

**15. REMOVE ENGINE RH MOUNTING BRACKET**


Remove the 2 bolts, nut and mounting bracket.

**16. REMOVE TIMING BELT GUIDE****17. SET NO.1 CYLINDER TO TDC/COMPRESSION**

(a) Temporarily install the crankshaft pulley bolt to the crankshaft.

(b) Turn the crankshaft and align the crankshaft timing pulley groove with the oil pump alignment mark.


NOTICE: Always turn the crankshaft clockwise.



(c) Check that timing marks of the camshaft timing pulleys and No.3 timing belt cover are aligned.

If not, turn the crankshaft 1 revolution (360°).

(d) Remove the crankshaft pulley bolt.




18. IF REUSING TIMING BELT, CHECK INSTALLATION MARKS ON TIMING BELT

Check that there are 3 installation marks and front mark on the timing belt.


If the installation and front marks have disappeared, before removing the timing belt, place new installation and front marks on the timing belt to the following position:

- Timing mark of RH camshaft timing pulley
- Timing mark of LH camshaft timing pulley
- Dot mark of crankshaft timing pulley




19. REMOVE TIMING BELT TENSIONER

Alternately loosen the 2 bolts, and remove them, the tensioner and dust boot.




20. REMOVE TIMING BELT




21. REMOVE CAMSHAFT TIMING PULLEYS


- (a) Using SST, remove the bolt and RH timing pulley.
SST 09249 – 63010, 09960 – 10010 (09962 – 01000)



(b) Using SST, remove the LH timing pulley.
SST 09960-10010 (09962-01000)




HINT: Arrange the camshaft timing pulleys (RH and LH sides).




22. REMOVE NO.2 IDLER PULLEY

Remove the bolt and idler pulley.




23. REMOVE No.1 IDLER PULLEY

Using a 10 mm hexagon wrench, remove the bolt, idler pulley and plate washer.




24. REMOVE CRANKSHAFT TIMING PULLEY

(a) Remove the bolt and timing belt plate.



(b) Using SST, remove the crankshaft timing pulley.
SST 09213-60017 (09213-00020, 09213-00030, 09213-00050)

NOTICE: Do not scratch the sensor part of the crankshaft timing pulley.



TIMING BELT INSPECTION

1. INSPECT TIMING BELT



NOTICE:

- Do not bend, twist or turn the timing belt inside out.
- Do not allow the timing belt to come into contact with oil, water or steam.
- Do not utilize timing belt tension when installing or removing the mount bolt of the camshaft timing pulley.


If there are any defects, as shown in the illustrations, check the following points:

(a) Premature parting


- Check for proper installation.
- Check the timing cover gasket for damage and proper installation.




(b) If the belt teeth are cracked or damaged, check to see if either camshaft is locked.



(c) If there is noticeable wear or cracks on the belt face, check to see if there are nicks on the side of the idler pulley lock and water pump.




(d) If there is wear or damage on only one side of the belt, check the belt guide and the alignment of each pulley.



(e) If there is noticeable wear on the belt teeth, check timing cover for damage and check gasket has been installed correctly and for foreign material on the pulley teeth.


If necessary, replace the timing belt.



2. INSPECT IDLER PULLEYS

Check that the idler pulley turns smoothly.

If necessary, replace the idler pulley.




3. INSPECT TIMING BELT TENSIONER

(a) Visually check tensioner for oil leakage.

HINT: If there is only the faintest trace of oil on the seal on the push rod side, the tensioner is all right.


If leakage is found, replace the tensioner.



(b) Hold the tensioner with both hands and push the push rod strongly as shown to check that it doesn't move.

If the push rod moves, replace the tensioner.

NOTICE: Never hold the tensioner push rod facing downward.




(c) Measure the protrusion of the push rod from the housing end.

Protrusion:

10.0 – 10.8 mm (0.394 – 0.425 in.)

If the protrusion is not as specified, replace the tensioner.



TIMING BELT INSTALLATION

(See Components for Removal and Installation)

1. INSTALL CRANKSHAFT TIMING PULLEY

(a) Align the pulley set key with the key groove of the timing pulley and slide on the timing pulley.



(b) Using SST and a hammer, tap in the timing pulley, facing the sensor side rearward.

SST 09223-46011

NOTICE: Do not scratch the sensor part of the crankshaft timing pulley.

(c) Install the timing belt plate with the bolt.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)




2. INSTALL NO.1 IDLER PULLEY

(a) Using a 10 mm hexagon wrench, install the idler pulley with the plate washer and bolt.

Torque: 34 N-m (350 kgf-cm, 25 ft-lbf)



(b) Check that the pulley bracket moves smoothly.




3. INSTALL No.2 IDLER PULLEY

(a) Install the idler pulley with the bolt.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)


(b) Check that the idler pulley moves smoothly.



4. INSTALL RH CAMSHAFT TIMING PULLEY

(a) Install the timing pulley, facing the flange side outward.

(b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.




(c) Using SST, install and torque the bolt.

SST 09249-63010, 09960-10010 (09962-01000)

Torque: 88 N-m (900 kgf-cm, 65 ft-lbf)


HINT: Use a torque wrench with a fulcrum length of 340 mm (113.39 in.)



5. INSTALL LH CAMSHAFT TIMING PULLEY

(a) Install the timing pulley, facing the flange side inward.


(b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.



(d) Using SST, install and torque the bolt.

SST 09960-10010 (09962-01000)

Torque: 126 N-m (1,300 kgf-cm, 94 ft-lbf)




6. SET NO.1 CYLINDER TO TDC/COMPRESSION

(a) Crankshaft Timing Pulley Position:

Temporarily install the crankshaft pulley bolt to the crankshaft.

Turn the crankshaft and align the crankshaft timing pulley groove with the oil pump alignment mark.



(b) RH Camshaft Timing Pulley Position:


Using SST, turn the camshaft pulley, align the timing marks of the camshaft and the No.3 timing belt cover.

SST 09960-10010 (09962-01000)

(c) LH Camshaft Timing Pulley Position:

Using SST, turn the camshaft pulley, align the timing marks of the camshaft and the No.3 timing belt cover.

SST 09960-10010 (09962-01000)



7. INSTALL TIMING BELT


NOTICE: The engine should be cold.

(a) Remove any oil or water on the pulleys, and keep them clean.

(b) Check the timing belt front mark.


(c) Align the installation mark on the timing belt with the dot mark of the crankshaft timing pulley.

(d) Align the installation marks on the timing belt with the timing marks of the camshaft timing pulleys.




(e) Install the timing belt with the following order:

- Crankshaft timing pulley
- Water pump pulley
- LH camshaft timing pulley
- No.2 idler pulley
- RH camshaft timing pulley
- No.1 idler pulley




8. SET TIMING BELT TENSIONER

- Using a press, slowly press in the push rod using 981–9,807 N (1100–1,000 kgf, 200–2,205 lbf) of pressure.
- Align the holes of the push rod and housing, pass a 1.27 mm hexagon wrench through the holes to keep the setting position of the push rod.
- Release the press.




- Install the dust boot to the tensioner.




9. INSTALL TIMING BELT TENSIONER

- Temporarily install the tensioner with the 2 bolts.
- Alternately tighten the 2 bolts.

Torque: 27 N·m (280 kgf·cm, 20 ft·lbf)




- Remove the 1.27 mm hexagon wrench from the tensioner.



10. CHECK VALVE TIMING

- Turn the crankshaft, and align the crankshaft timing pulley groove with the oil pump alignment mark.


NOTICE: Always turn the crankshaft clockwise.



(b) Check that the timing marks of the RH and LH timing pulleys with the timing marks of the No.3 timing belt cover as shown in the illustration.


If the marks do not align, remove the timing belt and reinstall it.

(c) Remove the crankshaft pulley bolt.



11. INSTALL TIMING BELT GUIDE


Install the belt guide, facing the cup side outward.



12. INSTALL ENGINE RH MOUNTING BRACKET

Install the mounting bracket with the 2 bolts and nut.

Torque: 28 N·m (290 kgf·cm, 21 ft·lbf)




13. INSTALL NO.2 TIMING BELT COVER

(a) Check that the timing belt cover gasket has no cracks or peeling, etc.


If the gasket does have cracks or peeling, etc., replace it using following steps.

- (1) Using a screwdriver and gasket scraper, remove all the old gasket material.
- (2) Thoroughly clean all components to remove all the loose material.
- (3) Remove the backing paper from a new gasket and install the gasket evenly to the part of the belt cover shaded black in the illustration.
- (4) After installing the gasket, press down on it so that the adhesive firmly sticks to the belt cover.

(b) Install new gasket to the No.2 belt cover.




(c) Install the belt cover with the 5 bolts.
Torque: 8.5 N-m (85 kgf-cm. 74 in.-lbf)



14. CONNECT ENGINE WIRE

- (a) Connect the engine wire with the clamp.
- (b) Install the bolt holding the engine wire to the No.3 timing belt cover.



15. INSTALL NO.1 TIMING BELT COVER


- (a) Check that the timing belt cover gaskets have cracks or peeling, etc.

If the gasket does have cracks or peeling, etc., replace it using following steps, peeling, etc., replace them using following steps.


- (1) Using a screwdriver and gasket scraper, remove all the old gasket material.
- (2) Thoroughly clean all components to remove all the loose material.
- (3) Remove the backing paper from a new gasket and install the gasket evenly to the part of the belt cover shaded back in the illustration.

NOTICE: When joining 2 gaskets, do not leave a gap between them. Cut off any excess gasket.

- (4) After installing the gasket, press down on it so that the adhesive firmly sticks to the belt cover.
- (b) Install new gaskets to the No.1 belt cover.



(c) Install the belt cover with the 4 bolts.
Torque: 8.5 N-m (85 kgf-cm, 74 in.-lbf)


**16. INSTALL CRANKSHAFT PULLEY**

(a) Align the pulley set key with the key groove of the pulley, and slide the pulley.

(b) Using SST, install and torque the bolt.


SST 09213-54015, 09330-00021

Torque: 216 N-m (2,200 kgf-cm, 159 ft-lbf)

**17. INSTALL NO.2 GENERATOR BRACKET**


Install the bracket with the pivot bolt and nut. Do not tighten the bolt yet.

Torque: 28 N-m (290 kgf-cm, 21 ft-lbf) for Nut

**18. INSTALL NO.2 RH ENGINE MOUNTING BRACKET AND ENGINE MOVING CONTROL ROD**


Install the mounting bracket and control rod with the 3 bolts.

Torque: 63.7 N-m (650 kgf-cm, 47 ft-lbf)


**19. INSTALL RH ENGINE MOUNTING STAY**

Install the mounting stay with the 3 bolts.

Torque: 31.4 N-m (320 kgf-cm, 23 ft-lbf)

**24. CONNECT GROUND STRAPS**

Connect the 2 straps.

**21. INSTALL AND ADJUST PS DRIVE BELT**


Install the drive belt with the pivot and adjusting bolts.

Drive belt tension:**New belt**

150 ± 185 lbf

Used belt

115 ± 20 lbf

**22. INSTALL GENERATOR DRIVE BELT**


Adjust the drive belt. (See CH section)

Drive belt tension:**New belt**

175 ± 5 lbf


Used belt


115 ± 20 lbf

23. INSTALL COOLANT RESERVOIR TANK**24. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY****25. START ENGINE, AND CHECK FOR ABNORMAL NOISE AND SMOOTH OPERATION****26. INSTALL RH FENDER APRON SEAL****27. INSTALL RH FRONT WHEEL**

CYLINDER HEAD COMPONENTS FOR REMOVAL AND INSTALLATION


80989-01






N-m (kgf-cm, ft-lbf) : Specified torque


◆ Non-reusable part




N-m (kgf-cm, ft-lbf) : Specified torque

- ◆ Non-reusable part
- For use with SST







CYLINDER HEADS REMOVAL

(See Components for Removal and Installation)



1. REMOVE BATTERY AND TRAY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. DRAIN ENGINE COOLANT

3. DISCONNECT ACCELERATOR CABLE

4. DISCONNECT THROTTLE CABLE



5. REMOVE AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE

(a) Disconnect the volume air flow meter connector and wire clamp.

(b) Disconnect the accelerator cable clamp.

(c) Disconnect the PCV hose.

(d) Loosen the air cleaner hose clamp bolt.

(e) Disconnect the 4 air cleaner cap clips.

(f) Remove the air cleaner cap and volume air flow meter together with the air cleaner hose.


6. w/ CRUISE CONTROL SYSTEM:

REMOVE CRUISE CONTROL ACTUATOR

(a) Remove the bolt, clip and actuator cover.


(b) Disconnect the actuator connector and clamp.


(c) Remove the 3 bolts, and disconnect the actuator with the bracket.





7. DISCONNECT GROUND STRAPS

Disconnect the 2 straps.




**8. REMOVE RH ENGINE MOUNTING STAY**

Remove the 3 bolts and RH engine mounting stay.

**9. DISCONNECT RADIATOR HOSES****10. DISCONNECT HEATER HOSES**

Disconnect the 2 hoses.


**11. DISCONNECT FUEL HOSES**

Disconnect the fuel inlet and return hoses.

CAUTION: Catch leaking fuel in a container.


**12. DISCONNECT PRESSURE HOSE OF HYDRAULIC MOTOR**

Remove the bolt, and disconnect the pressure hose from the water inlet.



13. REMOVE V – BANK COVER


Using a 5 mm hexagon wrench, remove the 2 nuts and V-bank cover.



14. REMOVE EMISSION CONTROL VALVE SET


(a) Disconnect the following vacuum hoses:

- (1) Vacuum hose from fuel pressure control VSV
- (2) Vacuum hose from fuel pressure regulator
- (3) Vacuum hose from cylinder head rear plate
- (4) Vacuum hose from intake air control valve VSV
- (5) Vacuum hose from EGR vacuum modulator
- (6) Vacuum hose from EGR valve




(b) Disconnect the following connectors:

- (1) Intake air control valve connector
- (2) Fuel pressure connector
- (3) EGR VSV connector



(c) Remove the 2 nuts and emission control valve set.




15. REMOVE AIR INTAKE CHAMBER

(a) Disconnect the following hoses:


- (1) Brake booster vacuum hose
- (2) PCV hose
- (3) Intake air control valve vacuum hose

(b) Disconnect the data link connector 1.


(c) Remove the nut and disconnect the 2 ground straps.



- (d) Remove the bolt and disconnect the hydraulic motor pressure hose from the air intake chamber.
- (e) Remove the bolt, and disconnect the ground strap.
- (f) Disconnect the RH oxygen sensor connector clamp from the PS pressure tube.




- (g) Remove the 2 nuts, and disconnect the PS pressure tube.
- (h) Disconnect the 2 PS air hoses.




- (i) Remove the 2 bolts and No.1 engine hanger.
- (j) Remove the 2 bolts and air intake chamber stay.




- (k) Remove the 4 nuts, EGR pipe and 2 gaskets.




- (l) Disconnect the following connectors:
- (1) Throttle position sensor connector
 - (2) IAC valve connector
 - (3) EGR gas temperature sensor connector
 - (4) A/C idle-up connector




- (m) Disconnect the following vacuum hoses:
- (1) 2 vacuum hoses from TVV
 - (2) Vacuum hose from cylinder head rear plate




- (3) Vacuum hose from charcoal canister



- (n) Disconnect the following hoses:
- (1) 2 water bypass hoses
 - (2) Air assist hose




- (o) Using an 8 mm hexagon wrench, remove the 2 bolts, 2 nuts, air intake chamber and gasket.




16. REMOVE INTAKE AIR CONTROL VALVE FROM AIR INTAKE CHAMBER

- (a) Disconnect the A/C air hose.
- (b) Remove the 3 nuts and data link connector 1 clamp.
- (c) Remove the intake air control valve by prying a screwdriver between the intake air control valve and air intake chamber.
- (d) Remove the gasket.




17. REMOVE A/C IDLE-UP VSV FROM AIR INTAKE CHAMBER

- (a) Disconnect the air hose.
- (b) Remove the 2 bolts and A/C idle-up VSV.




18. REMOVE THROTTLE BODY FROM AIR INTAKE CHAMBER

- (a) Disconnect the following vacuum hoses:
 - (1) Vacuum hose from P port of EGR vacuum modulator
 - (2) Vacuum hose from R port of EGR vacuum modulator
- (b) Remove the 2 bolts, 2 nuts, throttle body and gasket.




19. REMOVE EGR VALVE AND VACUUM MODULATOR FROM AIR INTAKE CHAMBER

Remove the 3 nuts, EGR valve, vacuum modulator and gasket.




20. DISCONNECT ENGINE WIRE FROM ENGINE LH SIDE

- (a) Disconnect the following connectors:
 - (1) 3 injector connectors
 - (2) 3 ignition coil connectors
- (b) Remove the 2 nuts, and disconnect the engine wire.



21. DISCONNECT ENGINE WIRE FROM NO.3 TIMING BELT COVER

Disconnect the 2 clamps and engine wire.




22. DISCONNECT ENGINE WIRE FROM ENGINE REAR SIDE

(a) Disconnect the following connectors:

- (1) LH oxygen sensor
- (2) Engine coolant temperature sensor
- (3) Camshaft position sensor

(b) Disconnect the 3 clamps.

(c) Remove the 2 nuts, and disconnect the engine wire.




23. DISCONNECT ENGINE WIRE FROM ENGINE RH SIDE

(a) Disconnect the following connectors:


- (1) 3 injector connectors
- (2) 3 ignition coil connectors
- (3) Water temperature sender gauge connector
- (4) Water temperature sensor connector
- (5) RH oxygen sensor connector

(b) Remove the 5 nuts, and disconnect the engine wire.




24. REMOVE IGNITION COILS

Remove the 6 bolts and 6 ignition coils from the RH and LH cylinder heads.




HINT: Arrange the ignition coils in the correct order.




25. REMOVE SPARK PLUGS

Using a 16 mm plug wrench, remove the 6 spark plugs from the RH and LH cylinder heads.



26. REMOVE FRONT EXHAUST PIPE

(a) Remove the 2 bolts and front exhaust pipe clamp.



(b) Remove the 2 bolts, and disconnect the bracket.


(c) Remove the 2 bolts and 2 nuts holding the front exhaust pipe to the three-way catalytic converter.

(d) Remove the 4 nuts holding the front exhaust pipe to the exhaust manifolds.


(e) Remove the front exhaust pipe and gaskets.

27. REMOVE TIMING BELT


(See steps 2 to 20 on pages [EG2-41](#) to 45)

**28. REMOVE CAMSHAFT TIMING PULLEYS**


(a) Using SST, remove the bolt and RH timing pulley.
SST 09249-63010, 09960-10010 (09862-01000)




(b) Using SST, remove the LH timing pulley.
SST 09960-10010 (09962-01000)




HINT: Arrange the camshaft timing pulleys (RH and LH sides).

**29. REMOVE NO.2 IDLER PULLEY**


Remove the bolt and idler pulley.

**30. REMOVE NO.3 TIMING BELT COVER**



Remove the 6 bolts and belt cover.

**31. REMOVE CYLINDER HEAD REAR PLATE**


- (a) Disconnect the vacuum hose from the vacuum tank.
- (b) Remove the nut, and disconnect the ground strap.
- (c) Remove the bolt and rear plate.

**32. REMOVE WATER INLET PIPE**

- (a) Remove the bolt and inlet pipe.
- (b) Remove the O-ring.


**33. REMOVE AIR ASSIST HOSE AND VACUUM HOSE****34. REMOVE INTAKE MANIFOLD, DELIVERY PIPES AND INJECTORS**

Remove the 9 bolts, 2 nuts, 2 plate washers and intake manifold together with the delivery pipes, and injectors.




35. REMOVE FUEL PRESSURE REGULATOR FROM LH DELIVERY PIPE

- (a) Remove the 2 bolts, and pull out the pressure regulator.
- (b) Remove the O-ring from the pressure regulator.




36. REMOVE TVV FROM INTAKE MANIFOLD




37. REMOVE FUEL PULSATION DAMPER AND No.1 FUEL PIPE

Remove the bolt, pulsation damper, No. 1 fuel pipe and 2 gaskets.



38. REMOVE No.2 FUEL PIPE

Remove the 2 union bolts, No.2 fuel pipe and 4 gaskets.




39. REMOVE DELIVERY PIPES AND INJECTORS


- (a) Remove the 4 bolts, delivery pipes together with the 6 injectors.

NOTICE: Be careful not to drop the injectors when removing the delivery pipes.

- (b) Remove the 4 spacers from the intake manifold.




- (c) Pull out the 6 injectors from the delivery pipes.
Remove the O-ring and grommet from each injector.




40. REMOVE WATER OUTLET

- (a) Remove the 2 bolts, 2 nuts and 2 plate washers.
(b) Disconnect the water bypass hose and remove the water outlet.
(c) Remove the 2 intake manifold gaskets.




41. REMOVE No.2 ENGINE HANGER

- Remove the 2 bolts and engine hanger.




42. REMOVE LH EXHAUST MANIFOLD


- (a) Remove the main heated oxygen sensor (Bank 2 Sensor 1).



- (b) Remove the bolt, nut and exhaust manifold stay.




(c) Remove the 6 nuts, exhaust manifold and gasket.




43. REMOVE OIL DIPSTICK AND GUIDE

- (a) Remove the bolt holding the dipstick guide to the LH cylinder head.
- (b) Pull out the dipstick guide together with the dipstick from the No.1 oil pan.
- (c) Remove O-ring from the dipstick guide.




44. REMOVE PS BRACKET

Remove the 3 bolts and PS bracket.




45. REMOVE RH EXHAUST MANIFOLD


- (a) Remove the main heated oxygen sensor (Bank 1 Sensor 1).




- (b) Remove the 4 nuts, EGR pipe and 2 gaskets.



(c) Remove the bolts, 2 nuts, exhaust manifold stay and exhaust manifold plate.




(d) Remove the 6 nuts, exhaust manifold and gasket.



46. REMOVE CYLINDER HEAD COVERS

Remove the 8 bolts, cylinder head cover and gasket.
Remove the 2 cylinder head covers.




47. REMOVE CAMSHAFT POSITION SENSOR

(a) Remove the bolt and position sensor.
(b) Remove the gasket from the position sensor.


48. REMOVE CAMSHAFTS

NOTICE: Since the thrust clearance of the camshaft is small, the camshaft must be held level while it is being removed. If the camshaft is not kept level, the portion of the cylinder head receiving the shaft thrust may crack or be damaged, causing the camshaft to seize or break. To avoid this, the following steps should be carried out.



A. Remove intake camshaft of RH cylinder head

(a) Align the timing marks (2 dot marks) of the camshaft drive and driven gears by turning the camshaft with a wrench.



(b) Secure the exhaust camshaft sub-gear to the main gear with a service bolt.


Recommended service bolt:

Thread diameter 6 mm

Thread pitch 1.0 mm


Bolt length 16–20 mm

HINT: When removing the camshaft, mark certain that the torsional spring force of the sub-gear has been eliminated by the above operation.



(c) Uniformly loosen and remove the 10 bearing cap bolts, in several passes, in the sequence shown.


(d) Remove the 5 bearing caps and intake camshaft.



B. Remove exhaust camshaft of RH cylinder head


(a) Uniformly loosen and remove the 10 bearing cap bolts, in several passes, in the sequence shown.

(b) Remove the 5 bearing caps, oil seal and exhaust camshaft.



C. Remove intake camshaft of LH cylinder head

(a) Align the timing marks (11 dot mark) of the camshaft drive and driven gears by turning the camshaft with a wrench.



(b) Secure the exhaust camshaft sub-gear to the main gear with a service bolt.


Recommended service bolt:

Thread diameter 6 mm

Thread pitch 1.0 mm


Bolt length 16–20 mm

HINT: When removing the camshaft, make sure that the torsional spring force of the sub-gear has been eliminated by the above operation.



(c) Uniformly loosen and remove the 10 bearing cap bolts, in several passes, in the sequence shown.


(d) Remove the 5 bearing caps and intake camshaft.



D. Remove exhaust camshaft of LH cylinder head


(a) Uniformly loosen and remove the 10 bearing cap bolts, in several passes, in the sequence shown.

(b) Remove the 5 bearing caps, oil seal and exhaust camshaft.




HINT:

- Arrange the camshafts in the correct order.




- Arrange the bearing caps in the correct order.



49. DISASSEMBLE EXHAUST CAMSHAFTS


(a) Mount the hexagonal wrench head portion of the camshaft in a vise.

NOTICE: Be careful not to damage the camshaft.




(b) Using SST, turn the sub-gear counterclockwise, and remove the service bolt.

SST 09960-10010 (09962-0100)




(c) Using snap ring pliers, remove the snap ring.




(d) Remove the following parts:

- (1) Wave washer
- (2) Camshaft sub-gear
- (3) Camshaft gear spring




HINT: Arrange the camshaft sub-gears and gear springs (RH and LH sides).



50. REMOVE CYLINDER HEADS


(a) Using a 8 mm hexagon wrench, remove the cylinder head (recessed head) bolt on each cylinder head, then repeat for the other side, as shown.



(b) Uniformly loosen and remove the 8 cylinder head (12 pointed head) bolts on each cylinder head, in several passes, in the sequence shown, then repeat for the other side, as shown.

Remove the 16 cylinder head bolts and plate washers.


NOTICE: Head warpage or cracking could result from removing bolts in an incorrect order.



(c) Lift the cylinder head from the dowels on the cylinder block and place the 2 cylinder heads on wooden blocks on a bench.

HINT: If the cylinder head is difficult to lift off, pry with a screwdriver between the cylinder head and cylinder block saliences.


NOTICE: Be careful not to damage the contact surfaces of the cylinder head and cylinder block.




CYLINDER HEAD DISASSEMBLY

(See Components for Removal and Installation)

1. REMOVE VALVE LIFTERS AND SHIMS




HINT: Arrange the valve lifters and shims in the correct order.



2. REMOVE VALVES


(a) Using SST, compress the valve spring and remove the 2 keepers.

SST 09202 – 70010




(b) Remove the following parts:


- (1) Spring retainer
- (2) Valve spring
- (3) Valve




(c) Using needle-nose pliers, remove the oil seal.



(d) Using compressed air and a magnetic finger, remove the spring seat by blowing air.




HINT: Arrange the valves, valve springs, spring seats and spring retainers in the correct order.



CYLINDER HEAD COMPONENTS INSPECTION AND REPAIR

1. CLEAN TOP SURFACES OF PISTONS AND CYLINDER BLOCK


(a) Turn the crankshaft, and bring each piston to top dead center (TDC). Using a gasket scraper, remove all the carbon from the piston top surface.



(b) Using a gasket scraper, remove all the gasket material from the cylinder block surface.

(c) Using compressed air, blow carbon and oil from the bolt holes.

CAUTION: Protect your eyes when using high pressure compressed air.




2. CLEAN CYLINDER HEAD

A. Remove gasket material

Using a gasket scraper, remove all the gasket material from the cylinder block contact surface.


NOTICE: Be careful not to scratch the cylinder block contact surface.



B. Clean combustion chambers


Using a wire brush, remove all the carbon from the combustion chambers.

NOTICE: Be careful not to scratch the cylinder block contact surface.




C. Clean cylinder head

Using a soft brush and solvent, thoroughly clean the cylinder head.



D. Clean valve guide bushings

Using a valve guide bushing brush and solvent, clean all the guide bushings.



3. INSPECT CYLINDER HEAD


A. Inspect for flatness

Using a precision straight edge and feeler gauge, measure the surfaces contacting the cylinder block and the manifolds for warpage.

Maximum warpage:

0.10 mm (0.0039 in.)


If warpage is greater than maximum, replace the cylinder head.



B. Inspect for cracks

Using a dye penetrant, check the combustion chamber, intake ports, exhaust ports and cylinder block surface for cracks.


If cracked, replace the cylinder head.



4. CLEAN VALVES

(a) Using a gasket scraper, chip off any carbon from the valve head.

(b) Using a wire brush, thoroughly clean the valve.




5. INSPECT VALVE STEMS AND GUIDE BUSHINGS

(a) Using a caliper gauge, measure the inside diameter of the guide bushing.

Bushing inside diameter:

5.510 – 5.530 mm (0.2169 – 0.2177 in.)



(b) Using a micrometer, measure the diameter of the valve stem.

Valve stem diameter:

Intake

5.470 – 5.485 mm (0.2154 – 0.2159 in.)

Exhaust

5.465 – 5.480 mm (0.2152 – 0.2157 in.)

(c) Subtract the valve stem diameter measurement from the guide bushing inside diameter measurement.

Standard oil clearance:

Intake

0.025 – 0.060 mm (0.0010 – 0.0024 in.)

Exhaust

0.030 – 0.065 mm (0.0012 – 0.0026 in.)

Maximum oil clearance:


Intake

0.08 mm (0.0031 in.)

Exhaust


0.10 mm (0.0039 in.)

If the clearance is greater than maximum, replace the valve and guide bushing.




6. IF NECESSARY, REPLACE VALVE GUIDE BUSHINGS

(a) Gradually heat the cylinder head to 80 – 100₂ C (176 – 212₂ F).



(b) Using SST and a hammer, tap out the guide bushing. SST 09201– 01055, 09608–20012 (09608–03020)



(c) Using a caliper gauge, measure the bushing bore diameter of the cylinder head.


(d) Select a new guide bushing (STD or O/S 0.05). If the bushing bore diameter of the cylinder head is greater than 10.313 mm (0.4060 in.), machine the bushing bore to the following dimension:

10.345 – 10.363 mm (0.4073 – 0.4080 in.)


If the bushing bore diameter of the cylinder head is greater than 10.363 mm (0.4080 in.), replace the cylinder head.

Both intake and exhaust


Bushing bore diameter mm (in.)	Bushing size
10.295 – 10.313 (0.4053 – 0.4060)	Use STD
10.345 – 10.363 (0.4073 – 0.4080)	Use O/S 0.05



HINT: Different bushings are used for the intake and exhaust.



(e) Gradually heat the cylinder head to 80 – 100°C (176 – 212°F).



(f) Using SST and a hammer, tap in a new guide bushing to the specified protrusion height.

SST 09201– 01055, 09608–20012 (09608–03020)


Protrusion height:

Intake


11.1 – 11.3 mm (0.437 – 0.445 in.)

Exhaust

8.9 – 9.3 mm (0.350 – 0.366 in.)



(h) Using a sharp 5.5 mm reamer, ream the guide bushing to obtain the standard specified clearance (See step 5 above) between the guide bushing and valve stem.




7. INSPECT AND GRIND VALVES

(a) Grind the valve enough to remove pits and carbon.

(b) Check that the valve is ground to the correct valve face angle.

Valve face angle:

44.5°



(c) Check the valve head margin thickness.


Standard margin thickness:

1.0 mm (0.039 in.)

Minimum margin thickness:

0.5 mm (0.020 in.)

If the margin thickness is less than minimum, replace the valve.



(d) Check the valve overall length.

Standard overall length:

Intake

95.45 mm (3.5779 in.)

Exhaust

95.40 mm (3.7559 in.)

Minimum overall length:


Intake

94.95 mm (3.7382 in.)

Exhaust


94.90 mm (3.7362 in.)

If the overall length is less than minimum, replace the valve.




(e) Check the surface of the valve stem tip for wear. If the valve stem tip is worn, resurface the tip with a grinder or replace the valve.

NOTICE: Do not grind off more than minimum.



8. INSPECT AND CLEAN VALVE SEATS

(a) Using a 45₂ carbide cutter, resurface the valve seats. Remove only enough metal to clean the seats.



(b) Check the valve seating position.

Apply a light coat of prussian blue (or white lead) to the valve face. Lightly press the valve against the seat. Do not rotate valve.

(c) Check the valve face and seat for the following:



- If blue appears 360° around the face, the valve is concentric. If not, replace the valve.
- If blue appears 360° around the valve seat, the guide and face are concentric. If not, resurface the seat.

- Check that the seat contact is in the middle of the valve face with the following width:


1.0 – 1.4 mm (0.039 – 0.055 in.)

If not, correct the valve seats as follows:

- (1) If the seating is too high on the valve face, use 30° and 45° cutters to correct the seat.




- (2) If the seating is too low on the valve face, use 75° and 45° cutters to correct the seat.



(d) Hand-lap the valve and valve seat with an abrasive compound.

(e) After hand-lapping, clean the valve and valve seat.




9. INSPECT VALVE SPRINGS

(a) Using a steel square, measure the deviation of the valve spring.

Maximum deviation:

2.0 mm (0.079 in.)

If the deviation is greater than maximum, replace the valve spring.




(b) Using a vernier caliper, measure the free length of the valve spring.

Free length:

45.50 mm (1.7913 in.)

If the free length is not as specified, replace the valve spring.




(c) Using a spring tester, measure the tension of the valve spring at the specified installed length.

Installed tension:

186 – 206 N (19.0 – 21.0 kgf, 41.9 – 46.3 lbf)

at 33.8 mm (1.331 in.)

If the installed tension is not as specified, replace the valve spring.



10. INSPECT CAMSHAFTS AND BEARINGS

A. Inspect camshaft for runout


(a) Place the camshaft on V – blocks.

(b) Using a dial indicator, measure the circle runout at the center journal.

Maximum circle runout:

0.06 mm (0.0024 in.)

If the circle runout is greater than maximum, replace the camshaft.



B. Inspect cam lobes

Using a micrometer, measure the cam lobe height.

Standard cam lobe height:

Intake

42.11 – 42.21 mm (1.6579 – 1.6618 in.)

Exhaust

41.96 – 42.06 mm (1.6520 – 1.6559 in.)

Minimum cam lobe height:


Intake

41.96 mm (1.6520 in.)

Exhaust

41.81 mm (1.6461 in.)

If the cam lobe height is less than minimum, replace the camshaft.




C. Inspect camshaft journals

Using a micrometer, measure the journal diameter.

Journal diameter:

26.949 – 26.965 mm (1.0610 – 1.0616 in.)


If the journal diameter is not as specified, check the oil clearance.



D. Inspect camshaft bearings

Check that bearings for flaking and scoring.

If the bearings are damaged, replace the bearing caps and cylinder head as a set.




E. Inspect camshaft journal oil clearance

(a) Clean the bearing caps and camshaft journals.

(b) Place the camshafts on the cylinder head.

(c) Lay a strip of Plastigage across each of the camshaft journals.




(d) Install the bearing caps.


(See step 3 on pages [EG2-98](#) to 102)

Torque: 16 N·m (160 kgf·cm, 12 ft·lbf)

NOTICE: Do not turn the camshaft.



(e) Remove the bearing caps.



(f) Measure the Plastigage at its widest point.

Standard oil clearance:

0.035 – 0.072 mm (0.0014 – 0.0028 in.)

Maximum oil clearance:

0.10 mm (0.0039 in.)

If the oil clearance is greater than maximum, replace the camshaft. If necessary, replace the bearing caps and cylinder head as a set.

(g) Completely remove the Plastigage.

(h) Remove the camshafts.

F. Inspect camshaft thrust clearance

(a) Install the camshafts.

(See step 3 on pages [EG2-98](#) to 102)

(b) Using a dial indicator, measure the thrust clearance while moving the camshaft back and forth.

Standard thrust clearance:



0.040 – 0.090 mm (0.0016 – 0.0035 in.)

Maximum thrust clearance:

0.12 mm (0.0047 in.)

If the thrust clearance is greater than maximum, replace the camshaft. If necessary, replace the bearing caps and cylinder head as a set.

(c) Remove the camshafts.



G. Inspect camshaft gear backlash

(a) Install the camshafts without installing the exhaust cam sub-gear.

(See step 3 on pages [EG2-98](#) to 102)

(b) Using a dial indicator, measure the backlash.

Standard backlash:


0.020 – 0.200 mm (0.0008 – 0.0079 in.)

Maximum backlash:

0.30 mm (0.0118 in.)

If the backlash is greater than maximum, replace the camshafts.

(c) Remove the camshafts.




H. Inspect camshaft gear spring

Using a vernier caliper, measure the free distance between the spring ends.

Free distance:

18.2 – 18.8 mm (0.712 – 0.740 in.)

If the free distance is not as specified, replace the gear spring.




11. INSPECT VALVE LIFTERS AND LIFTER BORES

(a) Using a caliper gauge, measure the lifter bore diameter of the cylinder head.

Lifter bore diameter:

31.000 – 31.018 mm (1.2205 – 1.2212 in.)



(b) Using a micrometer, measure the lifter diameter.

Lifter diameter:

30.966 – 30.976 mm (1.2191 – 1.2196 in.)

(c) Subtract the lifter diameter measurement from the lifter bore diameter measurement.


Standard oil clearance:

0.024 – 0.050 mm (0.0009 – 0.0020 in.)

Maximum oil clearance:

0.07 mm (0.0028 in.)

If the oil clearance is greater than maximum, replace the lifter. If necessary, replace the cylinder head.




12. INSPECT AIR INTAKE CHAMBER

Using a precision straight edge and feeler gauge, measure the surface contacting the intake manifold for warpage.

Maximum warpage:

0.10 mm (0.0039 in.)

If warpage is greater than maximum, replace the chamber.



13. INSPECT INTAKE MANIFOLD

Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head and air intake chamber for warpage.

Maximum warpage:


Air Intake Chamber Side

0.15 mm (0.0059 in.)

Cylinder Head Side

0.08 mm (0.0031 in.)

If warpage is greater than maximum, replace the manifold.




14. INSPECT EXHAUST MANIFOLD

Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head for warpage.

Maximum warpage:

0.50 mm (0.0196 in.)

If warpage is greater than maximum, replace the manifold.



15. INSPECT CYLINDER HEAD BOLTS

(for 12 Pointed Head Bolts)

Using a caliper gauge, measure the thread outside diameter of the bolt.


Standard outside diameter:

8.95 – 9.05 mm (0.3524 – 0.3563 in.)

Minimum outside diameter:


8.75 mm (0.3445 in.)

If the diameter is less than minimum, replace the bolt.




16. IF NECESSARY, REPLACE SPARK PLUG TUBE GASKETS

- (a) Bend up the tab on the ventilation baffle plate which prevents the gasket from the slipping out.
 (b) Using a screwdriver and hammer, tap out the gasket.



- (c) Using needle-nose pliers, pry out the gasket.



- (d) Using SST and a hammer, tap in a new gasket until its surface is flush with the upper edge of the cylinder head cover.

SST 09608-20012 (09608-03070)


- (e) Apply a light coat of MP grease to the gasket lip.
 (f) Return the ventilation plate tab to its original position.

CYLINDER HEAD ASSEMBLY

(See Components for Removal and Installation)

HINT:

- Thoroughly clean all parts to be assembled.
- Before installing the parts, apply new engine oil to all sliding and rotating surfaces.
- Replace all gaskets and oil seals with new ones.




1. INSTALL SPARK PLUG TUBES

HINT: When using a new cylinder head, spark plug tubes must be installed.

- (a) Apply adhesive to the end of the spark plug tube.


Adhesive:

Part No. 08833-00070, THREE BOND 1324 or equivalent



(b) Using a press, press in a new spark plug tube until there is 42.4 – 43.4 mm (1.669 – 1.749) protruding from the camshaft bearing cap installation surface of the cylinder head.

NOTICE: Avoid pressing a new spark plug tube in too far by measuring the amount of the protrusion while pressing.




2. INSTALL PCV PIPES

HINT: When using a new cylinder head, PCV pipe must be installed.


Using a wooden block and hammer, tap in a new spark tube until its top side is flush with the cylinder head edge.

NOTICE: Be careful not to damage the cylinder head edge.




3. INSTALL VALVES

(a) Using SST, push in a new oil seal.
SST 09201 –41020




HINT: The intake valve oil seal is silver and the exhaust valve oil seal is black.




(b) Install the following parts:


- (1) Valve
- (2) Spring seat
- (3) Valve spring
- (4) Spring retainer



- (c) Using SST, compress the valve spring and place the 2 keepers around the valve stem.
SST 09202 – 70010




- (d) Using a plastic-faced hammer, lightly tap the valve stem tip to ensure a proper fit.



4. INSTALL VALVE LIFTERS AND SHIMS

- (a) Install the valve lifter and shim.
(b) Check that the valve lifter rotates smoothly by hand.



CYLINDER HEAD INSTALLATION

(See Components for Removal and Installation)

1. INSTALL CYLINDER HEADS

A. Place cylinder head on cylinder block

(a) Place 2 new cylinder head gaskets in position on the cylinder block.

NOTICE: Be careful of the installation direction.

(b) Place the 2 cylinder heads in position on the cylinder head gaskets.

B. Install cylinder head (12 pointed head) bolts

HINT:

- The cylinder head bolts are tightened in 2 progressive steps (steps (b) and (d)).



- If any bolt is broken or deformed, replace it.

(a) Apply a light coat of engine oil on the threads and under the heads of the cylinder head bolts.


(b) Install and uniformly tighten the 12 cylinder head bolts on each cylinder head, in several passes, in the sequence shown, then repeat for the other side, as shown.

Torque: 64 N·m (550 kgf·cm, 40 ft·lbf)

If any of the cylinder head bolts does not meet the torque specification, replace the cylinder head bolt.




(c) Mark the front of the cylinder head bolt head with paint.



(d) Retighten the cylinder head bolts by 90° in the numerical order shown.

(e) Check that the painted mark is now at a 90° angle to the front.




C. Install cylinder head (recessed head) bolts

(a) Apply a light coat of engine oil on the threads and under the heads of the cylinder head bolts.

(b) Using a 8 mm hexagon wrench, install the cylinder head bolt on each cylinder head, then repeat for the other side, as shown.


Torque: 18.5 N·m (185 kgf·cm, 13 ft·lbf)



2. ASSEMBLY EXHAUST CAMSHAFTS


(a) Mount the hexagonal wrench head portion of the camshaft in a vise.

NOTICE: Be careful not to damage the camshaft.




(b) Install the following parts:

- (1) Camshaft gear spring
- (2) Camshaft sub-gear
- (3) Wave washer



(c) Using snap ring pliers, install the snap ring.




(d) Using SST, align the holes of the camshaft main gear and sub-gear by turning camshaft sub-gear counterclockwise, and install a service bolt.

SST 09960-10010 (09962-0100)

HINT: Align the pins on the gears with the gear spring ends.

3. INSTALL CAMSHAFTS


NOTICE: Since the thrust clearance of the camshaft is small, the camshaft must be held level while it is being installed. If the camshaft is not level, the portion of the cylinder head receiving the shaft thrust may crack or be damaged, causing the camshaft to seize or break. To avoid this, the following steps should be carried out.




A. Install exhaust camshaft of RH cylinder head

(a) Apply new engine oil to the thrust portion and journal of the camshaft.


(b) Place the exhaust camshaft at 90° angle of timing mark (2 dot marks) on the cylinder head.



(c) Apply MP grease to a new oil seal lip.



(d) Install the oil seal to the camshaft.





- (e) Remove any old packing (FIPG) material.
- (f) Apply seal packing to the No. 1 bearing cap as shown.

Seal packing:


Part No. 08826-00080 or equivalent

- (g) Install the 5 bearing caps in their proper locations.




- (h) Apply a light coat of engine oil on the threads and under the heads of the bearing cap bolts.
- (i) Install and uniformly tighten the 10 bearing cap bolts, in several passes, in the sequence shown.

Torque: 16 N·m (160 kgf-cm, 12 ft-lbf)




B. Install intake camshaft of RH cylinder head


- (a) Apply new engine oil to the thrust portion and journal of the camshaft.
- (b) Align the timing marks (2 dot marks) of the camshaft drive and driven gears.
- (c) Place the intake camshaft on the cylinder head.



- (d) Install the 5 bearing caps in their proper locations.




(e) Apply a light coat of engine oil on the threads and under the heads of the bearing cap bolts.




(f) Install and uniformly tighten the 10 bearing cap bolts, in several passes, in the sequence shown.

Torque: 16 N-m (160 kgf-cm, 12 ft-lbf)




(g) Remove the service bolt




C. Install exhaust camshaft of LH cylinder head

(a) Apply MP grease to the thrust portion of the camshaft.


(b) Place the intake camshaft at 90° angle of timing mark (1 dot mark) on the cylinder head.



(c) Apply MP grease to a new oil seal lip.



(d) Install the oil seal to the camshaft.




(e) Remove any old packing (FIPG) material.


(f) Apply seal packing to the No. 1 bearing cap as shown.

Seal packing:

Part No. 08826-00080 or equivalent




(g) Install the 5 bearing caps in their proper locations.



(h) Apply a light coat of engine oil on the threads and under the heads of the bearing cap bolts.

(i) Install and uniformly tighten the 10 bearing cap bolts, in several passes, in the sequence shown.

Torque: 16 N-m (160 kgf-cm, 12 ft-lbf)




D. Install intake camshaft of LH cylinder head


(a) Apply MP grease to the thrust portion of the camshaft.

(b) Align the timing marks (1 dot mark) of the camshaft drive and driven gears.

(c) Place the intake camshaft on the cylinder head.




(d) Install the 5 bearing caps in their proper locations.



(e) Apply a light coat of engine oil on the threads and under the heads of bearing cap bolts.

(f) Install and uniformly tighten the 10 bearing cap bolts, in several passes, in the sequence shown.

Torque: 16 N·m (160 kgf·cm, 12 ft·lbf)



(g) Remove the service bolt.

4. CHECK AND ADJUST VALVE CLEARANCE

(See steps 17 to 19 on pages [EG2-18](#) to [23](#))

Turn the camshaft and position the cam lobe upward, and check and adjust the valve clearance.

Valve clearance (Cold):

Intake

0.15 – 0.25 mm (0.006 – 0.010 in.)

Exhaust

0.25–0.35mm(0.010–0.014in.)


6. INSTALL SEMI-CIRCULAR PLUGS


(a) Remove any old packing (FIPG) material.

(b) Apply seal packing to the semi-circular plug grooves,


Seal packing:

Part No. 08826-00080 or equivalent





(c) Install the 4 semi-circular plugs to the cylinder heads.




6. INSTALL CAMSHAFT POSITION SENSOR

(a) Install a new gasket to the position sensor.

(b) Install the positron sensor with the bolt.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)




7. INSTALL CYLINDER HEAD COVERS

(a) Apply seal packing to the cylinder heads as shown in the illustration.


Seal packing:

Part No. 08826-00080 or equivalent



- (b) Install the gasket to the cylinder head cover.
 (c) Install the cylinder head cover with the 8 bolts. Uniformly tighten the bolts in several passes. Install the 2 cylinder head covers.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



8. INSTALL RH EXHAUST MANIFOLD

- (a) Install a new gasket and the exhaust manifold with the 6 nuts.


Torque: 49 N-m (500 kgf-cm, 36 ft-lbf)



- (b) Install the exhaust manifold stay and plate with the bolt and 2 nuts.


Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)

HINT: Install the manifold stay so that the tip of the stay touches the head of the differential retainer installation bolt as shown in the illustration.




- (c) Install 2 new gaskets and the EGR pipe with the 4 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)



- (d) Install the main heated oxygen sensor (Bank 1 Sensor 1).


Torque: 44 N-m (450 kgf-cm, 33 ft-lbf)



9. INSTALL PS BRACKET

Install the PS bracket with the 3 bolts.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)



10. INSTALL OIL DIPSTICK AND GUIDE

(a) Install a new O-ring to the dipstick guide.


(b) Apply soapy water to the O-ring.

(c) Push in the dipstick guide end into the guide hole of the No. 1 oil pan.

(d) Install the dipstick guide with the bolt.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)


(e) Install the dipstick.



11. INSTALL LH EXHAUST MANIFOLD


(a) Install a new gasket and the exhaust manifold with the 6 nuts.

Torque: 49 N-m (500 kgf-cm, 36 ft-lbf)




(b) Install the exhaust main manifold stay with the bolt and nut.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)




(c) Install the main heated oxygen sensor (Bank 2 Sensor 1).

Torque: 44 N-m (450 kgf-cm, 33 ft-lbf)

**12. INSTALL No.2 ENGINE HANGER**

Install the engine hanger with the 2 bolts.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)


**13. INSTALL WATER OUTLET**

(a) Connect the water outlet to the bypass hose.

(b) Install 2 new gaskets and the water outlet with the 2 bolts, 2 nuts and 2 plate washers.


Torque: 15 N-m (150 kgf-cm, 11 ft-lbf)

NOTICE: Do not scratch the seal surface of the water outlet with the stud bolt.

**14. INSTALL INJECTORS AND DELIVERY PIPES**


(a) Install 2 new grommets to each injector.

(b) Apply a light coat of gasoline to 2 new O-rings and install them to each injector.




(c) While turning the injector clockwise and counter-clockwise, push it to the delivery pipes. Install the 6 injectors.

(d) Position the injector connector outward.




(e) Place the 4 spacers in position on the intake manifold.



(f) Place the delivery pipes together with the 6 injectors in position on the intake manifold.


(g) Temporarily install the 4 bolts holding the delivery pipes to the intake manifold.



(h) Check that the injectors rotate smoothly.


HINT: If injectors do not rotate smoothly, the probable cause is incorrect installation of O-rings. Replace the O-rings.

(i) Position the injector connector outward.



(j) Tighten the 4 bolts holding the delivery pipes to the intake manifold.


Torque: 10 N·m (100 kgf·cm, 7 ft·lbf)



15. INSTALL No.2 FUEL PIPE

Install the No.2 fuel pipe with the 2 union bolts and 4 gaskets.

Torque: 32.5 N·m (330 kgf·cm, 24 ft·lbf)




16. INSTALL NO.1 FUEL PIPE AND PULSATION DAMPER

Install the No.1 fuel pipe with the pulsation damper, 4 new gaskets and bolt.

Torque: 32.5 N·m (330 kgf·cm, 24 ft·lbf) for Pulsation damper

Torque: 15 N·m (150 kgf·cm, 11 ft·lbf) for Bolt




17. INSTALL TVV

(a) Apply adhesive to 2 or 3 threads.


Adhesive:

**Part No. 08833-00070, THREE BOND 1324
or equivalent**



(b) Install the TVV.

Torque: 30 N-m (305 kgf-cm, 22 ft-lbf)




18. INSTALL FUEL PRESSURE REGULATOR


(a) Apply a light coat of gasoline to a new O-ring, and install it to the pressure regulator.

(b) Attach the pressure regulator to the delivery pipe.

(c) Check that the pressure regulator rotates smoothly.


NOTICE: If it does not rotate smoothly, the O-ring may be pinched, so remove the pressure regulator and repeat steps (b) and (e) above.





(d) Install the pressure regulator with the 2 bolts.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



19. INSTALL INTAKE MANIFOLD


Install the intake manifold with the 9 bolts, 2 nuts and 2 plate washers.

Torque: 15 N-m (150 kgf-cm, 11 ft-lbf)




20. RETIGHTEN WATER OUTLET MOUNTING BOLTS AND NUTS

Torque: 15 N-m (150 kgf-cm, 11 ft-lbf)




21. INSTALL AIR ASSIST HOSE



22. INSTALL WATER INLET PIPE


(a) Install a new O-ring to the water inlet pipe.

(b) Apply soapy water to the O-ring.



- (c) Connect the water inlet pipe to the water inlet.
- (d) Install the bolt holding the water inlet pipe to the cylinder head.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)




23. INSTALL CYLINDER HEAD REAR PLATE

- (a) Install the rear plate and grand strap with the bolt and nut.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)

- (b) Connect the vacuum hose to the air intake chamber.
- (c) Connect the 2 vacuum hoses to the vacuum tank.



24. INSTALL NO-3 TIMING BELT COVER

- (a) Check that the timing belt cover gaskets have no cracks or peeling, etc.


If the gaskets do have cracks or peeling etc., replace them using following steps.

- (1) Using a screwdriver and gasket scraper, remove all the old gasket material.
- (2) Thoroughly clean all components to remove all the loose material.
- (3) Remove the backing paper from a new gasket and install the gasket evenly to the part of the belt cover shaded black in the illustration.

NOTICE: When joining gaskets, do not leave a gap between them. Cut off any excess gasket.


- (4) After installing the gasket, press down on it so that the adhesive firmly sticks to the belt cover.

- (b) Install new gaskets to the No.3 belt cover.



- (c) Install the belt cover with the 6 bolts.


Torque: 8.5 N-m (85 kgf-cm, 74 in.-lbf)

**25. INSTALL NO.2 IDLER PULLEY**

(a) Install the idler pulley with the bolt.


Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)

(b) Check that the idler pulley moves smoothly.

**26. INSTALL RH CAMSHAFT TIMING PULLEY**

(a) Install the timing pulley, facing the flange side outward.

(b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.




(c) Using SST, install and torque the bolt.

SST 09249-63010, 09960-10010 (09962-01000)


Torque: 88 N·m (900 kgf·cm, 65 ft·lbf)

HINT: Use a torque wrench with a fulcrum length of 340 mm (13.39 in.)

**27. INSTALL LH CAMSHAFT TIMING PULLEY**

(a) Install the timing pulley, facing the flange side inward.


(b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.



(d) Using SST, install and torque the bolt.

SST 09960-10010 (09962-01000)

Torque: 125 N·m (1,300 kgf·cm, 94 ft·lbf)

28. INSTALL TIMING BELT(See steps 6 to 27 on pages [EG2-51](#) to 66)**29. INSTALL FRONT EXHAUST PIPE**

(a) Temporarily install 3 new gaskets and the front exhaust pipe with the 2 bolts and 6 nuts.

(b) Tighten the 4 nuts holding the exhaust manifolds to the front exhaust pipe.

Torque: 62 N-m (630 kgf-cm, 46 ft-lbf)



(c) Tighten the 2 bolts and 2 nuts holding the three-way catalytic converter to the front exhaust pipe.

Torque: 56 N-m (570 kgf-cm, 41 ft-lbf)


(d) Connect the bracket with the 2 bolts.

Torque: 19 N-m (195 kgf-cm, 14 ft-lbf)

(e) Connect the front exhaust pipe clamp with the 2 bolts.


Torque: 29 N-m (300 kgf-cm, 22 ft-lbf)**30. INSTALL SPARK PLUGS**

Using a 16 mm plug wrench, install the 6 spark plugs to the RH and LH cylinder heads.

**31. INSTALL IGNITION COILS**


Install the 6 ignition coils to the RH and LH cylinder heads.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)




32. CONNECT ENGINE WIRE TO ENGINE RH SIDE

- (a) Connect the following connectors:
- (1) 3 injector connectors
 - (2) 3 ignition coil connectors
 - (3) Water temperature sender gauge connector
 - (4) Water temperature sensor connector
 - (5) RH oxygens sensor connector
- (b) Connect the engine wire with the 5 nuts.




33. CONNECT ENGINE WIRE TO ENGINE REAR SIDE

- (a) Connect the following connectors:
- (1) LH oxygen sensor
 - (2) Engine coolant temperature sensor
 - (3) Camshaft position sensor
- (b) Connect the 3 clamps.
- (c) Connect the engine wire with the 2 nuts.




34. CONNECT ENGINE WIRE TO NO.3 TIMING BELT COVER

Connect the engine wire with the 2 clamps.



35. CONNECT ENGINE WIRE TO ENGINE LH SIDE


- (a) Connect the following connectors:
 - (1) 3 injector connectors
 - (2) 3 ignition coil connectors
- (b) Connect the engine wire with the 2 nuts.



36. INSTALL EGR VALVE AND VACUUM MODULATOR TO AIR INTAKE CHAMBER


Install a new gasket, the EGR valve and vacuum modulator with the 3 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)



37. INSTALL THROTTLE BODY TO AIR INTAKE CHAMBER


- (a) Place a new gasket on the air intake chamber.



- (b) Install the throttle body with the 2 bolts and 2 nuts.


Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)

- (c) Connect the following vacuum hoses:
 - (1) Vacuum hose to P port of EGR vacuum modulator
 - (2) Vacuum hose to R port of EGR vacuum modulator



38. INSTALL A/C IDLE-UP VSV TO AIR INTAKE CHAMBER

- (a) Install the A/C idle-up VSV with the 2 bolts.
- (b) Connect the air hose.




39. INSTALL INTAKE AIR CONTROL VALVE TO AIR INTAKE CHAMBER

- (a) Install a new gasket to the air intake chamber.
- (b) Apply a light coat of engine oil to the rubber portions.
- (c) Apply seal packing to the positions of the intake air control valve as shown in the illustration.

Seal packing:


Part No. 08826-00080 or equivalent



- (d) Install the intake air control valve and data link connector 1 clamp with the 3 nuts.

Torque: 14.5 N-m (145 kgf-cm, 10 ft-lbf)


- (d) Connect the A/C air hose.



40. INSTALL AIR INTAKE CHAMBER


- (a) Using an 8 mm hexagon wrench, install a new gasket and the air intake chamber with the 2 bolts and 2 nuts.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)




- (b) Connect the following hoses:

- (1) 2 water bypass hoses
- (2) Air assist hose




- (c) Connect the following vacuum hoses:

- (1) 2 vacuum hoses to TVV
- (2) Vacuum hose to cylinder head rear plate



(3) Vacuum hose to charcoal canister




(d) Connect the following connectors:

- (1) Throttle position sensor connector
- (2) IAC valve connector
- (3) EGR gas temperature sensor connector
- (4) A/C idle-up connector



(e) Install 2 new gaskets and EGR pipe with the 4 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)




(f) Install the No.1 engine hanger with the 2 bolts.

Torque: 39 N-m (400 kgf-cm, 19 ft-lbf)


(g) Install the air intake chamber stay with the 2 bolts.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)




(h) Connect the 2 PS air hoses.


(i) Connect the PS pressure tube with the 2 nuts.



- (j) Connect the RH oxygen sensor connector clamp to the PS pressure tube.
- (k) Connect the ground strap with the bolt.
- (l) Connect the hydraulic pressure pipe to the air intake chamber with the bolt.




- (m) Connect the following hoses:
 - (1) Brake booster vacuum hose
 - (2) PCV hose
 - (3) Intake air control valve vacuum hose
 - (n) Connect the data link connector 1.
 - (o) Connect the 2 ground straps with the nut.
- Torque: 14.5 N·m (145 kgf·cm, 10 ft·lbf)**




41. INSTALL EMISSION CONTROL VALVE SET

- (a) Install the emission control valve set with the 2 bolts.
- Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)**




- (b) Connect the following connectors:
 - (1) Intake air control connector
 - (2) Fuel pressure connector
 - (3) EGR VSV connector



(c) Connect the following vacuum hoses:

- (1) Vacuum hose to fuel pressure control VSV
- (2) Vacuum hose to fuel pressure regulator
- (3) Vacuum hose to cylinder head rear plate
- (4) Vacuum hose to intake air control valve VSV
- (5) Vacuum hose to EGR vacuum modulator
- (6) Vacuum hose to EGR valve




42. INSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V-bank cover with the 2 nuts.



43. CONNECT PRESSURE HOSE TO HYDRAULIC MOTOR


Connect the pressure hose to the water inlet.



44. CONNECT FUEL HOSES


- (a) Connect the fuel return hose to the fuel pipe.
- (b) Connect the fuel inlet hose to the fuel filter.

Torque: 30 N-m (300 kgf-cm, 22 ft-lbf)




45. CONNECT HEATER HOSES

Connect the 2 hoses.



46. CONNECT RADIATOR HOSES

Connect the 2 hoses.



47. INSTALL RH ENGINE MOUNTING STAY


Install the mounting stay with the 3 bolts.

Torque: 31.4 N-m (320 kgf-cm, 23 ft-lbf)



48. CONNECT GROUND STRAPS

Connect the 2 straps.




49. w/ CRUISE CONTROL SYSTEM:

INSTALL CRUISE CONTROL ACTUATOR

(a) Connect the actuator and bracket with the 3 bolts.

(b) Connect the actuator connector and clamp.

(c) Install the actuator cover with the bolt and clip.



50. INSTALL AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE


(a) Connect the air cleaner hose, and install the air cleaner cap and volume air flow meter with the 4 clips.

(b) Tighten the air cleaner hose clamp bolt.

(c) Connect the PCV hose.

(d) Connect the accelerator cable clamp.

(e) Connect the volume air flow meter connector and wire clamp.




51. CONNECT THROTTLE CABLE

52. CONNECT ACCELERATOR CABLE

53. FILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts, 7.7 Imp. qts)



54. INSTALL BATTERY TRAY AND BATTERY

55. START ENGINE AND CHECK FOR LEAKS


56. PERFORM ROAD TEST


Check for abnormal noise, shock, slippage, correct shift points and smooth operation.

57. RECHECK ENGINE COOLANT LEVEL

CYLINDER BLOCK COMPONENTS FOR ENGINE REMOVAL AND INSTALLATION


8827P-91






N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part



P13391

210580



ENGINE REMOVAL

(See Components for Engine Removal and Installation)

1. REMOVE BATTERY AND TRAY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.



2. REMOVE HOOD

3. DRAIN ENGINE COOLANT

4. DRAIN ENGINE OIL


5. DISCONNECT ACCELERATOR CABLE

6. DISCONNECT THROTTLE CABLE



7. REMOVE AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE


- (a) Disconnect the volume air flow meter connector and wire clamp.
- (b) Disconnect the accelerator cable clamp.
- (c) Disconnect the PCV hose.
- (d) Loosen the air cleaner hose clamp bolt.
- (e) Disconnect the 4 air cleaner cap clips.
- (f) Remove the air cleaner cap and volume air flow meter together with the air cleaner hose.
- (g) Remove the element.
- (h) Remove the 3 bolts and air cleaner case.



8. w/ CRUISE CONTROL SYSTEM:


REMOVE CRUISE CONTROL ACTUATOR

- (a) Remove the bolt, clip and actuator cover.
- (b) Disconnect the actuator connector and clamp.
- (c) Remove the 3 bolts, and disconnect the actuator with the bracket.



9. REMOVE RADIATOR

(See page [EG2-336](#))




10. DISCONNECT ENGINE WIRE

(a) Remove the 2 bolts and disconnect the engine relay box.

(b) Disconnect the following wires and connectors:

(1) 5 connectors from relay box




(2) 2 igniter connectors

(3) Noise filter connector

(4) Connector from LH fender apron

(5) 2 ground straps


(c) Disconnect the wire clamp.



(d) Disconnect the connector from the LH fender apron.

(e) Remove the bolt and disconnect the ground strap.


(f) Disconnect the wire clamp.



11. DISCONNECT VACUUM HOSES

Disconnect the following vacuum hoses:


(1) Vacuum hoses from vacuum tank for intake air control valve



(2) Vacuum hose from charcoal canister




(3) Brake booster vacuum hose from air intake chamber



12. DISCONNECT HEATER HOSES


Disconnect the 2 hoses.



13. DISCONNECT FUEL HOSES

Disconnect the fuel inlet and return hoses.

CAUTION: Catch leaking fuel in a container.



14. DISCONNECT TRANSAXLE CONTROL CABLE FROM TRANSAXLE



15. DISCONNECT ENGINE WIRE FROM CABIN

(a) Remove the following parts:

- (1) Under cover
- (2) Lower instrument panel
- (3) Glove compartment door
- (4) Glove compartment

(b) Disconnect the following connectors:

- (1) 3 ECM connectors
- (2) 5 cowl wire connectors
- (3) Cooling fan ECU connector



(c) Disconnect the wire clamp.

(d) Remove the 2 nuts, and pull out the engine wire from the cowl panel.


**16. REMOVE A/C COMPRESSOR WITHOUT DISCONNECTING HOSES**

(a) Disconnect the A/C compressor connector.

(b) Remove the drive belt.


(c) Remove the 5 bolts and drive belt adjusting bar bracket and, disconnect the A/C compressor.

HINT: Move the compressor aside and suspend it.



17. REMOVE FRONT EXHAUST PIPE

(a) Remove the 2 bolts and exhaust pipe clamp.



(b) Remove the 2 bolts, and disconnect the bracket.


(c) Remove the 2 bolts and 2 nuts holding the front exhaust pipe to the three-way catalytic converter.

(d) Remove the 4 nuts holding the front exhaust pipe to the exhaust manifolds.

(e) Remove the front exhaust pipe and 3 gaskets.

18. REMOVE DRIVE SHAFTS


(See SA section)



19. DISCONNECT PS PRESSURE TUBE

(a) Disconnect the 2 PS air hoses.


(b) Remove the 2 nuts and disconnect the PS pressure tube.



20. DISCONNECT HYDRAULIC COOLING FAN PRESSURE HOSE

Using SST, disconnect the pressure hose.

SST 09631- 22020



21. REMOVE PS PUMP WITHOUT DISCONNECTING HOSES


(a) Remove the PS drive belt.

(b) Remove the 2 bolts, and disconnect the PS pump from the engine.


HINT: Move the PS pump aside and suspend it.

**22. DISCONNECT LH ENGINE MOUNTING INSULATOR**


Remove the 4 bolts, and disconnect the mounting insulator.

**23. DISCONNECT RR ENGINE MOUNTING INSULATOR**


- (a) Remove the 2 hole plugs.
- (b) Remove the 4 nuts, and disconnect the mounting insulator.


**24. REMOVE ENGINE MOUNTING SHOCK ABSORBER**

Remove the 4 bolts and engine mounting shock absorber.


**25. DISCONNECT FR ENGINE MOUNTING INSULATOR**

Remove the 3 bolts, and disconnect the mounting insulator.


**26. ATTACH ENGINE SLING DEVICE TO ENGINE HANGERS**

**27. REMOVE COOLANT RESERVOIR TANK**


(a) Disconnect the reservoir hose.




(b) Using a screwdriver, remove the reservoir tank.

**28. DISCONNECT GROUND STRAPS**


Disconnect the 2 straps.

**29. REMOVE RH ENGINE MOUNTING STAY**

Remove the 3 bolts and RH engine mounting stay.


**30. REMOVE ENGINE MOVING CONTROL ROD AND NO.2 RH ENGINE MOUNTING BRACKET**

Remove the 3 bolts, control rod and mounting bracket.




31. REMOVE ENGINE AND TRANSAXLE ASSEMBLY FROM VEHICLE

- (a) Lift the engine out of the vehicle slowly and carefully.
NOTICE: Be careful not to hit the PS gear housing or park/neutral position switch.
- (b) Make sure the engine is clear of all wiring, hoses and cables.
- (c) Place the engine and transaxle assembly onto the stand.



32. REMOVE FR ENGINE MOUNTING INSULATOR

Remove the 4 bolts and mounting insulator.




33. REMOVE RR ENGINE MOUNTING INSULATOR

Remove the 4 bolts and mounting insulator.

34. REMOVE FRONT EXHAUST PIPE STAY

Remove the 2 bolts and pipe stay.

COMPONENTS FOR ENGINE & TRANSAXLE SEPARATION AND ASSEMBLY



804882-01

ENGINE & TRANSAXLE SEPARATION


(See Components for Engine & Transaxle Separation and Assembly)

1. DISCONNECT ENGINE WIRE

(a) Disconnect the following connector:


- (1) O/D solenoid connector
- (2) PNP switch speedometer
- (3) Starter 50 terminal
- (4) Starter B terminal
- (5) Speed sensor connector

(b) Disconnect the 2 wire clamps from the transaxle.




2. REMOVE OIL DIPSTICK GUIDE AND DIPSTICK FOR TRANSAXLE

- (a) Remove the mounting bolt.
- (b) Pull out the dipstick guide and dipstick from the port of transaxle.
- (c) Remove the O-ring from the dipstick guide.



3. REMOVE STARTER


Remove the 2 bolts and starter.




4. REMOVE TRANSAXLE

A. Remove torque converter clutch mounting bolts

- (a) Remove the 2 bolts and flywheel housing undercover.




- (b) Turn the crankshaft pulley bolt to gain access to each bolt.
- (c) Hold the crankshaft pulley bolt with a wrench, and remove the 6 bolts.




6. Remove transaxle


- (a) Remove the bolt, 2 nuts, manifold stay and exhaust manifold plate.



(b) Remove the bolt, nut and No.2 manifold stay.




(c) Remove the 2 bolts holding the No.2 oil pan to the transaxle.



(d) Remove the 6 bolts holding the engine to the transaxle.


(e) Remove the transaxle together with the torque converter clutch from the engine.



5. REMOVE DRIVE PLATE

Uniformly loosen and remove the drive plate bolts, in several passes, in the sequence shown.

COMPONENTS FOR PREPARATION AND AFTER ASSEMBLY



PREPARATION FOR DISASSEMBLY

(See Components for Cylinder Block Preparation of Disassembly and After Assembly)

1. INSTALL ENGINE TO ENGINE STAND FOR DISASSEMBLY

2. REMOVE TIMING BELT AND PULLEYS


(See pages EG2-42 to 47)

3. REMOVE CYLINDER HEAD

(See pages EG2-64 to 79)

4. REMOVE GENERATOR

Remove the 2 bolts and generator.




5. REMOVE GENERATOR ADJUSTING BAR AND BRACKET

Remove the 3 nuts, generator adjusting bar and bracket.




6. REMOVE A/C COMPRESSOR HOUSING BRACKET


Remove the 3 bolts and compressor housing bracket.



7. REMOVE No.2 IDLER PULLEY BRACKET


Remove the 2 bolts and idler pulley bracket.






8. REMOVE KNOCK SENSORS

- (a) Disconnect the 2 knock sensor connectors.
- (b) Remove the wire band.
- (c) Disconnect the engine wire clamp.




- (d) Using SST, remove the 2 knock sensors.
SST 09816 – 30010




9. REMOVE WATER INLET HOUSING

Remove the 8 bolts, 2 nuts and water inlet housing.




10. REMOVE WATER PUMP

Remove the 4 bolts, 2 nuts, water pump and gasket.



11. REMOVE NO.2 OIL PAN

- (a) Remove the 10 bolts and 2 nuts.




(b) Insert the blade of SST between the No. 1 and No.2 oil pans, and cut off applied sealer and remove the No. 1 oil pan.

SST 09032 – 00100


NOTICE:

- Be careful not to damage the No.2 oil pan contact surface of the No.1 oil pan.
- Be careful not to damage the No.2 oil pan flange.




12. REMOVE OIL STRAINER

Remove the bolt, 2 nuts, oil strainer and gasket.




13. REMOVE NO.1 OIL PAN

(a) Remove the 17 bolts.




(b) Using a screwdriver, remove the No. 1 oil pan by prying the portions between the cylinder block and No.1 oil pan.

NOTICE: Be careful not to damage the contact surfaces of the cylinder block and No.1 oil pan.




14. REMOVE OIL PUMP

(a) Remove the 9 bolts.



(b) Remove the oil pump by prying a screwdriver between the oil pump and main bearing cap.


(c) Remove the O-ring.



15. REMOVE OIL FILTER


Using SST, remove the oil filter.

SST 09816 – 30010





16. REMOVE OIL FILTER UNION

Using a 12 mm hexagon wrench, remove the oil filter union.




17. REMOVE WATER SEAL PLATE

Remove the 2 nuts and seal plate.


**18. REMOVE ENGINE COOLANT DRAIN COCK****19. REMOVE OIL PRESSURE SWITCH**

Using SST, remove the oil pressure switch.
SST 09816 – 30010

**20. REMOVE EGR COOLER**


Remove the 3 bolts, 2 nuts, EGR cooler and gasket.

COMPONENTS FOR CYLINDER BLOCK DISASSEMBLY AND ASSEMBLY



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part




CYLINDER BLOCK DISASSEMBLY

(See Components for Disassembly and Assembly)

1. REMOVE REAR OIL SEAL RETAINER

- (a) Remove the 6 bolts.
- (b) Using a screwdriver, remove the oil seal retainer by prying the portions between the oil seal retainer and main bearing cap.



2. CHECK CONNECTING ROD THRUST CLEARANCE

Using a dial indicator, measure the thrust clearance while moving the connecting rod back and forth.

Standard thrust clearance:

0.15 – 0.30 mm (0.0059 – 0.0118 in.)

Maximum thrust clearance:


0.35 mm (0.0138 in.)

If the thrust clearance is greater than maximum, replace the connecting rod assembly

- (s). If necessary, replace the crankshaft.


Connecting rod thickness:

20.80 – 20.85 mm (0.8189 – 0.8209 in.)




3. REMOVE CONNECTING ROD CAPS AND CHECK OIL CLEARANCE

- (a) Check the matchmarks on the connecting rod and cap to ensure correct reassembly.




- (b) Remove the 2 connecting rod cap bolts.



(c) Using the 2 removed connecting rod cap bolts, remove the connecting rod cap and lower bearing by wiggling the connecting rod cap right and left.


HINT: Keep the lower bearing inserted with the connecting rod cap.




(d) Clean the crank pin and bearing.

(e) Check the crank pin and bearing for pitting and scratches.

If the crank pin or bearing is damaged, replace the bearings. If necessary, replace the crankshaft.



(f) Lay a strip of Plastigage across the crank pin.




(g) Install the connecting rod cap with the 2 bolts. (See step 7 on page [EG2-167](#))

Torque:


1st 24.5 N·m (250 kgf·cm. 18 ft·lbf)

2nd Turn extra 90°

NOTICE: Do not turn the crankshaft.



(h) Remove the 2 bolts, connecting rod cap and lower bearing. (See procedure (b) and (c) above)



Measure the Plastigage at its widest point.


Standard oil clearance:

0.038 – 0.064 mm (0.0015 – 0.0025 in.)

Maximum oil clearance:

0.08 mm (0.0031 in.)

If the oil clearance is greater than maximum, replace the bearings. If necessary, grind or replace the crankshaft.



HINT: If replacing a bearing, replace it with 1 having the same number as marked on the connecting rod. There are 4 sizes of standard bearings, marked "1", "2", "3" and "4" accordingly.

Reference:

Connecting rod big end inside diameter:

Mark '1'

518.000 – 56.006 mm (2.2047 – 2.2050 in.)

Mark '2'

56.006 – 56.012 mm (2.2050 – 2.2052 in.)

Mark '3'

56.012 – 56.018 mm (2.2052 – 2.2054 in.)

Mark '4'

56.018 – 56.024 mm (2.2054 – 2.2057 in.)

Crankshaft crank pin diameter:

52.994 – 53.000 mm (2.0864 – 2.0868 in.)

Standard sized bearing center wall thickness:

Mark '1'

1.484 – 1.487 mm (0.0584 – 0.0585 in.)

Mark '2'

1.487 – 1.490 mm (0.0585 – 0.0587 in.)


Mark '3'

1.490 – 1.493 mm (0.0587 – 0.0588 in.)

Mark W

1.493 – 1.496 mm (0.0588 – 0.0589 in.)


(j) Completely remove the Plastigage.




4. REMOVE PISTON AND CONNECTING ROD ASSEMBLIES

(a) Using a ridge reamer, remove all the carbon from the top of the cylinder.

(b) Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.

**HINT:**

- Keep the bearings, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in correct order.

**5. CHECK CRANKSHAFT THRUST CLEARANCE**

Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard thrust clearance:

0.04 – 0.24 mm (0.0016 – 0.0095 in.)


Maximum thrust clearance:

0.30 mm (0.0118 in.)


If the thrust clearance is greater than maximum, replace the thrust washers as a set.

Thrust washer thickness:


1.930 – 1.980 mm (0.0760 – 0.0780 in.)

**6. REMOVE MAIN BEARING CAPS AND CHECK OIL CLEARANCE**

(a) Uniformly loosen and remove the 8 main bearing cap bolts and seal washers, in several passes, in the sequence shown.




(b) Uniformly loosen and remove the 16 main bearing cap bolts, in several passes, in the sequence shown.



(c) Using a screwdriver, pry out main bearing caps, remove the 4 main bearing caps, lower bearings and (No.2 main bearing cap only) 2 lower thrust washers.


HINT:

- Keep the lower bearing and main bearing cap together.
- Arrange the main bearing caps and lower thrust washers in correct order.



(d) Lift out the crankshaft.


HINT: Keep the upper bearings together with the cylinder block.



(e) Clean each main journal and bearing.


(f) Check each main journal and bearing for pitting and scratches.

If the journal or bearing is damaged, replace the bearings. If necessary, replace the crankshaft.



(g) Place the crankshaft on the cylinder block.

(h) Lay a strip of Plastigage across each journal.



- (i) Install the 4 main bearing caps.
(See step 4 on pages [EG2-165](#))

12 Pointed Head Bolts:

Torque:


1 st 22 N·m (225 kgf·cm, 16 ft·lbf)

2nd Turn extra 90°


Hexagon Head Bolts:

Torque: 27 N·m (275 kgf·cm, 20 ft·lbf)

NOTICE: Do not turn the crankshaft.



- (j) Remove the main bearing caps.
(See procedures (a) to (c) above)



- (k) Measure the Plastigage at its widest point.

Standard oil clearance:

0.026 – 0.046 mm (0.0010 – 0.0018 in.)

Maximum clearance:

0.06 mm (0.0024 in.)

If the oil clearance is greater than maximum, replace the bearings. If necessary, replace the crankshaft.

HINT: If using a bearing, replace it with one having the same number. If the number of the bearing cannot be determined, select the correct bearing by adding together the numbers imprinted on the cylinder block and crankshaft, then refer to the table below for the appropriate bearing number. There are 5 standard bearing sizes, marked '1', '2', '3', '4' and '5' accordingly.


	Total number " ": Number mark				
Cylinder block (A) + Crankshaft (B) _	0-5	6-11	12-17	18-23	24-28
Use bearing	"1"	"2"	"3"	"4"	"5"

EXAMPLE: Cylinder block "06" (A)

+ Crankshaft "08" (B)

= Total number 14 (Use bearing "3")

V01565



Reference:**Cylinder block main journal bore diameter****(A):****Mark "00'****66.000 mm (2.5984 in.)****Mark '01'****66.001 mm (2.5985 in.)****Mark "02"****66.002 mm (2.5985 in.)****Mark '03'****66.003 mm (2.5985 in.)****Mark "04'****66.004 mm (2.5986 in.)****Mark '05'****66.005 mm (2.5986 in.)****Mark '06'****66.006 mm (2.5987 in.)****Mark '07'****66.007 mm (2.5987 in.)****Mark '08'****66.008 mm (2.5987 in.)****Mark '09'****66.009 mm (2.5988 in.)****Mark "10'****66.010 mm (2.5988 in.)****Mark '11 "****66.011 mm (2.5989 in.)****Mark '12'****66.012 mm (2.5989 in.)****Mark '13'****66.013 mm (2.5989 in.)****Mark "14'****66.014 mm (2.5990 in.)****Mark '15'****66.015 mm (2.5990 in.)****Mark "16'****66.016 mm (2.5990 in.)**

Crankshaft main journal diameter (B):**Mark '00"**

61.000 mm (2.401 6 in.)

Mark '01'

60.999 mm (2.4015 in.)

Mark '02'

60.998 mm (2.4015 in.)

Mark '03"

60.997 mm (2.4015 in.)

Mark '04'

60.996 mm (2.4014 in.)

Mark '05'

60.995 mm (2.4014 in.)

Mark '06"

60.994 mm (2.4013 in.)

Mark '07'

60.993 mm (2.4012 in.)

Mark '08'

60.992 mm (2.4012 in.)

Mark '09"

60.991 mm (2.4012 in.)

Mark '10'

60.990 mm (2.4012 in.)

Mark '11'

60.989 mm (2.4011 in.)

Mark '12"

60.988 mm (2.4011 in.)

Standard sized bearing center wall thickness:**Mark '1'**

2.488 – 2.489 mm (0.0979 – 0.0980 in.)

Mark '2

2.489 – 2.492 mm (0.0980 – 0.0981 in.)

Mark '3"

2.492 – 2.495 mm (0.0981 – 0.0982 in.)

Mark '4'

2.495 – 2.498 mm (0.0982 – 0.0983 in.)

Mark '5'

2.498 – 2.501 mm (0.0983 – 0.0985 in.)


Standard sized Bearing Selection Chart

Crankshaft number mark	Cylinder block number mark																
	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16
00	1	1	1	1	1	1	2	2	2	2	2	2	3	3	3	3	3
01	1	1	1	1	1	2	2	2	2	2	2	3	3	3	3	3	3
02	1	1	1	1	2	2	2	2	2	2	3	3	3	3	3	3	4
03	1	1	1	2	2	2	2	2	2	3	3	3	3	3	3	4	4
04	1	1	2	2	2	2	2	2	3	3	3	3	3	3	4	4	4
05	1	2	2	2	2	2	2	3	3	3	3	3	3	4	4	4	4
06	2	2	2	2	2	2	3	3	3	3	3	3	4	4	4	4	4
07	2	2	2	2	2	3	3	3	3	3	3	4	4	4	4	4	4
08	2	2	2	2	3	3	3	3	3	3	4	4	4	4	4	4	5
09	2	2	2	3	3	3	3	3	3	4	4	4	4	4	4	5	5
10	2	2	3	3	3	3	3	3	4	4	4	4	4	4	5	5	5
11	2	3	3	3	3	3	3	4	4	4	4	4	4	5	5	5	5
12	3	3	3	3	3	3	4	4	4	4	4	4	5	5	5	5	5

EXAMPLE: Cylinder block "06", Crankshaft "08"
= Use bearing "3"


W03574

(l) Completely remove the Plastigage.




7. REMOVE CRANKSHAFT

- Lift out the crankshaft.
- Remove the 4 upper main bearings and 2 upper thrust washers from the cylinder block.



HINT: Arrange the main bearing caps, bearings and thrust washers in correct order.



CYLINDER BLOCK INSPECTION AND REPAIR

1. CLEAN CYLINDER BLOCK


A. Remove gasket material

Using a gasket scraper, remove all the gasket material from the top surface of the cylinder block.

B. Clean cylinder block

Using a soft brush and solvent, thoroughly clean the cylinder block.

NOTICE: If the cylinder is washed at high temperatures, the cylinder liner sticks out beyond the cylinder block, so always wash the cylinder block at a temperature of 45°C (113°F) or less.




2. INSPECT TOP SURFACE OF CYLINDER BLOCK FOR FLATNESS

Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head gasket for warpage.

Maximum warpage:

0.07 mm (0.0028 in.)


If warpage is greater than maximum, replace the cylinder block.



3. INSPECT CYLINDER FOR VERTICAL SCRATCHES

Visually check the cylinder for vertical scratches.

If deep scratches are present, replace the cylinder block.



4. INSPECT CYLINDER BORE DIAMETER

Using a cylinder gauge, measure the cylinder bore diameter at positions A, B and C in the thrust and axial directions.


Standard diameter:

87.500 – 87.512 mm (3.4449 – 3.4453 in.)

Maximum diameter:


87.52 mm (3.4457 in.)

If the diameter is greater than maximum, replace the cylinder block.



5. REMOVE CYLINDER RIDGE

If the wear is less than 0.2 mm (0.008 in.), using a ridge reamer, grind the top of the cylinder.



6. INSPECT MAIN BEARING CAP BOLTS

(for 12 Pointed Head Bolts)

Using a vernier caliper, measure the tension portion diameter of the main bearing cap bolt.


Standard diameter:

7.500 – 7.600 mm (0.2953 – 0.2992 in.)

Minimum diameter:

7.20 mm (0.2835 in.)

If the diameter is less than minimum, replace the bolt.




PISTON AND CONNECTING ROD DISASSEMBLY

1. CHECK FIT BETWEEN PISTON AND PISTON PIN

Try to move the piston back and forth on the piston pin.

If any movement is felt, replace the piston and pin as a set.




2. REMOVE PISTON RINGS

(a) Using a piston ring expander, remove the 2 compression rings.




(b) Remove the 2 side rails and oil ring by hand.
HINT: Arrange the piston rings in correct order only.




3. DISCONNECT CONNECTING ROD FROM PISTON


(a) Using a small screwdriver, pry out the 2 snap rings.



(b) Gradually heat the piston to approx. 60°C (140°F).




(c) Using a plastic-faced hammer and brass bar, lightly tap out the piston pin and remove the connecting rod.



HINT:

- The piston and pin are a matched set.
- Arrange the pistons, pins, rings, connecting rods and bearings in correct order.




PISTON AND CONNECTING ROD INSPECTION


B0007-01

1. CLEAN PISTON

(a) Using a gasket scraper, remove the carbon from the piston top.




(b) Using a groove cleaning tool or broken ring, clean the piston ring grooves.



(c) Using solvent and a brush, thoroughly clean the piston.

NOTICE: Do not use a wire brush.



2. INSPECT PISTON

A. Inspect piston oil clearance

(a) Using a micrometer, measure the piston diameter at ring angles to the piston pin center line, 23.2 mm (0.913 in.) from the piston head.

Piston diameter:

87.406 – 87.416 mm (3.4412 – 3.4416 in.)

(b) Measure the cylinder bore diameter in the thrust directions. (See step 4 on page [EG2-152](#))

(c) Subtract the piston diameter measurement from the cylinder bore diameter measurement.

Standard oil clearance:


0.084 – 0.106 mm (0.0033 – 0.0042 in.)

Maximum oil clearance:

0.13 mm (0.0051 in.)

If the oil clearance is greater than maximum, replace all the 6 pistons. If necessary, replace the cylinder block.

HINT: The shape of the piston varies for the RH and LH banks. The RH piston is marked with "R", the LH piston with "L".



B. Inspect piston ring groove clearance

Using a feeler gauge, measure the clearance between new piston ring and the wall of the ring groove.

Ring groove clearance:


No.1

0.020 – 0.070 mm (0.0008 – 0.0028 in.)

No.2


0.020 – 0.060 mm (0.0008 – 0.0024 in.)

If the clearance is not as specified, replace the piston.



C. Inspect piston ring end gap

- (a) Insert the piston ring into the cylinder bore.
 (b) Using a piston, push the piston ring a little beyond the bottom of the ring travel, 105 mm (4.13 in.) from the top of the cylinder block.



- (c) Using a feeler gauge, measure the end gap.

Standard end gap:

No. 1

0.25 – 0.35 mm (0.0098 – 0.0138 in.)

No.2

0.35 – 0.45 mm (0.0138 – 0.0177 in.)

Oil (Side rail)

0.15 – 0.40 mm (0.0059 – 0.0157 in.)

Maximum end gap:

No.1

0.95 mm (0.0374 in.)


No.2

1.05 mm (0.0413 in.)

Oil (Side rail)


1.00 mm (0.0394 in.)

If the end gap is greater than maximum, replace the piston ring. If the end gap is greater than maximum, even with a new piston ring, replace the cylinder block.



D. Inspect piston pin fit

At 60°C (140°F), you should be able to push the piston pin into the piston pin hole with your thumb.



3. INSPECT CONNECTING ROD

A. Inspect connecting rod alignment


Using a rod aligner and feeler gauge, check the connecting rod alignment.

- Check for out-of-alignment.

Maximum out-of-alignment:

0.05 mm (0.0020 in.) per 100 mm (3.94 in.)

If out-of-alignment is greater than maximum, replace the connecting rod assembly.




- Check for twist

Maximum twist:

0.15 mm (0.0059 in.) per 100 mm (3.94 in.)

If twist is greater than maximum, replace the connecting rod assembly.




B. Inspect piston pin oil clearance

(a) Using a caliper gauge, measure the inside diameter of the connecting rod bushing.

Bushing inside diameter:

22.005 – 22.014 mm (0.8663 – 0.8667 in.)



(b) Using a micrometer, measure the piston pin diameter.

Piston pin diameter:

21.997 – 22.006 mm (0.8660 – 0.8664 in.)

(c) Subtract the piston pin diameter measurement from the bushing inside diameter measurement.


Standard oil clearance:

0.005 – 0.011 mm (0.0002 – 0.0004 in.)

Maximum oil clearance:

0.05 mm (0.0020 in.)


If the oil clearance is greater than maximum, replace the bushing. If necessary, replace the piston and piston pin as a set.



C. If necessary, replace connecting rod bushing


(a) Using SST and a press, press out the bushing.

SST 09222 – 30010




(b) Align the oil holes of a new bushing and the connecting rod.


(c) Using SST and a press, press in the bushing.
SST 09222-30010



(d) Using a pin hole grinder, hone the bushing to obtain the standard specified clearance (see step B above) between the bushing and piston pin.



(e) Check the piston pin fit at normal room temperature. Coat the piston pin with engine oil, and push it into the connecting rod with your thumb.



D. Inspect connecting rod bolts

Using a vernier caliper, measure the tension portion of the connecting rod bolt.

Standard diameter:


7.2 – 7.3 mm (0.284 – 0.287 in.)

Minimum diameter:

7.0 mm (0.276 in.)

HINT: If the tension portion diameter is less than minimum, replace the connecting rod bolt.

BODY-06



CRANKSHAFT INSPECTION

1. INSPECT CRANKSHAFT FOR CIRCLE RUNOUT

- (a) Place the crankshaft on V-blocks.
- (b) Using a dial indicator, measure the circle runout, as shown in the illustration.

Maximum circle runout:

0.06 mm (0.0024 in.)

If the circle runout is greater than maximum, replace the crankshaft.

2. INSPECT MAIN JOURNALS AND CRANK PINS

- (a) Using a micrometer, measure the diameter of each main journal and crank pin.

Main journal diameter:

60.988 – 61.000 mm (2.4011 – 2.4016 in.)

Crank pin diameter:

52.994 – 53.000 mm (2.0864 – 2.0866 in.)


If the diameter is not as specified, check the oil clearance (See steps 3 or 6 on page [EG2-142](#) or 145). If necessary, replace the crankshaft.

- (b) Check each main journal and crank pin for taper and out-of-round as shown.

Maximum taper and out-of-round:


0.02 mm (0.0008 in.)

If the taper and out-of-round is greater than maximum, replace the crankshaft.



CRANKSHAFT OIL SEALS REPLACEMENT


HINT: There are 2 methods (A and B) to replace the oil seal which are as follows:



1. REPLACE CRANKSHAFT FRONT OIL SEAL

A. If oil pump is removed from cylinder block:


(a) Using a screwdriver, pry out the oil seal.



(b) Using SST and a hammer, tap in a new oil seal until its surface is flush with the oil pump body edge.

SST 09223 – 00010

(c) Apply MP grease to the oil seal lip.



B. If oil pump is installed to the cylinder block:

(a) Using a knife, cut off the oil seal lip.

(b) Using a screwdriver, pry out the oil seal.


NOTICE: Be careful not to damage the crankshaft. Tape the screwdriver tip.



(c) Apply MP grease to a new oil seal lip.

(d) Using SST and a hammer, tap in the oil seal until its surface is flush with the oil pump body edge.


SST 09223 – 00010



2. REPLACE CRANKSHAFT REAR OIL SEAL

A. If rear oil seal retainer is removed from cylinder block:


(a) Using a screwdriver and hammer, tap out the oil seal.



(b) Using SST and a hammer, tap in a new oil seal until its surface is flush with the rear oil seal retainer edge.

SST 09223-15030, 09608-30022 (09608-05010)

(c) Apply MP grease to the oil seal lip.




B. If rear oil seal retainer is installed to cylinder block:

(a) Using a knife, cut off the oil seal lip.

(b) Using a screwdriver, pry out the oil seal.


NOTICE: Be careful not to damage the crankshaft. Tape the screwdriver tip.



(c) Apply MP grease to a new oil seal lip.

(d) Using SST and a hammer, tap in the oil seal until its surface is flush with the rear oil seal retainer edge.

SST 09223-15030, 09608-30022 (09608-05010)




PISTON AND CONNECTING ROD ASSEMBLY


1. ASSEMBLE PISTON AND CONNECTING ROD

(a) Using a small screwdriver, install a new snap ring at one end of the piston pin hole.

HINT: Be sure that end gap of the snap ring is not aligned with the pin hole cutout portion of the piston.




(b) Gradually heat the piston to about 60°C (140°F).




(c) Coat the piston pin with engine oil.

(d) Align the front marks of the piston and connecting rod, and push in the piston pin with your thumb.




(e) Using a small screwdriver, install a new snap ring on the other end of the piston pin hole.

HINT: Be sure that end gap of the snap ring is not aligned with the pin hole cutout portion of the piston.



2. INSTALL PISTON RINGS

(a) Install the oil ring expander and 2 side rails by hand.



(b) Using a piston ring expander, install the 2 compression rings with the code mark facing upward.


Code mark:

No.1

1RorT


No.2

2R or 2T



(c) Position the piston rings so that the ring ends are as shown.

NOTICE: Do not align the ring ends.



3. INSTALL BEARINGS

(a) Align the bearing claw with the groove of the connecting rod or connecting cap.

(b) Install the bearings in the connecting rod and connecting rod cap.

CYLINDER BLOCK ASSEMBLY

(See Components for Disassembly and Assembly)

HINT:

- Thoroughly clean all parts to be assembled.
Before installing the parts, apply new engine oil to all sliding and rotating surfaces.
- Replace all gaskets, O-rings and oil seals with new parts.




1. INSTALL MAIN BEARINGS

HINT:


- Main bearings come in widths of 19.0 mm (0.748 in.) and 22.4 mm (0.882 in.). Install the 22.4 mm (0.882 in.) bearings in the No. 1 and No.4 cylinder block journal positions with the main bearing cap.
- Install the 19.0 mm (0.748 in.) bearings in the No. 2 and No.3 positions.
- Upper bearings have an oil groove and oil holes; lower bearings do not.

(a) Align the bearing claw with the claw groove of the cylinder block, and push in the 4 upper bearings.

NOTICE: Install the bearing with the oil hole in the cylinder block.




(b) Align the bearing claw with the claw groove of the main bearing cap, and push in the 4 lower bearings.
HINT: A number is marked on each main bearing cap to indicate the installation position.




2. INSTALL UPPER THRUST WASHERS

Install the 2 thrust washers under the No.2 journal position of the cylinder block with the oil grooves facing outward.




3. PLACE CRANKSHAFT ON CYLINDER BLOCK




4. INSTALL MAIN BEARING CAPS AND LOWER THRUST WASHERS

A. Place main bearing caps and lower thrust washers on cylinder block

(a) Install the 2 thrust washers on the No.2 bearing cap with the grooves facing outward.




(b) Temporarily place the 4 main bearing caps level and let them in their proper locations.



(c) Apply a light coat of engine oil on the threads and under the main bearing cap bolts (12 Pointed Head Bolts).

(d) Temporarily install the 8 main bearing cap bolts.




(e) Using a plastic-faced hammer, lightly tap the bearing cap to ensure a proper fit.

B. Install main bearing cap bolts (for 12 Pointed Head Bolts)

HINT:

- The main bearing cap bolts are tightened in 2 progressive steps (steps (b) and (d)).
- If any of the main bearing cap bolts is broken or deformed, replace it.




(a) Apply a light coat of engine oil on the threads and under the main bearing cap bolts.


(b) Install and uniformly tighten the 16 main bearing cap bolts, in several passes, in the sequence shown.

Torque: 22 N·m (225 kgf·cm, 16 ft·lbf)

If any of the main bearing cap bolts does not meet the torque specification, replace the main bearing cap bolt.




(c) Mark the front of the main bearing cap bolts with paint.



(d) Retighten the main bearing cap bolts by 90° in the numerical order shown.

(e) Check that the painted mark is now at a 90° angle to the front.




C. Install main bearing cap bolts (for Hexagon Head Bolts)

(a) Install a new seal washer to the main bearing cap bolt.

(b) Install and uniformly tighten the 8 main bearing cap bolts, in several passes, in the sequence shown.

Torque: 27 N·m (275 kgf·cm, 20 ft·lbf)

(c) Check that the crankshaft turns smoothly.



5. CHECK CRANKSHAFT THRUST CLEARANCE

Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard thrust clearance:

0.04 – 0.24 mm (0.0016 – 0.0095 in.)


Maximum thrust clearance:

0.30 mm (0.0118 in.)

If the thrust clearance is greater than maximum, replace the thrust washers as a set.

Thrust washer thickness:


1.930 – 1.980 mm (0.0760 – 0.0780 in.)



6. INSTALL PISTON AND CONNECTING ROD ASSEMBLES

Using a piston ring compressor, push the correctly numbered piston and connecting rod assemblies into each cylinder with the front mark of the piston facing forward.

HINT: The shape of the piston varies for the RH and LH banks. The RH piston is marked with "R", the LH piston with "L".




7. INSTALL CONNECTING ROD CAPS

A. Place connecting rod cap on connecting rod

(a) Match the numbered connecting rod cap with the connecting rod.

(b) Align the pin dowels of the connecting rod cap with the pins of the connecting rod, and install the connecting rod.




(c) Check that the protrusion of the connecting rod cap is facing in the correct direction.

B. Install connecting rod cap bolts

HINT:


- The connecting rod cap bolts are tightened in 2 progressive steps (steps (b) and (d)).
- If any of the connecting rod cap bolts is broken or deformed, replace it.




(a) Apply a light coat of engine oil on the threads and under the heads of the connecting rod cap bolts.
 (b) Install and alternately tighten the 2 connecting rod cap bolts in several passes.

Torque: 24.5 N·m (250 kgf-cm, 18 ft-lbf)


If any of the connecting rod cap bolts does not meet the torque specification, replace the connecting rod cap bolts.



(c) Mark the front of the connecting cap bolts with paint.



(d) Retighten the cap bolts by 90° as shown.
 (e) Check that the painted mark is now at a 90° angle to the front.
 (f) Check that the crankshaft turns smoothly.



8. CHECK CONNECTING ROD OIL CLEARANCE

Using a dial indicator, measure the thrust clearance while moving the connecting rod back and forth.

Standard thrust clearance:

0.15 – 0.30 mm (0.0059 – 0.0118 in.)

Maximum thrust clearance:

0.35 mm (0.0138 in.)

If the thrust clearance is greater than maximum, replace the connecting rod assembly (s). If necessary, replace the crankshaft.

Connecting rod thickness:

20.80 – 20.85 mm (0.8189 – 0.8209 in.)

9. INSTALL REAR OIL SEAL RETAINER

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the oil seal retainer and cylinder block.


- Using a razor blade and gasket scraper, remove all the oil packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.


(b) Apply seal packing to the oil seal retainer as shown in the illustration.

Seal packing:

Part No. 08826-00080 or equivalent


- Install a nozzle that has been cut to a 2 – 3 mm (0.08 – 0.12) opening.
- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.





(c) Install the oil seal retainer with the 6 bolts.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)




AFTER ASSEMBLY

(See Components for Cylinder Block Preparation of Disassembly and After Assembly)

1. INSTALL EGR COOLER

Install a new gasket and the EGR cooler with the 3 bolts and 2 nuts.

Torque: 9 N-m (90 kgf-cm, 78 in.-lbf)




2. INSTALL OIL PRESSURE SWITCH

(a) Apply adhesive to 2 or 3 threads.

Adhesive:


Part No. 08833-00080. THREE BOND 1344, LOCTITE 242 or equivalent



(b) Using SST, install the oil pressure switch.

SST 09816 – 30010

Torque: 13 N-m (130 kgf-cm, 9 ft-lbf)




3. INSTALL ENGINE COOLANT DRAIN COCK

(a) Apply seal packing to 2 or 3 threads.

Seal packing:

Part No. 08826-00100 or equivalent



(b) Install the drain cock.

Torque: 39 N-m (400 kgf-cm, 29 ft-lbf)

HINT: After applying the specified torque, rotate the drain cock clockwise until it is in the position shown.

4. INSTALL WATER SEAL PLATE

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the seal plate and cylinder block.


- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing groove.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

(b) Apply seal packing to the seal plate as shown in the illustration.


Seal packing:

Part No. 08826-00100 or equivalent

- Install a nozzle that has been cut to a 3–5 mm (0.12 – 0.20 in.) opening.
- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.




204



(c) Install the seal plate with the 2 nuts.


Torque: 14.5 N-m (145 kgf-cm, 10 ft-lbf)



5. INSTALL OIL FILTER UNION


Using a 12 mm hexagon wrench, install the oil filter union.

Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)



6. INSTALL OIL FILTER

(a) Apply clean engine oil to the gasket of a new oil filter.



(b) Lightly screw the oil filter into place, and tighten it until the gasket contacts the seat.


(c) Using SST, tighten it an additional 3/4 turn.

SST 09228-07500

7. INSTALL OIL PUMP

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the oil pump and cylinder block.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.



(b) Apply seal packing to the oil pump as shown in the illustration.


Seal packing:

Part No. 08826-00080 or equivalent


- Install a nozzle that has been cut to a 2–3 mm (0.08–0.12 in.) opening.

HINT: Avoid applying an excessive amount to the surface.


- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.



(c) Place a new O-ring in position on the cylinder block.




(d) Engage the spline teeth of the oil pump drive gear with the large teeth of the crankshaft, and slide the oil pump on the crankshaft.



(e) Install the oil pump with the 9 bolts.

Torque:

- 8 N·m (80 kgf·cm, 69 in.-lbf) for 10 mm head bolt**
- 19.5 N·m (200 kgf·cm, 14 ft-lbf) for 12 mm head bolt**



8. INSTALL NO.1 OIL PAN

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surface of the No.1 oil pan and cylinder block.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

NOTICE: Do not use a solvent which will affect the painted surfaces.

(b) Apply seal packing to the No.2 oil pan as shown in the illustration.

Seal packing:

Part No. 08826-00080 or equivalent


Region "x" is at the outer side of the bolt hole.

Region "y" is at the inner side of the bolt hole.

- Install a nozzle that has been cut to a 4–5 mm (0.16 – 0.20 in.) opening.

HINT: Avoid applying an excessive amount to the surface.

- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.




(c) Install the No.1 oil pan with the 17 bolts.

Torque:

8 N·m (80 kgf·cm, 69 in.-lbf) for 10 mm head bolt


19.5 N·m (200 kgf·cm, 14 ft-lbf) for 12 mm head bolt



9. INSTALL OIL STRAINER

Install a new gasket and the oil strainer with the bolt and 2 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



10. INSTALL NO.2 OIL PAN

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surface of the No.1 and No.2 oil pans.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

NOTICE: Do not use a solvent which will affect the pointed surfaces.

(b) Apply seal packing to the No.2 oil pan as shown in the illustration.


Seal packing:

Part No. 08828-00080 or equivalent

- Install a nozzle that has been cut to a 4–5 mm (0.16 – 0.20 in.) opening.


HINT: Avoid applying an excessive amount to the surface.

- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.



(c) Install the No.2 oil pan with the 10 bolts and 2 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



11. INSTALL WATER PUMP

Install a new gasket and the water pump with the 4 bolts and 2 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)

NOTICE: Do not get oil on the gasket.

12. INSTALL WATER INLET HOUSING

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the water inlet housing and cylinder block.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

(b) Apply seal packing to the water inlet housing as shown in the illustration.



Seal packing:

Part No. 08826-00100 or equivalent

- Install a nozzle that has been cut to a 3–5 mm (0.12–0.20 in.) opening.


HINT: Avoid applying an excessive amount to the surface.

- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.



(c) Install the water inlet housing with the 8 bolts and 2 nuts, in the several passes, in the sequence shown.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)




13. INSTALL KNOCK SENSORS


(a) Using SST, install the 2 knock sensors.

SST 09816 – 30010

Torque: 39 N·m (400 kgf·cm, 29 ft-lbf)




- (b) Connect the 2 knock sensor connectors.
- (c) Install the wire band.
- (d) Connect the engine wire clamp.



14. INSTALL NO.2 IDLER PULLEY BRACKET

Install the pulley bracket with the 2 bolts.

Torque: 28 N-m (290 kgf-cm, 21 ft-lbf)



15. INSTALL A/C COMPRESSOR HOUSING BRACKET

Install the compressor housing bracket with the 3 bolts.


Torque: 25 N-m (250 kgf-cm, 18 ft-lbf)



16. INSTALL GENERATOR BRACKET AND ADJUSTING BAR

Install the generator bracket and adjusting bar with the 3 nuts.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)



17. INSTALL GENERATOR

Install the generator with the 2 bolts. Do not tighten the bolts yet.


18. INSTALL CYLINDER HEAD

(See pages [EG2-96](#) to 118)

19. INSTALL TIMING PULLEYS AND BELT

(See pages [EG2-49](#) to 55)

20. REMOVE ENGINE STAND




ENGINE & TRANSAXLE ASSEMBLY


(See Components for Engine & Transaxle Separation and Assembly)

1. INSTALL DRIVE PLATE

(a) Install the front spacer on the crankshaft with the chamfered end facing the shaft.



(b) Install the drive plate and rear spacer on the crankshaft.




(c) Clean the threads of the bolt with the gasoline.

(d) Apply adhesive to 2 or 3 threads of the mount bolt.


Adhesive:

Part No. 08833-00070. THREE BOND 1324 or equivalent



(e) Install and uniformly tighten the mounting bolts, in the several passes, in the sequence shown.

Torque: 83 N-m (850 kgf-cm, 61 ft-lbf)




2. CHECK TORQUE CONVERTER CLUTCH INSTALLATION

Using a scale and a straight edge, measure from the installed surface to the front surface of the transaxle housing.

Correct distance:

13.7 mm (0.539 in.) or more




3. INSTALL TRANSAXLE TO ENGINE

A. Install transaxle


- (a) Attach the transaxle to the engine.
- (b) Install the 6 bolts.

Torque: 64 N·m (650 kgf·cm, 47 ft·lbf)




- (c) Install the 2 bolts holding the No.2 oil pan to the transaxle.

Torque: 46 N·m (470 kgf·cm, 34 ft·lbf)



- (e) Install the No.2 manifold stay with the bolt and nut.


Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)



- (f) Install the manifold stay, exhaust manifold plate with the bolt and 2 nuts.

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

HINT: Install the manifold so that the tip of the stay touches the head of the differential retainer installation bolt as shown in the illustration.




B. Install torque converter clutch mounting bolts

- (a) Clean the threads of the bolt with the gasoline.
- (b) Apply adhesive to 2 or 3 threads of the mount bolt.

Adhesive:


Part No. 08833-00070, THREE BOND 1324 or equivalent



(c) Hold the crankshaft pulley bolt with a wrench, and install the 6 bolts evenly.


Torque: 41 N-m (420 kgf-cm, 30 ft-lbf)

HINT: First install the dark green colored bolt, then install the other bolts.



(d) Install the flywheel housing under cover with the 2 bolts.

Torque: 18 N-m (185 kgf-cm, 13 ft-lbf)



4. INSTALL OIL DIPSTICK GUIDE AND DIPSTICK FOR TRANSMISSION

(a) Install a new O-ring to the dipstick guide.

(b) Apply soapy water to the O – ring.

(c) Connect the dipstick guide end to the dipstick tube of the oil pan.

(d) Install the dipstick guide with the bolt.

(e) Install the dipstick.

5. CONNECT ENGINE WIRE

(a) Connect the following parts:

- (1) O/D solenoid connector
- (2) PNP switch speedometer
- (3) Starter 50 terminal
- (4) Starter B terminal
- (5) Speed sensor connector

(b) Disconnect the 2 wire clamps from the transaxle.

(c) Install the 2 wire clamps to the transaxle.


ENGINE INSTALLATION

(See Components for Engine Removal and Installation)

1. INSTALL FRONT EXHAUST PIPE STAY

Install the pipe stay with the 2 bolts.


Torque: 21 N-m (210 kgf-cm, 16 ft-lbf)



2. INSTALL RR ENGINE MOUNTING INSULATOR

Install the mounting insulator with the 4 bolts.


Torque: 63.7 N-m (650 kgf-cm, 47 ft-lbf)



3. INSTALL FR ENGINE MOUNTING INSULATOR

Install the mounting insulator with the 4 bolts.

Torque: 6.74 N-m (650 kgf-cm, 47 ft-lbf)




4. INSTALL ENGINE AND TRANSAXLE ASSEMBLY IN VEHICLE

(a) Attach the engine sling device to the engine hangers.


(b) Lower the engine into the engine compartment.

Tilt the transaxle downward, lower the engine and clear the LH mounting.

NOTICE: Be careful not to hit the PS gear housing or neutral start switch.




(c) Keep the engine level, and align RH and LH mountings with the body bracket.



5. INSTALL NO.2 ENGINE MOUNTING BRACKET AND ENGINE MOVING CONTROL ROD

Install the engine moving control rod and No.2 engine mounting bracket with the 3 bolts.


Torque: 63.7 N-m (650 kgf-cm, 47 ft-lbf)



6. INSTALL RH ENGINE MOUNTING STAY


Install the RH mounting stay with the 3 bolts.

Torque: 31.4 N-m (320 kgf-cm, 23 ft-lbf)



7. CONNECT GROUND STRAPS


Connect the 2 straps.



8. INSTALL COOLANT RESERVOIR TANK

(a) Install the reservoir tank.

(b) Connect the reservoir hose.




9. CONNECT FR ENGINE MOUNTING INSULATOR

Connect the mounting insulator with the 3 bolts.


Torque: 80.4 N-m (820 kgf-cm, 59 ft-lbf) for TMC made

Torque: 65.7 N-m (670 kgf-cm, 48 ft-lbf) for TMM made

**10. INSTALL ENGINE MOUNTING ABSORBER**

Install the engine mounting absorber with the 4 bolts.


Torque: 48 N·m (490 kgf·cm, 35 ft·lbf)

**11. CONNECT RR ENGINE MOUNTING INSULATOR**

(a) Connect the mounting insulator with the 4 nuts.


Torque: 65.7 N·m (670 kgf·cm, 48 ft·lbf)

(b) Install the 2 hole plugs.

**12. CONNECT LH ENGINE MOUNTING INSULATOR**

Connect the mounting insulator with the 4 bolts.


Torque: 63.7 N·m (650 kgf·cm, 47 ft·lbf)

13. REMOVE ENGINE SLING DEVICE**14. INSTALL PS PUMP**

(a) Install the PS pump with the 2 bolts.

Torque: 43 N·m (440 kgf·cm, 31 ft·lbf)


(b) Install the drive belt.

**15. CONNECT HYDRAULIC COOLING FAN PRESSURE HOSE**


Using SST, connect the pressure hose.

SST 09631- 22020

Torque: 44 N·m (450 kgf·cm, 33 ft·lbf)

**16. CONNECT PS PRESSURE TUBE**

- (a) Connect the PS pressure tube with the 2 nuts.
- (b) Connect the 2 PS air hoses.


17. INSTALL DRIVE SHAFTS (See SA section)**18. INSTALL FRONT EXHAUST PIPE**

- (a) Temporarily install 3 new gaskets and the front exhaust pipe with the 2 bolts and 6 nuts.
 - (b) Tighten the 4 nuts holding the exhaust manifolds to the front exhaust pipe.
- Torque: 62 N-m (630 kgf-cm, 46 ft-lbf)**
- (c) Tighten the 2 bolts and 2 nuts holding the three-way catalytic converter to the front exhaust pipe.

Torque: 56 N-m (570 kgf-cm, 41 ft-lbf)


- (d) Connect the bracket with the 2 bolts.

Torque: 19 N-m (195 kgf-cm, 14 ft-lbf)




- (e) Connect the front exhaust pipe clamp with the 2 bolts.

Torque: 29 N-m (300 kgf-cm, 22 ft-lbf)

**19. INSTALL A/C COMPRESSOR**

- (a) Install the A/C compressor and drive belt adjusting bar bracket with the 5 bolts.



Torque: 25 N-m (250 kgf-cm, 18 ft-lbf)




20. CONNECT ENGINE WIRE TO CABIN

(a) Push in the engine wire through the cowl panel. Install the 2 nuts.

- (b) Connect the wire clamp.
- (c) Connect the following connectors:
 - (1) 3 engine ECM connectors
 - (2) 5 cowl wire connectors
 - (3) Cooling fan ECU connector
- (d) Install the following parts:
 - (1) Glove compartment
 - (2) Glove compartment door
 - (3) Lower instrument panel
 - (4) Under cover




21. CONNECT TRANSAXLE CONTROL CABLE TO TRANSAXLE


**22. CONNECT FUEL HOSES**

- (a) Connect the fuel return hose to the fuel pipe.
- (b) Connect the fuel inlet hose to the fuel filter.

Torque: 30 N·m (300 kgf·cm, 22 ft·lbf)


**23. CONNECT HEATER HOSES**

Connect the 2 hoses.


**24. CONNECT VACUUM HOSES**

Connect the following vacuum hoses:


- (1) Brake booster vacuum hose to air intake chamber



- (2) Vacuum hose to charcoal canister




- (3) Vacuum hoses to vacuum tank for intake air control valve




25. CONNECT ENGINE WIRE


- (a) Connect the wire clamps.
- (b) Connect the ground strap with the bolt.
- (c) Connect the connector to the LH fender apron.



- (d) Connect the wire clamps
- (e) Connect the following wires and connectors:
 - (1) 2 igniter connectors
 - (2) Noise filter connector
 - (3) Connector to LH fender apron
 - (4) 2 ground straps




- (5) 5 connectors to relay box
- (f) Connect the engine relay box with the 2 bolts.




26. INSTALL RADIATOR

(See page [EG2-342](#))




27. w/ CRUISE CONTROL SYSTEM: INSTALL CRUISE CONTROL ACTUATOR

- (a) Connect the actuator and bracket with the 3 bolts.
- (b) Connect the actuator connector and clamp.
- (c) Install the actuator cover with the bolt and clip.

**28. INSTALL AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE**

- (a) Connect the air cleaner hose, and install the air cleaner cap and volume air flow meter with the 4 clips.
- (b) Tighten the air cleaner hose clamp bolt.
- (c) Connect the PCV hose.
- (d) Connect the accelerator cable clamp.
- (e) Connect the volume air flow meter connector and wire clamp.

**29. CONNECT THROTTLE CABLE****30. CONNECT ACCELERATOR CABLE****31. FILL ENGINE WITH OIL****Capacity:****Drain and refill****w/ Oil filter change**

4.7 liters (5.0 US qts, 4.1 Imp. qts)

w/o Oil filter change


4.5 liters (4.8 US qts, 4.0 Imp. qts)

Dry fill

5.5 liters (5.8 US qts, 4.8 Imp. qts)

32. FILL WITH ENGINE COOLANT**Capacity:**

8.7 liters (9.2 US qts, 7.7 Imp. qts)


**33. INSTALL BATTERY TRAY AND BATTERY****34. START ENGINE AND CHECK FOR LEAKS****35. PERFORM ROAD TEST**

Check for abnormal noise, shock, slippage, correct shift points and smooth operation.

36. RECHECK ENGINE COOLANT AND ENGINE OIL LEVELS

EXHAUST SYSTEM COMPONENTS

99M2-01



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

P13310

SERVICE SPECIFICATIONS

KSCRM-06

SERVICE DATA

Engine tune – up	Battery (Except Delco Battery)		
	Specific gravity (Except maintenance free battery)		
	55D23L Battery		
	GNB Incorporated	at 20°C (68°F)	1.25 – 1.27
	JHONSON CONTROLS	at 27°C (81°F)	1.26 – 1.28
	80D26L Battery		
	GNB Incorporated	at 20°C (68°F)	1.27 – 1.29
	JHONSON CONTROLS	at 27°C (81°F)	1.28 – 1.30
	Voltage (Maintenance free battery)	at 20°C (68°F)	12.7 – 12.9 V
	Drive belt tension	New belt	175 ± 5 lbf
		Used belt	115 ± 20 lbf
	Valve clearance (Cold)	Intake	0.15 – 0.25 mm (0.006 – 0.010 in.)
		Exhaust	0.25 – 0.35 mm (0.010 – 0.014 in.)
	Valve clearance adjusting shim (for repair part)		
		Mark 2.500	2.500 mm (0.0984 in.)
		Mark 2.550	2.550 mm (0.1004 in.)
		Mark 2.600	2.600 mm (0.1024 in.)
		Mark 2.650	2.650 mm (0.1043 in.)
		Mark 2.700	2.700 mm (0.1063 in.)
		Mark 2.750	2.750 mm (0.1083 in.)
		Mark 2.800	2.800 mm (0.1102 in.)
		Mark 2.850	2.850 mm (0.1122 in.)
		Mark 2.900	2.900 mm (0.1142 in.)
		Mark 2.950	2.950 mm (0.1161 in.)
		Mark 3.000	3.000 mm (0.1181 in.)
		Mark 3.050	3.050 mm (0.1201 in.)
		Mark 3.100	3.100 mm (0.1220 in.)
		Mark 3.150	3.150 mm (0.1240 in.)
		Mark 3.200	3.200 mm (0.1260 in.)
		Mark 3.250	3.250 mm (0.1280 in.)
		Mark 3.300	3.300 mm (0.1299 in.)
	Ignition timing		10° BTDC @ idle (w/ Terminals TE1 and E1 connected of DLC1)
	Idle speed		700 ± 50 rpm
Intake manifold vacuum	at idle speed		60 kPa (450 mmHg, 17.7 in.Hg) or more
Compression pressure	at 250 rpm	STD	1,226 kPa (12.5 kgf/cm ² , 178 psi) or more
		Limit	981 kPa (10.0 kgf/cm ² , 142 psi)
	Difference of pressure between each cylinder		98 kPa (1.0 kgf/cm ² , 14 psi) or less
Tinning belt tensioner	Protrusion (from housing side)		10.0 – 10.8 mm (0.394 – 0.425 in.)

Cylinder head	Warpage	Limit	0.10 mm (0.039 in.)
	Valve seat		
	Refacing angle		30°, 45°, 75°
	Contacting angle		45°
	Contacting width		1.0 – 1.4 mm (0.039 – 0.055 in.)
	Cylinder head bolt thread inside diameter	STD Limit	10.70 – 11.00 mm (0.4213 – 0.4724 in.) 9.60 mm (0.3780 in.)
Valve guide bushing	Inside diameter		5.510 – 5.530 mm (0.2169 – 0.2177 in.)
	Outside diameter (for repair part)	STD	10.295 – 10.313 mm (0.4053 – 0.4080 in.)
		O/S 0.05	10.345 – 10.363 mm (0.4073 – 0.4080 in.)
	Protrusion height	Intake Exhaust	11.1 – 11.3 mm (0.437 – 0.445 in.) 8.9 – 9.3 mm (0.350 – 0.366 in.)
Valve	Valve overall length	STD (Intake) (Exhaust) Limit (Intake) (Exhaust)	95.45 mm (3.5779 in.) 95.40 mm (3.7559 in.) 94.95 mm (3.7382 in.) 94.90 mm (3.7362 in.)
	Valve face angle		44.5°
	Stem diameter	Intake Exhaust	5.470 – 5.485 mm (0.2154 – 0.2159 in.) 5.465 – 5.480 mm (0.2152 – 0.2157 in.)
	Stem oil clearance	STD (Intake) (Exhaust) Limit (Intake) (Exhaust)	0.025 – 0.060 mm (0.0010 – 0.0024 in.) 0.030 – 0.065 mm (0.0012 – 0.0026 in.) 0.08 mm (0.0031 in.) 0.10 mm (0.0039 in.)
	Margin thickness	STD Limit	1.0 mm (0.039 in.) 0.5 mm (0.020 in.)
Valve spring	Deviation	Limit	2.0 mm (0.079 in.)
	Free length		45.50 mm (1.7913 in.)
	Installed tension at 33.8 mm (1.331 in.)		186 – 206 N (19.0 – 21.0 kgf, 41.9 – 46.3 lbf)
Valve lifter	Lifter diameter		30.966 – 30.976 mm (1.2191 – 1.2195 in.)
	Lifter bore diameter		31.000 – 31.016 mm (1.2205 – 1.2211 in.)
	Oil clearance	STD Limit	0.024 – 0.050 mm (0.0009 – 0.0020 in.) 0.07 mm (0.0028 in.)
Camshaft	Thrust clearance	STD Limit	0.040 – 0.090 mm (0.0016 – 0.0035 in.) 0.12 mm (0.0047 in.)
	Journal oil clearance	STD Limit	0.035 – 0.072 mm (0.0014 – 0.0028 in.) 0.10 mm (0.0039 in.)
	Journal diameter		26.949 – 26.965 mm (1.0610 – 1.0616 in.)
	Circle runout	Limit	0.06 mm (0.0024 in.)
	Cam lobe height	STD (Intake) (Exhaust) Limit (Intake) (Exhaust)	42.11 – 42.21 mm (1.6579 – 1.6618 in.) 41.96 – 42.06 mm (1.6520 – 1.6559 in.) 41.96 mm (1.6520 in.) 41.81 mm (1.6461 in.)
	Camshaft gear backlash	STD Limit	0.020 – 0.200 mm (0.0008 – 0.0079 in.) 0.30 mm (0.0118 in.)
	Camshaft gear spring end free distance		18.2 – 18.8 mm (0.712 – 0.740 in.)
Air intake chamber	Warpage	Limit	0.10 mm (0.0039 in.)

Intake manifold	Warpage		
	Air intake side	Limit	0.15 mm (0.0059 in.)
	Cylinder head side	Limit	0.08 mm (0.0031 in.)
Exhaust manifold	Warpage	Limit	0.50 mm (0.0196 in.)
Cylinder block	Cylinder head surface warpage	Limit	0.07 mm (0.0028 in.)
	Cylinder bore diameter		87.500 – 87.512 mm (3.4449 – 3.4453 in.)
		Limit	87.52 mm (3.4457 in.)
	Main journal bore diameter		
	(Reference)	Mark 00	86.000 mm (2.5984 in.)
		Mark 01	86.001 mm (2.5985 in.)
		Mark 02	86.002 mm (2.5985 in.)
		Mark 03	86.003 mm (2.5985 in.)
		Mark 04	86.004 mm (2.5986 in.)
		Mark 05	86.005 mm (2.5986 in.)
		Mark 06	86.006 mm (2.5987 in.)
		Mark 07	86.007 mm (2.5987 in.)
		Mark 08	86.008 mm (2.5987 in.)
		Mark 09	86.009 mm (2.5988 in.)
		Mark 10	86.010 mm (2.5988 in.)
		Mark 11	86.011 mm (2.5989 in.)
		Mark 12	86.012 mm (2.5989 in.)
		Mark 13	86.013 mm (2.5989 in.)
		Mark 14	86.014 mm (2.5990 in.)
		Mark 15	86.015 mm (2.5990 in.)
		Mark 16	86.016 mm (2.5990 in.)
	Main bearing cap stud bolt tension portion diameter		
		STD	7.500 – 7.800 mm (0.2953 – 0.2992 in.)
		Limit	7.40 mm (0.2913 in.)
Piston and piston ring	Piston diameter		87.408 – 87.416 mm (3.4412 – 3.4416 in.)
	Piston oil clearance	STD	0.084 – 0.106 mm (0.0033 – 0.0042)
		Limit	0.13 mm (0.0051 in.)
	Piston ring groove clearance	No.1	0.020 – 0.070 mm (0.0008 – 0.0028 in.)
		No.2	0.020 – 0.060 mm (0.0008 – 0.0024 in.)
	Piston ring end gap	STD (No.1)	0.25 – 0.35 mm (0.0098 – 0.0138 in.)
		(No.2)	0.35 – 0.45 mm (0.0138 – 0.0177 in.)
		(Oil)	0.15 – 0.40 mm (0.0059 – 0.0157 in.)
		Limit (No.1)	0.95 mm (0.0374 in.)
		(No.2)	1.05 mm (0.0413 in.)
Connecting rod		(Oil)	1.00 mm (0.0394 in.)
	Thrust clearance	STD	0.15 – 0.30 mm (0.0059 – 0.0118 in.)
		Limit	0.35 mm (0.0138 in.)
	Connecting rod thickness		20.80 – 20.85 mm (0.8189 – 0.8209 in.)
	Connecting rod big end inside diameter		
	(Reference)	Mark 1	56.000 – 56.006 mm (2.2047 – 2.2050 in.)
		Mark 2	56.006 – 56.012 mm (2.2050 – 2.2052 in.)
		Mark 3	56.012 – 56.018 mm (2.2052 – 2.2054 in.)
		Mark 4	56.018 – 56.024 mm (2.2054 – 2.2057 in.)

Connecting rod (Cont'd)	Connecting rod bearing center wall thickness (Reference)		Mark 1	1.484 – 1.487 mm (0.0584 – 0.0585 in.)
			Mark 2	1.487 – 1.490 mm (0.0585 – 0.0587 in.)
			Mark 3	1.490 – 1.493 mm (0.0587 – 0.0588 in.)
			Mark 4	1.493 – 1.496 mm (0.0588 – 0.0589 in.)
	Connecting rod oil clearance		STD	0.038 – 0.064 mm (0.0015 – 0.0025 in.)
			Limit	0.08 mm (0.0031 in.)
	Rod out-of-alignment	Limit per 100mm (3.94 in.)		0.05 mm (0.0020 in.)
	Rod twist	Limit per 100mm (3.94 in.)		0.15 mm (0.0059 in.)
	Bushings inside diameter			22.005 – 22.014 mm (0.8663 – 0.8667 in.)
	Piston pin diameter			21.997 – 22.006 mm (0.8660 – 0.8664 in.)
	Bushings oil clearance		STD	0.005 – 0.011 mm (0.0002 – 0.0004 in.)
			Limit	0.05 mm (0.0020 in.)
	Connecting rod bolt tension portion diameter		STD	7.2 – 7.3 mm (0.284 – 0.287 in.)
			Limit	7.0 mm (0.276 in.)
Crankshaft	Thrust clearance		STD	0.04 – 0.24 mm (0.0016 – 0.0095 in.)
			Limit	0.30 mm (0.0118 in.)
	Thrust washer thickness			1.830 – 1.980 mm (0.0720 – 0.0780 in.)
	Main journal oil clearance		STD	0.026 – 0.046 mm (0.0010 – 0.0018 in.)
			Limit	0.06 mm (0.0024 in.)
	Main journal diameter			60.988 – 61.000 mm (2.4011 – 2.4016 in.)
	Main bearing center wall thickness (Reference)		Mark 1	2.486 – 2.489 mm (0.0979 – 0.0980 in.)
			Mark 2	2.489 – 2.492 mm (0.0980 – 0.0981 in.)
			Mark 3	2.492 – 2.495 mm (0.0981 – 0.0982 in.)
			Mark 4	2.495 – 2.498 mm (0.0982 – 0.0983 in.)
			Mark 5	2.498 – 2.501 mm (0.0983 – 0.0985 in.)
	Crank pin diameter			52.994 – 53.000 mm (2.0864 – 2.0866 in.)
	Circle runout	Limit		0.06 mm (0.0024 in.)
	Main journal taper and out-of-round	Limit		0.02 mm (0.0008 in.)
	Crank pin taper and out-of-round	Limit		0.02 mm (0.0008 in.)

MEPQ-24

TORQUE SPECIFICATIONS

Part tightened	N·m	kgf·cm	ft·lbf
Cylinder head cover x Cylinder head	8	80	69 in.-lbf
Spark plug x Cylinder head	18	180	13
Ignition coil x Cylinder head cover	8	80	69 in.-lbf
Air intake chamber x Intake manifold	43	440	32
EGR pipe x Exhaust manifold	12	120	9
EGR pipe x Air intake chamber	12	120	9
No.1 engine hanger x Air intake chamber	39	400	29
No.1 engine hanger x Cylinder head	39	400	29
Air intake chamber stay x Air intake chamber	19.5	200	14
Air intake chamber stay x Cylinder head	19.5	200	14
Emission control valve set x Air intake chamber	8	80	69 in.-lbf
Timing belt plate x Oil pump	8	80	69 in.-lbf
No.1 idler pulley x Oil pump	34	350	25
No.2 idler pulley x No.2 idler pulley bracket	43	440	32

Camshaft timing pulley x Camshaft (For use with SST)	88	900	65
Camshaft timing pulley x Camshaft	125	1,300	94
Timing belt tensioner x Oil pump	27	280	20
Engine RH mounting bracket x Cylinder block	28	290	21
No.2 timing belt cover x No.3 timing belt cover	8.5	85	74 in.-lbf
No.1 timing belt cover x Oil pump	8.5	85	74 in.-lbf
Crankshaft pulley x Crankshaft	215	2,200	159
No.2 generator bracket x Engine RH mounting bracket	28	290	21
Engine moving control rod x Engine RH mounting bracket	63.7	650	47
Engine moving control rod x RH fender apron	63.7	650	47
RH engine mounting stay x Water outlet	31.4	320	23
RH engine mounting stay x Engine moving control rod	31.4	320	23
RH engine mounting stay x No.2 RH engine mounting bracket	31.4	320	23
Camshaft bearing cap x Cylinder head	16	160	12
Cylinder head x Cylinder block – 12-pointed head bolt (1 st)	54	550	40
Cylinder head x Cylinder block – 12-pointed head bolt (2nd)	Turn 90°	Turn 90°	Turn 90°
Cylinder head x Cylinder block – Recessed head bolt	18.5	185	13
Camshaft position sensor x Cylinder head	8	80	69 in.-lbf
Exhaust manifold x Cylinder head	49	500	36
EGR pipe x RH exhaust manifold	12	120	9
EGR pipe x EGR cooler	12	120	9
Exhaust manifold stay x Exhaust manifold	19.5	200	14
Exhaust manifold stay x Transmission housing	19.5	200	14
Oxygen sensor x Exhaust manifold	44	450	33
PS bracket x RH cylinder head	43	440	32
Oil dipstick guide x LH cylinder head	8	80	69 in.-lbf
No.2 engine hanger x LH cylinder head	19.5	200	14
Water outlet x Intake manifold	15	150	11
No.3 timing belt cover x Cylinder head	8.5	85	74 in.-lbf
Intake manifold x Cylinder head	15	150	11
Delivery pipe x Intake manifold	10	100	7
No. 1 fuel pipe x Intake manifold	19.5	200	14
Cylinder head rear plate x LH cylinder head	8	80	69 in.-lbf
Water inlet pipe x LH cylinder head	19.5	200	14
Front exhaust pipe x Exhaust manifold	62	630	46
Front exhaust pipe x Three-way catalytic converter	56	570	41
Front exhaust pipe bracket x Sub frame	19	195	14
Front exhaust pipe clamp x Front exhaust pipe stay	29	300	22
EGR valve x Air intake chamber	12	120	9
Throttle body x Air intake chamber	19.5	200	14
Intake air control valve x Air intake chamber	14.5	145	10
Fuel inlet hose x Fuel filter	30	300	22
Connecting rod cap x Connecting rod – 1 st	24.5	250	18
Connecting rod cap x Connecting rod – 2nd	Turn 90°	Turn 90°	Turn 90°
Main bearing cap x Cylinder block – 1 st (12 pointed head bolt)	22	225	16
Main bearing cap x Cylinder block – 2nd (12 pointed head bolt)	Turn 90°	Turn 90°	Turn 90°
Main bearing cap x Cylinder block (Hexagon head bolt)	27	275	20
Rear oil seal retainer x Cylinder block	8	80	69 in.-lbf
EGR cooler x Cylinder block	9	90	78 in.-lbf

Oil pressure switch x Cylinder block	13	130	9
Engine coolant drain cock x Cylinder block	39	400	29
Water seal plate x Cylinder block	14.5	145	10
Oil filter union x Cylinder block	13	130	9
Oil pump x Cylinder block (10 mm head bolt)	8	80	69 in.-lbf
Oil pump x Cylinder block (12 mm head bolt)	19.5	200	14
No.1 oil pan x Cylinder block	19.5	200	14
No.1 oil pan x Oil pump	8	80	69 in.-lbf
No.1 oil pan x Rear oil seal retainer	8	80	69 in.-lbf
Oil strainer x Main bearing cap	8	80	69 in.-lbf
Oil strainer x Oil pump	8	80	69 in.-lbf
No.2 oil pan x No. 1 oil pan	8	80	69 in.-lbf
Water pump x Cylinder block	8	80	69 in.-lbf
Water inlet housing x Cylinder block	8	80	69 in.-lbf
Knock sensor x Cylinder block	39	400	29
No.2 idler pulley bracket x Cylinder block	28	290	21
A/C compressor housing bracket x Cylinder block	25	250	18
Generator bracket x Cylinder block	43	440	32
Drive plate x Crankshaft	83	850	61
Transaxle x Engine	64	650	47
No.2 oil pan x Transaxle	46	470	34
Drive plate x Torque convertor clutch	41	420	30
Front exhaust pipe stay x No.1 oil pan	21	210	15
RR engine mounting insulator x Cylinder block	63.7	650	47
FR engine mounting insulator x Cylinder block	63.7	650	47
FR engine mounting insulator x Front suspension member (TMC made)	80.4	820	59
FR engine mounting insulator x Front suspension member (TM M made)	65.7	670	48
Engine mounting absorber x Front suspension member	48	490	35
Engine mounting absorber x Transaxle	48	490	35
RR engine mounting insulator x Front suspension member	65.7	670	48
LH engine mounting insulator x Transaxle	63.7	650	47
PS pump x PS pump bracket	43	440	31
PS pump x Hydraulic cooling fan pressure hose	44	450	33
A/C compressor x Generator bracket	25	250	18
A/C compressor x Cylinder block	25	250	18

EMISSION CONTROL SYSTEMS

DESCRIPTION

The emission control systems are installed to reduce the amount of HC, CO and NOx emitted from the engine, and to also prevent release of evaporated fuel from the gasoline tank and prevent atmospheric release of blow-by gas.


The system consists of the PCV, EVAP, EGR and TWC.

The function of each system is shown in the following table.


System	Abbreviation	Purpose
Positive crankcase ventilation Evaporative emission control Exhaust gas recirculation Three-way catalytic converter Sequential multiport fuel injection*	PCV EVAP EGR TWC SFI	Reduces blow-by gas Reduces evaporative HC Reduces NOx Reduces CO, HC and NOx Regulates all engine conditions for reduction of exhaust emissions.

*For inspection and repair of the SFI system, refer to the SFI section.

COMPONENT LAYOUT




SCHEMATIC DRAWING



PREPARATION


SST (SPECIAL SERVICE TOOL)

881M1-61

 09843-18020 Diagnosis Check Wire	
--	--

RECOMMENDED TOOLS

882M1-06

 09082-00050 TOYOTA Electrical Tester Set	
--	--

EQUIPMENT

882M1-03

Tachometer	
Torque wrench	
Vacuum gauge	

SSM (SPECIAL SERVICE MATERIALS)

884M1-04

08833-00070 Adhesive 1311, THREE BOND 1311 or equivalent	TVV
---	-----

POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM


DESCRIPTION

80362-00

To reduce HC emission, crankcase blow-by gas is routed through the PCV valve to the air intake chamber for combustion in the cylinders.

OPERATION

80362-01



Engine not Running




Air Intake Chamber Side
○ PCV VALVE IS CLOSED

Cylinder Head Side

EC4388

Normal Operation



○ PCV VALVE IS OPEN
○ VACUUM PASSAGE IS LARGE

EC4391

Idling or Deceleration



○ PCV VALVE IS OPEN
○ VACUUM PASSAGE IS SMALL

EC4390

Acceleration or High Load




○ PCV VALVE IS OPEN

EC4389

V04137


BISON-04



PCV VALVE INSPECTION

1. REMOVE PCV VALVE

- (a) Disconnect the PCV hose from the PCV valve.
- (b) Remove the PCV valve.




2. INSTALL CLEAN HOSE TO PCV VALVE

3. INSPECT PCV VALVE OPERATION

- (a) Blow air into the cylinder head side, and check that air passes through easily.

CAUTION: Do not suck air through the valve.

Petroleum substances inside the valve are harmful.




- (b) Blow air into the intake manifold side, and check that air passes through with difficulty.

If operation is not as specified, replace the PCV valve.

4. REMOVE CLEAN HOSE FROM PCV VALVE

5. REINSTALL PCV VALVE



PCV HOSES AND CONNECTORS INSPECTION

VISUALLY INSPECT HOSES, CONNECTIONS AND GASKETS

Check for cracks, leaks or damage.

BISON-04

EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM


DESCRIPTION

00200H-00


To reduce HC emission, evaporated fuel from the fuel tank is routed through the charcoal canister to the intake manifold for combustion in the cylinders.

OPERATION

00200P-00



Engine Coolant Temp.	TVV	Throttle Valve Position	Canister Check Valve			Check Valve in Tank Cap	Evaporated Fuel (HC)
			(1)	(2)	(3)		
Below 40 ₂ C (104 ₂ F)	CLOSED	—	—	—	—	—	HC from tank is absorbed into the canister.
Above 59 ₂ C (138 ₂ F)	OPEN	Positioned below port P	CLOSED	—	—	—	
		Positioned above port P	OPEN	—	—	—	HC from canister is led into air intake chamber.
High pressure in tank	—	—	—	OPEN	CLOSED	CLOSED	HC from tank is absorbed into the canister.
High vacuum in take	—	—	—	CLOSED	OPEN	OPEN	Air is led into the fuel tank




FUEL VAPOR LINES, FUEL TANK AND TANK CAP INSPECTION

1. VISUALLY INSPECT LINES AND CONNECTIONS

Look for loose connections, sharp bends or damage.

2. VISUALLY INSPECT FUEL TANK


Look for deformation, cracks or fuel leakage.



3. VISUALLY INSPECT FUEL TANK CAP

Check if the cap and/or gasket are deformed or damaged.

If necessary, repair or replace the cap.




CHARCOAL CANISTER INSPECTION

1. REMOVE CHARCOAL CANISTER


2. VISUALLY INSPECT CHARCOAL CANISTER

Look for cracks or damage.




3. CHECK FOR CLOGGED FILTER AND STUCK CHECK VALVE

(a) Blow low pressure compressed air (4.71 kPa, 48 gf/cm², 0.68 psi) into port A and check that air flows without resistance from the other ports.



(b) Blow low pressure compressed air (4.71 kPa, 48 gf/cm², 0.68 psi) into port B and check that air does not flow from the other ports.

If a problem is found, replace the charcoal canister.



4. CLEAN FILTER IN CANISTER

Clean the filter by blowing 294 kPa (3 kgf/cm², 43 psi) of compressed air into port A while holding port B closed.

NOTICE:

- Do not attempt to wash the canister.
- No activated carbon should come out.


5. REINSTALL CHARCOAL CANISTER

TVV INSPECTION

894000-94


1. DRAIN ENGINE COOLANT

2. REMOVE TVV FROM INTAKE MANIFOLD




3. INSPECT TVV OPERATION

- Cool the TVV to below 40°C (104°F) with cool water.
- Check that air does not flow from the upper port to lower port.



- Heat the TVV to above 59°C (138°F) with hot water.
- Check that air flows from the upper port to lower port. If operation is not as specified, replace the TVV.



4. REINSTALL TVV


Apply adhesive to 2 or 3 threads of the TVV, and install it.

Adhesive:

Part No. 08833-00070, THREE BOND 1324 or equivalent


Torque: 30 N-m (305 kgf-cm, 22 ft-lbf)

5. REFILL WITH ENGINE COOLANT



CHECK VALVE INSPECTION

1. REMOVE CHECK VALVE




2. INSPECT CHECK VALVE

(a) Check that air flows from the yellow port to the black port.

(b) Check that air does not flow from the black port to the yellow port.

If operation is not as specified, replace check valve.



3. REINSTALL CHECK VALVE


HINT: Reinstall the check valve with the black port facing the purge port side.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

DESCRIPTION

To reduce NO_x emission, part of the exhaust gases are recirculated through the EGR valve to the intake manifold to lower the maximum combustion temperature.

OPERATION




Engine Coolant Temp.	VSV	Throttle Valve Position	Pressure in the EGR Valve Pressure Chamber		EG R Vacuum Modulator	EG R Valve	Exhaust Gas
Below 55°C (131°F)	ON OPENS passage to atmosphere	-	-		-	CLOSED	Not recirculated
Above 60°C (140°F)	OFF CLOSED passage to atmosphere	Positioned below port E	-		-	CLOSED	Not recirculated
		Positioned between port E and port R	(1) LOW	*Pressure constantly alternating between low and high	OPENS passage to atmosphere	CLOSED	Not recirculated
			(2) HIGH		CLOSES passage to atmosphere	OPEN	Recirculated
		Positioned above port R	(3) HIGH	**	CLOSES passage to atmosphere	OPEN	Recirculated (increase)

* Pressure increase → Modulator closes → EGR valve opens → Pressure drops
 EGR valve closes ← Modulator opens ←

** When the throttle valve is positioned above port R, the EGR vacuum modulator will close the atmosphere passage and open the EGR valve to increase the EGR gas, even if the exhaust pressure is insufficiently low.

V03592

03001-01



EGR SYSTEM INSPECTION

1. CHECK AND CLEAN FILTER IN EGR VACUUM MODULATOR

- Remove the cap and filter.
- Check the filter for contamination or damage.
- Using compressed air, clean the filter.
- Reinstall the filter and cap.



HINT: Install the filter with the coarser surface facing out to the atmospheric side.

2. INSTALL VACUUM GAUGE

Using a 3-way connector, connect a vacuum gauge to the hose between the EGR valve and EGR VSV.

3. INSPECT SEATING OF EGR VALVE


Check that the engine starts and runs at idle.



4. CONNECT TERMINALS TE1 AND E1

Using SST, connect terminal TE1 and E1 of the data link connector 1.

SST 09843-18020




5. INSPECT VSV OPERATION WITH COLD ENGINE

- (a) The engine coolant temperature should be below 55₂ C (113₁ F).
- (b) Check that the vacuum gauge indicates zero at 2,800 rpm.




- (c) Check that the EGR pipe is not hot.



6. INSPECT OPERATION OF VSV AND EGR VACUUM MODULATOR WITH HOT ENGINE


- (a) Warm up the engine to above 80₂ C (176° F).
- (b) Check that the vacuum gauge indicates low vacuum at 2,800 rpm.



- (c) Disconnect the vacuum hose from port R of the EGR vacuum modulator and connect port R directly to the intake manifold with another hose.

- (d) Check that the vacuum gauge indicates high vacuum at 3,500 rpm.


HINT: As exhaust gas is increasingly recirculated, the engine will start to misfire.



7. DISCONNECT TERMINALS TE1 AND E1


Remove the SST from the data link connector 1.

SST 09843-18020



8. REMOVE VACUUM GAUGE

Remove the vacuum gauge, and reconnect the vacuum hoses to their proper locations.




9. INSPECT EGR VALVE

- Apply vacuum directly to the EGR valve with the engine idle.
- Check that the engine runs rough or dies.

(c) Reconnect the vacuum hoses to their proper locations.

IF NO PROBLEM IS FOUND DURING THIS INSPECTION, SYSTEM IS NORMAL; OTHERWISE INSPECT EACH PART



VSV INSPECTION

1. REMOVE VSV

2. INSPECT VSV

A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between the terminals.

Resistance:


33 – 39 Ω at 20°C (68°F)


If there is no continuity, replace the VSV.

B. Inspect VSV for ground

Using an ohmmeter, check that there is no continuity between each terminal and the body.


If there is continuity, replace the VSV.





C. Inspect VSV operation


(a) Check that the air flows from ports E to G.



(b) Apply battery voltage across the terminals.

(c) Check that the air flows from port E to the gas filter. If operation is not as specified, replace the VSV.

3. REINSTALL VSV




EGR VACUUM MODULATOR INSPECTION

1. DISCONNECT VACUUM HOSES FROM EGR VACUUM MODULATOR


Disconnect the following vacuum hoses:

- (1) Vacuum hose from P port
- (2) Vacuum hose from Q port
- (3) Vacuum hose from R port




2. INSPECT EGR VACUUM MODULATOR OPERATION

- (a) Block ports P and R with your finger.
- (b) Blow air into port Q, and check that the air passes through to the air filter side freely.



- (c) Start the engine, and maintain speed at 3,500 rpm.
- (d) Repeat the above test. Check that there is a strong resistance to air flow.



3. RECONNECT VACUUM HOSES TO EGR VACUUM MODULATOR

Connect the following vacuum hoses:


- (1) Vacuum hose to P port
- (2) Vacuum hose to Q port
- (3) Vacuum hose to R port




EGR VALVE INSPECTION

1. REMOVE EGR PIPE

Remove the 4 nuts, EGR pipe and 2 gaskets.



2. DISCONNECT EGR GAS TEMPERATURE SENSOR CONNECTOR AND CLAMP






3. REMOVE EGR VALVE AND VACUUM MODULATOR ASSEMBLY

(a) Disconnect the following hoses: .

- (1) Vacuum hose from P port of EGR vacuum modulator
- (2) Vacuum hose from Q port of EGR vacuum modulator
- (3) Vacuum hose from R port of EGR vacuum modulator
- (4) Vacuum hose from EGR valve

(b) Remove the 3 nuts, EGR valve and vacuum modulator assembly and gasket.







4. SEPARATE EGR VALVE AND VACUUM MODULATOR

(a) Remove the nut and disconnect the EGR vacuum modulator.

(b) Disconnect the pressure hose from the EGR valve and remove the EGR vacuum modulator.




5. REMOVE EGR GAS TEMPERATURE SENSOR




6. INSPECT EGR VALVE

Check for sticking and heavy carbon deposits.
If a problem is found, replace the EGR valve.

**7. REINSTALL EGR GAS TEMPERATURE SENSOR**

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

**8. REASSEMBLE EGR VALVE AND VACUUM MODULATOR**


(a) Connect the pressure hose to the EGR valve.


(b) Install the EGR vacuum modulator with the nut.

Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)

9. REINSTALL EGR VALVE AND VACUUM MODULATOR ASSEMBLY


(a) Install the EGR valve and vacuum modulator assembly to the air intake chamber.






(b) Install and torque the 3 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)



(c) Connect the following vacuum hoses:

- (1) Vacuum hose to P port of EGR vacuum modulator
- (2) Vacuum hose to a port of EGR vacuum modulator
- (3) Vacuum hose to R port of EGR vacuum modulator
- (4) Vacuum to EGR valve



10. RECONNECT EGR GAS TEMPERATURE SENSOR CONNECTOR AND CLAMP



11. REINSTALL EGR PIPE



Install 2 new gaskets and the EGR pipe with the 4 nuts.

Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)

THREE-WAY CATALYTIC CONVERTER (TWC) SYSTEM DESCRIPTION


To reduce HC, CO and NO_x emissions, they are oxidized, reduced and converted to nitrogen (N₂), carbon dioxide (CO₂) and water (H₂O) by the three-way catalytic converter.

OPERATION



EXHAUST PIPE ASSEMBLY INSPECTION


1. CHECK CONNECTIONS FOR LOOSENESS OR DAMAGE
2. CHECK CLAMPS FOR WEAKNESS. CRACKS OR DAMAGE



THREE-WAY CATALYTIC CONVERTER INSPECTION


CHECK FOR DENTS OR DAMAGE

If any part of the protector is damaged or dented to the extent that it contacts the three-way catalytic converter, repair or replace it.



HEAT INSULATOR INSPECTION

1. CHECK HEAT INSULATOR FOR DAMAGE
2. CHECK FOR ADEQUATE CLEARANCE BETWEEN CATALYTIC CONVERTER AND HEAT INSULATOR



THREE-WAY CATALYTIC CONVERTER REPLACEMENT

1. REMOVE CONVERTER

- (a) Jack up the vehicle.
- (b) Check that the converter is cool.
- (c) Remove the 4 bolts and nuts holding the pipes to the converter.
- (d) Remove the converter and 2 gaskets.

2. REINSTALL CONVERTER

- (a) Place 2 new gaskets on the front and rear pipes.
- (b) Install the converter with the bolts and nuts. Torque the bolts and nuts.

Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)

SERVICE SPECIFICATIONS

SERVICE DATA


VSV for EGR	Resistance	at 20 ₂ C (68 ₂ F)	33 –39Ω
-------------	------------	--	---------

TORQUE SPECIFICATIONS

Part tightened	N·m	kgf·cm	ft·lbf
TVV x Cylinder head	30	305	22
EGR gas temperature x EGR valve	20	200	14
EGR vacuum modulator x EGR valve	20	200	14
EGR valve x Air intake chamber	12	120	9
EGR pipe x Air intake chamber	12	120	9
EGR pipe x EGR cooler	12	120	9
Three –way catalytic converter x Front exhaust pipe	43	440	32
Three–way catalytic converter x Center exhaust pipe	43	440	32

SFI SYSTEM

DESCRIPTION



The SFI (Sequential Multiport Fuel Injection) system is composed of 3 basic sub-systems: Fuel, Air Induction and Electronic Control Systems.

FUEL SYSTEM

Fuel is supplied under constant pressure to the SFI injectors by an electric fuel pump. The injectors inject a metered quantity of fuel into the intake manifold in accordance with signals from the ECM (Engine Control Module).

AIR INDUCTION SYSTEM

The air induction system provides sufficient air for engine operation.

ELECTRONIC CONTROL SYSTEM

The 1 MZ-FE engine is equipped with a TOYOTA Computer Controlled System (TCCS) which centrally controls the SFI, ESA, IAC, diagnosis systems etc. by means of ECM—formerly SFI computer employing a microcomputer.

The ECM controls the following functions:

1. Sequential Multiport Fuel Injection (SFI)

The ECM receives signals from various sensors indicating changing engine operation conditions such as:

- Intake air volume
- Intake air temperature (IAT)
- Engine coolant temperature (ECT)
- Engine speed (RPM)
- Acceleration/deceleration
- Exhaust oxygen content etc.

The signals are utilized by the ECM to determine the injection duration necessary for an optimum air-fuel ratio.

2. Electronic Spark Advance (ESA)

The ECM is programmed with data for optimum ignition timing under all operating conditions.

Using data provided by sensors which monitor various engine functions (RPM, ECT, etc.), the ECM triggers the spark at precisely the right instant.

3. Idle Air Control (IAC)

The ECM is programmed with target idling speed values to respond to different engine conditions (ECT, A/C (air conditioning) ON/OFF, etc.). Sensors transmit signals to the ECM which control the flow of air through the throttle valve bypass and adjust idle speed to the target value.


4. Diagnosis

The ECM detects any malfunctions and abnormalities in the sensor network and lights a malfunction indicator lamp (MIL) on the combination meter. At the same time, the trouble is identified and a diagnostic trouble code is recorded by the ECM. The diagnostic trouble codes are referred in the Engine Troubleshooting. (See page [EG2-404](#))

5. Fail-Safe Function

In the event of the sensor malfunctioning, a back-up circuit will take over to provide minimal driveability, and the malfunction indicator lamp will illuminate.


SYSTEM CIRCUIT



OPERATION

FUEL SYSTEM

EG2FW-04




Fuel is pumped up by the fuel pump, which flows through the fuel filter under pressure through the fuel pipe to the delivery pipe where it is distributed to each injector.

The fuel pressure regulator adjusts the pressure of the fuel from the fuel line (high pressure side) to a pressure 284 kPa (2.9 kgf/cm², 41 psi) higher than the pressure inside the intake manifold, and excess fuel is returned to the fuel tank through the return tube.

When the engine is hot, the fuel pressure is increased to control percolation in the fuel system and improve restartability and idling stability.

The pulsation damper absorbs the slight fluctuations in fuel pressure caused by the injector. Fuel is injected into the intake manifold according to signals from the ECM.

AIR INDUCTION SYSTEM




Air filtered through the air cleaner passes through the MAF meter and the amount flowing to the air intake chamber is determined by the throttle valve opening in the throttle body and the engine speed. The MAF meter measures the intake flow to the engine by measuring the air's cooling effect on the thermistor which is heated by the heater.

Located in the throttle body is the throttle valve, which regulates the volume of air intake to the engine. Air intake controlled by the throttle valve opening is distributed from the intake chamber to the manifold of each cylinder and is drawn into the combustion chamber.

At low air temperatures the IAC valve opens and the air flows through the IAC valve, as well as the throttle body, into the air intake chamber. During engine warm up, fast idle is accomplished by air flowing into the intake chamber via the IAC valve, even when the throttle valve is completely closed. In this way the IAC valve controls the idle speed to suit the operating conditions.

The air intake chamber prevents pulsation of the intake air, reduces the influence of the MAF meter and increases the air intake volume. It also prevents intake air interference in each cylinder. There is also the intake air control valve attached to the air intake chamber. Part of the ACIS, the ECM provides signals to the VSV to open or close. This valve opens or closes the vacuum source to the actuator, which in turn opens or closes the intake air control valve. The intake air control valve is designed to modify the effective manifold length in 2 stages for increased power in all driving ranges.

ELECTRONIC CONTROL SYSTEM



P14298

The control system consists of sensors which detect various engine conditions, and an ECM which determines the injection volume (timing) based on the signals from the sensors.









The various sensors detect the intake air volume, engine speed, oxygen density in the exhaust gas, engine coolant temperature and intake air temperature etc. and convert the information into an electrical signal which is sent to the ECM; Based on these signals, the ECM calculates the optimum ignition timing for the current conditions and operates the injectors.

The ECM not only controls the fuel injection timing, but also the self diagnostic function which records the occurrence of a malfunction, fuel volume and timing injection control, idle speed control, fuel pressure control, knock sensor control and EGR control.

PREPARATION




SST (SPECIAL SERVICE TOOLS)

80072-01

	09268-41045 Injection Measuring Tool Set	
	(09268-41080) No.6 union	
	(09268-41090) No.7 Union	
	(90405-09015) No.1 Union	
	09268-45012 EFI Fuel Pressure Gauge	
	09631 -22020 Power Steering Hose Nut 14 x 17 mm Wrench Set	Fuel line flare nut
	09842-30070 Wiring "F" EFI Inspection	
	09843-18020 Diagnosis Check Wire	

80086-01

RECOMMENDED TOOLS

	09082-00050 TOYOTA Electrical Tester Set	
	09200-00010 Engine Adjust Kit	
	09258-00030 Hose Plug Set	Plug for the vacuum hose, fuel hose etc.

EQUIPMENT


Graduated cylinder	Injector
Carburetor cleaner	Throttle body
Sound scope	Injector
Tachometer	
Torque wrench	
Vacuum gauge	
Soft brush	Throttle body

SSM (SPECIAL SERVICE MATERIALS)

08826-00080 Seal packing or equivalent	Intake air control valve
--	--------------------------

COOLANT

Item	Capacity	Classification
Engine coolant	8.7 liters (9.2 US qts, 7.7 Imp. qts)	Ethylene-glycol base



PRECAUTION

1. Before working on the fuel system, disconnect the negative (–) terminal cable from the battery.


HINT: Any diagnostic trouble code retained by the computer will be erased when the battery terminal is removed.

Therefore, if necessary, read the diagnosis before removing the battery terminal.

CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.

2. Do not smoke or work near an open flame when working on the fuel system.

3. Keep gasoline away from rubber or leather parts.



MAINTENANCE PRECAUTIONS

1. CHECK CORRECT ENGINE TUNE-UP

(See page [EG2-8](#))

2. PRECAUTIONS WHEN CONNECTING GAUGE

(a) Use the battery as the power source for the timing light, tachometer, etc.

(b) Connect the tester probe of a tachometer to the terminal IG(–) of the DLC1.

3. IN EVENT OF ENGINE MISFIRE, FOLLOWING PRECAUTIONS SHOULD BE TAKEN

(a) Check proper connection of battery terminals, etc.

(b) After repair work, check that the ignition coil terminals and all other ignition system lines are reconnected securely.

(c) When cleaning the engine compartment, be especially careful to protect the electrical system from water.

4. PRECAUTIONS WHEN HANDLING OXYGEN SENSOR

(a) Do not allow oxygen sensor to drop or hit against an object.

(b) Do not allow the sensor to come into contact with water.

IF VEHICLE IS EQUIPPED WITH MOBILE RADIO SYSTEM (HAM, CB, ETC.)

If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section.


AIR INDUCTION SYSTEM

88008-02


1. Separation of the engine oil dipstick, oil filler cap, PCV hose, etc. may cause the engine to run out of tune.
2. Disconnection, looseness or cracks in the parts of the air induction system between the throttle body and cylinder head will allow air suction and cause the engine to run out of tune.

ELECTRONIC CONTROL SYSTEM

88009-02




1. Before removing SFI wiring connectors, terminals, etc., first disconnect the power by either turning the ignition switch to LOCK or disconnecting the negative (–) terminal cable from the battery.
HINT: Always check the diagnostic trouble code before disconnecting the negative (–) terminal cable from the battery.
2. When installing the battery, be especially careful not to incorrectly connect the positive (+) and negative (–) cables.
3. Do not permit parts to receive a severe impact during removal or installation. Handle all SFI parts carefully, especially the ECM.
4. Do not be careless during troubleshooting as there are numerous transistor circuits and even slight terminal contact can cause further troubles.
5. Do not open the ECM cover.
6. When inspecting during rainy weather, take care to prevent entry of water. Also, when washing the engine compartment, prevent water from getting on the SFI parts and wiring connectors.
7. Parts should be replaced as an assembly.




8. Care is required when pulling out and inserting wiring connectors.

(a) Release the lock and pull out the connector, pulling on the connectors.




(b) Fully insert the connector and check that it is locked.



9. Use SST for inspection or test of the injector or its wiring connector.

SST 09842-30070



FUEL SYSTEM

1. When disconnecting the high fuel pressure line, a large amount of gasoline will spill out, so observe the following procedures:


- Put a container under the connection.
- Slowly loosen the connection.
- Disconnect the connection.
- Plug the connection with a rubber plug.


2. When connecting the flare nut or union bolt on the high pressure pipe union, observe the following procedures:

Union Bolt Type:

- Always use 2 new gaskets.
- Tighten the union bolt by hand.
- Tighten the union bolt to the specified torque.

Torque: 30 N·m (310 kgf·cm, 22 ft·lbf)





Flare Nut Type:

(a) Apply a light coat of engine oil to the flare nut, and tighten the flare nut by hand.

M Using SST, tighten the flare nut to specified torque.

SST 09631– 22020


NOTICE: Do not rotate the fuel pipe, when tightening the flare nut.

Torque:

28 N·m (285 kgf·cm, 21 ft·lbf) for fuel pump side

30 N·m (310 kgf·cm, 22 ft·lbf) for others

HINT: Use a torque wrench with a fulcrum length of 30 cm (111.81 in.).




3. Observe the following precautions when removing and installing the injectors.


(a) Never reuse the O-ring.

(b) When placing a new O-ring on the injector, take care not to damage it in any way.

(c) Coat a new O-ring with spindle oil or gasoline before installing— never use engine, gear or brake oil.




4. Install the injector to the delivery pipe and intake manifold as shown in the illustration.




5. Check that there are no fuel leaks after performing any maintenance on the fuel system.

(a) Using SST, connect terminals +B and FP of the DLC 1.

SST 09843–18020




(b) With engine stopped, turn the ignition switch ON.




(c) Pinch the fuel return hose.

The pressure in the high pressure line will rise to approx. 392 kPa (4 kgf/cm² 57 psi). In this state, check to see that there are no leaks from any part of the fuel system.


NOTICE: Always pinch the hose. Avoid bending as it may cause the hose to crack.



(d) Turn the ignition switch to LOCK.



(e) Remove the SST from the DLC1.
SST 09843-18020



FUEL PUMP

E8ACV-98


ON-VEHICLE INSPECTION

1. CHECK FUEL PUMP OPERATION

(a) Using SST, connect terminals +B and FP of the DLC


1.

SST 09843-18020



(b) Turn the ignition switch ON.

NOTICE: Do not start the engine.




(c) Check that there is pressure in the fuel inlet hose from the fuel filter.


HINT: If there is fuel pressure, you will hear the sound of fuel flowing.

If there is no pressure, check the following parts:


- Fusible link
- Fuses (AM2 30A, IGN 7.5A)
- EFI main relay
- Fuel pump
- ECM
- Wiring connections



(d) Turn the ignition switch to LOCK.




- (e) Remove the SST from the DLC1.
SST 09843-18020




2. CHECK FUEL PRESSURE

- (a) Check the battery voltage is above 12 V.



- (b) Disconnect the negative (–) terminal cable from the battery.


CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.



- (c) Remove the union bolt and 2 gaskets, and disconnect the fuel inlet hose from the fuel filter outlet.

CAUTION:

- Put a shop towel under the fuel filter.
- Slowly loosen the union bolt.




- (d) Install the fuel inlet hose and SST (pressure gauge) to the fuel filter outlet with 3 new gaskets and the union bolt.

SST 09268-45012


Torque: 29 N·m (300 kgf·cm, 22 ft·lbf)

- (e) Wipe off any splattered gasoline.




(f) Using SST, connect terminals +B and FP of the DLC 1.

(g) Reconnect the negative (–) terminal cable to the battery.



(h) Turn the ignition switch ON.



(i) Measure the fuel pressure.


Fuel pressure:

266 – 304 kPa (2.7 – 3.1 kgf/cm², 38 – 44 psi)

If pressure is high, replace the fuel pressure regulator.


If pressure is low, check the following parts:

- Fuel hoses and connections
- Fuel pump
- Fuel filter
- Fuel pressure regulator




(j) Remove the SST from the DLC1.

SST 09843-18020



(k) Start the engine.


(l) Disconnect the vacuum sensing hose from the fuel pressure regulator, and plug the hose end.




(m) Measure the fuel pressure at idle.

Fuel pressure:

265 – 304 kPa (2.7 – 3.1 kgf/cm², 39 – 44 psi)



(n) Reconnect the vacuum sensing hose to the fuel pressure regulator.




(o) Measure the fuel pressure at idle.

Fuel pressure:

226 – 265 kPa (2.3 – 2.7 kgf/cm², 33 – 38 psi)

If pressure is not as specified, check the vacuum sensing hose and fuel pressure regulator.



(p) Stop the engine.


(q) Check that the fuel pressure remains as specified for 5 minutes after the engine has stopped.

Fuel pressure:

147 kPa (1.5 kgf/cm², 21 psi) or more

If pressure is not as specified, check the fuel pump, pressure regulator and/or injectors.

(r) After checking fuel pressure, disconnect the negative (–) terminal cable from the battery and carefully remove the SST to prevent gasoline from splashing.
SST 09268-45012




(s) Connect the fuel inlet hose with 2 new gaskets and the union bolt.

Torque: 29 N·m (300 kgf·cm, 22 ft·lbf)

(t) Reconnect the negative (-) terminal cable to the battery.

(u) Check for fuel leakage.

(See page [EG2-228](#))




FUEL PUMP INSPECTION

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.

2. REMOVE REAR SEAT CUSHION



3. INSPECT FUEL PUMP


A. Inspect fuel pump resistance

Using an ohmmeter, measure the resistance between terminals 4 and 5.

Resistance:

0.2-3.0 at 20°C (88°F)

If the resistance is not as specified, replace the fuel pump.



B. Inspect fuel pump operation

Connect the positive (+) lead from the battery to terminal 4 of the connector, and the negative (-) lead to terminal

5. Check that the fuel pump operates.

NOTICE:

- These tests must be performed quickly (within 10 seconds) to prevent the coil burning out.
- Keep the fuel pump as far away from the battery as possible.
- Always perform switching at the battery side.


If operation is not as specified, replace the fuel pump or lead wire.

4. REINSTALL REAR SEAT CUSHION

5. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

COMPONENTS FOR REMOVAL AND INSTALLATION

EG208-01




EG208-01

FUEL PUMP REMOVAL

(See Components for Removal and Installation)


CAUTION: Do not smoke or work near an open flame when working on the fuel pump.



1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. REMOVE REAR SEAT CUSHION




3. REMOVE FLOOR SERVICE HOLE COVER

- (a) Disconnect the fuel pump connector.
- (b) Remove the 5 screws and service hole cover.

4. REMOVE FUEL PUMP LEAD WIRE


NOTICE: Do not lift the fuel pump up with the wire harness picking.



5. DISCONNECT FUEL PIPE AND HOSE FROM FUEL PUMP BRACKET


CAUTION: Remove the fuel filter cap to prevent the fuel from flowing out.

- (a) Using SST, disconnect the outlet pipe from the pump bracket.
- SST 09631- 22020
- (b) Disconnect the return hose from the pump bracket.





6. REMOVE FUEL PUMP BRACKET ASSEMBLY FROM FUEL TANK

- (a) Remove the 8 bolts.



- (b) Pull out the pump bracket assembly.
- (c) Remove the gasket from the pump bracket.

COMPONENTS FOR DISASSEMBLY AND ASSEMBLY



FUEL PUMP DISASSEMBLY


(See Components for Disassembly and Assembly)


1. REMOVE FUEL PUMP FROM FUEL PUMP BRACKET

- Remove the fuel pump lead wire.
- Pull off the lower side of the fuel pump from the pump bracket.
- Disconnect the fuel hose from the fuel pump, and remove the fuel pump.
- Remove the rubber cushion from the fuel pump.

2. REMOVE FUEL SENDER GAUGE FROM FUEL PUMP BRACKET


- Disconnect the fuel sender gauge connector.
- Remove the 2 screws and sender gauge.






3. REMOVE FUEL PUMP FILTER FROM FUEL PUMP

- (a) Using a small screwdriver, remove the clip.
- (b) Pull out the pump filter.



4. REMOVE CONNECTOR

Remove the 2 screws, connector support, connector and gasket.



FUEL PUMP ASSEMBLY


(See Components for Disassembly and Assembly)

1. INSTALL CONNECTOR

Install new gasket, the connector and connector support with the 2 screws.


2. INSTALL FUEL PUMP FILTER TO FUEL PUMP

Install the pump filter with a new clip.



3. INSTALL FUEL SENDER GAUGE TO FUEL PUMP BRACKET


- (a) Install the sender gauge with the 2 screws.
- (b) Connect the fuel sender gauge connector.



4. INSTALL FUEL PUMP TO FUEL PUMP BRACKET

- (a) Install the rubber cushion to the fuel pump.
- (b) Connect the fuel hose to the outlet port of the fuel pump.
- (c) Install the fuel pump by pushing the lower side of the fuel pump.
- (d) Install the fuel pump connector.

8898E-94



FUEL PUMP INSTALLATION

(See Components for Removal and Installation)

1. INSTALL FUEL PUMP BRACKET ASSEMBLY TO FUEL TANK



- (a) Install a new gasket to the pump bracket.
- (b) Insert the pump bracket assembly into the fuel tank.

NOTICE:

- Do not damage the fuel pump filter.
- Be careful that the arm of the sender gauge should not bent.

- (c) Install the pump bracket with the 8 screws.

Torque: 4 N·m (40 kgf·cm, 35 in.-lbf)



2. CONNECT FUEL PIPE AND HOSE TO FUEL PUMP BRACKET

- (a) Using SST, connect the outlet pipe to the pump bracket.

SST 09631- 22020

Torque: 28 N·m (285 kgf·cm, 21 ft-lbf) for use with SST

- (b) Connect the return hoses to the pump bracket.


3. CONNECT FUEL PUMP LEAD WIRE

4. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

6. CHECK FOR FUEL LEAKAGE

(See page [EG2-228](#))

Connect the fuel pump (with fuel sender gauge) connector.




6. INSTALL FLOOR SERVICE HOLE COVER

Install the service hole cover with the 5 screws.

7. INSTALL REAR SEAT CUSHION

FUEL PRESSURE REGULATOR




ON-VEHICLE INSPECTION


CHECK FUEL PRESSURE

(See page [EG2-231](#))

881AC-08

COMPONENTS FOR REMOVAL AND INSTALLATION






FUEL PRESSURE REGULATOR REMOVAL

(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY


CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.



2. DISCONNECT VACUUM SENSING HOSE FROM FUEL PRESSURE REGULATOR

3. DISCONNECT FUEL RETURN HOSE FROM FUEL PRESSURE REGULATOR


CAUTION: Put a shop rag under the pressure regulator.



4. REMOVE FUEL PRESSURE REGULATOR

(a) Remove the 2 bolts, and pull out the pressure regulator.

(b) Remove the O-ring from the pressure regulator.



FUEL PRESSURE REGULATOR INSTALLATION

(See Components for Removal and Installation)



1. INSTALL FUEL PRESSURE REGULATOR

(a) Apply a light coat of gasoline to a new O-ring, and install it to the pressure regulator.

(b) Attach the pressure regulator to the delivery pipe.


(c) Check that the pressure regulator rotates smoothly.

NOTICE: If it does not rotate smoothly, the O-ring may be pinched, so remove the pressure regulator and repeat steps (a) to (e) above.



(d) Install the pressure regulator with the 2 bolts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



2. CONNECT FUEL RETURN HOSE TO FUEL PRESSURE REGULATOR

NOTICE: Be sure insert the hose up to the stopper and clip it.



3. CONNECT VACUUM SENSING HOSE TO FUEL PRESSURE REGULATOR

4. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

5. CHECK FOR FUEL LEAKS

(See page [EC-228](#))


INJECTOR



ON-VEHICLE INSPECTION


1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.



2. REMOVE V-BANK COVER


Using a 5 mm hexagon wrench, remove the 2 cap nuts and V-bank cover.



3. INSPECT INJECTOR OPERATION


Check operation sound from each injector.

(a) With the engine running or cranking, use a sound scope to check that there is normal operating noise in proportion to engine speed.



(b) If you have no sound scope, you can check the injector operating vibration with your finger.

If no sound or unusual sound is heard, check the wiring connector, injector or injection signal from the ECM.



4. INSPECT INJECTOR RESISTANCE

(a) Disconnect the injector connector.

(b) Using an ohmmeter, measure the resistance between the terminals.

Resistance:

Approx. 13.8 at 20° C (68° F)


If the resistance is not as specified, replace the injector.

(c) Reconnect the injector connector.

5. REINSTALL V-BANK COVER


Using a 5 mm hexagon wrench, install the V-bank cover with the 2 cap nuts.

HINT: For fixing the V-bank cover, push on the cover until sense of "click" is felt.




6. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

COMPONENTS FOR REMOVAL AND INSTALLATION



N-m (kgf-cm, ft-lbf) : Specified torque

◆ Non-reusable part



INJECTORS REMOVAL

(See Components for Removal and Installation)



1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. DRAIN ENGINE COOLANT

3. DISCONNECT ACCELERATOR CABLE


4. DISCONNECT THROTTLE CABLE



6. REMOVE AIR CLEANER HOSE


(a) Disconnect the PCV hose.

(b) Loosen the 2 hose clamps, and remove the air cleaner hose.



6. REMOVE V-SANK COVER


Using a 5 mm hexagon wrench, remove the 2 cap nuts and v-bank cover.




7. REMOVE EMISSION CONTROL VALVE SET

(a) Disconnect the following vacuum hoses:

- (1) Vacuum hose from VSV for ACIS
- (2) Vacuum hose from EGR vacuum modulator
- (3) Vacuum hose from EGR valve
- (4) Vacuum hose (from cylinder head rear plate)
- (5) Vacuum hose from air intake chamber
- (6) Vacuum hose from fuel pressure regulator



- (b) Disconnect the following connectors:
- (1) VSV connector for ACIS
 - (2) VSV connector for EGR
 - (3) VSV connector for fuel pressure control




- (c) Remove the 2 nuts and emission control valve set.




8. REMOVE No.2 EGR PIPE

Remove the 4 nuts, EGR pipe and 2 gaskets.




9. DISCONNECT HYDRAULIC MOTOR PRESSURE PIPE

Remove the 2 bolts, and disconnect the pressure pipe from the water inlet and air intake chamber.




10. REMOVE AIR INTAKE CHAMBER ASSEMBLY

- (a) Disconnect the 2 PS air hoses.
- (b) Remove the bolt holding the air intake chamber stay to the air intake chamber.




(c) Disconnect the following connectors:

- (1) A/C idle-up valve connector
- (2) EGR gas temperature sensor connector
- (3) Throttle position sensor connector
- (4) IAC valve connector




(d) Disconnect the following vacuum hoses:

- (1) Vacuum hose from charcoal canister




- (2) Vacuum hose from air intake chamber
- (3) 2 vacuum hoses from throttle body



(e) Disconnect the following hoses:

- (1) 2 water bypass hoses from throttle body
- (2) Air assist hose from throttle body




(f) Disconnect the following hoses:


- (1) Brake booster vacuum hose
 - (2) PCV hose
 - (3) Actuator vacuum hose
- (g) Disconnect the DLC1.
- (h) Remove the nut and disconnect the 2 ground straps.




- (i) Remove the nut and disconnect the PS pressure tube.
- (j) Remove the bolt holding the No.1 engine hanger to the air intake chamber.
- (k) Remove the bolt, and disconnect the ground strap.



Using a 8 mm hexagon wrench, remove the 2 bolts, 2 nuts, air intake chamber assembly and gasket.




11. DISCONNECT INJECTOR CONNECTORS



12. REMOVE AIR ASSIST HOSES AND PIPE




- (a) Disconnect the air assist pipe from the bracket on the No.1 fuel pipe.
- (b) Remove the air assist hoses from the intake manifold.



13. DISCONNECT FUEL INLET AND RETURN HOSES

- (a) Disconnect the fuel return hose from the No.1 fuel pipe.
- (b) Disconnect the fuel inlet hose from the fuel filter.

CAUTION: Catch leaking fuel in a container.



14. REMOVE DELIVERY PIPES AND INJECTORS

NOTICE: Be careful not to drop the injectors when removing the delivery pipes.

- Loosen the 2 union bolts holding the No.2 fuel pipe to the delivery pipes.
- Disconnect the fuel return hose from the fuel pressure regulator.
- Remove the union bolt for the RH delivery pipe, 2 gaskets, 2 bolts, LH delivery pipe together with the 3 injectors and No.2 fuel pipe.
- Remove the union bolt for the LH delivery pipe and 2 gaskets from the No.2 fuel pipe.
- Remove the 3 bolts, RH delivery pipe together with the 3 injectors and No.1 fuel pipe.
- Remove the 4 spacers from the intake manifold.


- Pull out the 6 injectors from the delivery pipes.
- Remove the 2 O-rings and 2 grommets from each injector.

INJECTORS INSPECTION


88387-91

1. INSPECT INJECTOR INJECTION


CAUTION: Keep injector clear of sparks during the test.




P14285




- (a) Disconnect the fuel hose from the fuel filter outlet.
 (b) Connect SST (union and hose) to the fuel filter outlet with 2 new gaskets and the union bolt.
 SST 09268-41045 (90405-09015)
 HINT: Use the vehicle's fuel filter.




- (c) Remove the fuel pressure regulator.
 (d) Connect the fuel return hose, SST (hose) and SST (union) to the fuel pressure regulator.
 SST 09268-41045 (09268-41090)




- (e) Install a new O-ring to the injector.
 (f) Connect SST (union and hose) to the injector, and hold the injector and union with SST (clamp).
 SST 09268-41045
 (g) Put the injector into the graduated cylinder.
 HINT: Install a suitable vinyl hose onto the injector to prevent gasoline from splashing out.



- (h) Using SST, connect terminals +B and FP of the DLC1.
 SST 00843-18020
 (i) Reconnect the negative (-) terminal cable to the battery.



- (j) Turn the ignition switch ON.
NOTICE: Do not start the engine.



(k) Connect SST (wire) to the injector and battery for 15 seconds, and measure the injection volume with a graduated cylinder. Test each injector 2 or 3 times.
SST 09842-30070

Volume:

54 – 64 cm³ (3.3 – 3.9 cu in.) per 15 sec.

Difference between each injector:

5 cm³ (0.3 cu in.) or less

If the ignition volume is not as specified, replace the injector.


2. INSPECT LEAKAGE

(a) In the condition above, disconnect the test probes of SST (wire) from the battery and check the fuel leakage from the injector.

SST 09842-30070

Fuel drop:

1 drop or less per minute




(b) Disconnect the negative (–) terminal cable to the battery.

(c) Remove SST.

SST 09268-41045 and 09843-18020

(d) Reinstall the fuel pressure regulator to the delivery pipe. (See step 1 on pages [EG2-241](#) and 242)

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)




INJECTORS INSTALLATION

(See Components for Removal and Installation)

1. INSTALL INJECTORS AND DELIVERY PIPES


(a) Install 2 new grommets to each injector.

(b) Apply a light coat of spindle oil or gasoline to 2 new O-rings and install them to each injector.




(c) While turning the injector clockwise and counter-clockwise, push it to the delivery pipes. Install the 6 injectors.

(d) Position the injector connector outward.




(e) Place the 4 spacers in position on the intake manifold.



(f) Place the RH delivery pipe and No.1 fuel pipe together with the 3 injectors in position on the intake manifold.

(g) Temporarily install the 2 bolts holding the RH delivery pipe to the intake manifold.

(h) Temporarily install the bolt holding the No.1 fuel pipe to the intake manifold.




(i) Place the LH delivery pipe and No.2 fuel pipe together with the 3 injectors in position on the intake manifold.

(j) Connect the fuel return hose to the fuel pressure regulator.

(k) Temporarily install the 2 bolts holding the LH delivery pipe to the intake manifold.


(l) Temporarily install the No.2 fuel pipe to the LH delivery pipe with the union bolt and 2 new gaskets.



(m) Check that the injectors rotate smoothly.

HINT: If injectors do not rotate smoothly, the probable cause is incorrect installation of O-rings. Replace the O-rings.

(n) Position the injector connector outward.



(o) Tighten the 4 bolts holding the delivery pipes to the intake manifold.


Torque: 10 N-m (100 kgf-cm, 7 ft-lbf)

(p) Tighten the bolt holding the No.1 fuel pipe to the intake manifold.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)

(q) Tighten the 2 union bolts holding the No.2 fuel pipe to the delivery pipes.

Torque: 32.5 N-m (330 kgf-cm, 24 ft-lbf)




2. CONNECT FUEL INLET AND RETURN HOSES

(a) Connect the fuel inlet hose to the fuel filter with the 2 new gaskets and union bolt.

Torque: 30 N-m (300 kgf-cm, 22 ft-lbf)

(b) Connect the fuel return hose to the No.1 fuel pipe.


HINT: Pass the fuel return hose under the heater hoses.




3. INSTALL AIR ASSIST HOSES AND PIPE

(a) Connect the air assist hoses to the intake manifold.

(b) Install the air assist pipe to the bracket on the No.1 fuel pipe.




4. CONNECT INJECTOR CONNECTORS



5. INSTALL AIR INTAKE CHAMBER ASSEMBLY

(a) Using a 8 mm hexagon wrench, install a new gasket and the air intake chamber assembly with the 2 bolts and 2 nuts.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)




(b) Connect the ground strap with the bolt.


(c) Install the bolt holding the No.1 engine hanger to the air intake chamber.

Torque: 39 N-m (400 kgf-cm, 29 ft-lbf)


(d) Connect the PS pressure tube with the nut.




- (e) Connect the following hoses:
- (1) Brake booster vacuum hose
 - (2) PCV hose
 - (3) Actuator vacuum hose
- (f) Connect the DLC1.
- (g) Connect the 2 ground straps with the nut.
- Torque: 14.5 N-m (145 kgf-cm. 10 ft-lbf)**




- (h) Connect the following hoses:
- (1) 2 water bypass hoses to throttle body
 - (2) Air assist hose to throttle body




- (i) Connect the following vacuum hoses:
- (1) Vacuum hose to air intake chamber
 - (2) 2 vacuum hoses to throttle body



- (3) Vacuum hose to charcoal canister




- (j) Connect the following connectors:
- (1) A/C idle-up valve connector
 - (2) EGR gas temperature sensor connector
 - (3) Throttle position sensor connector
 - (4) IAC valve connector



(k) Install the bolt holding the air intake chamber stay to the air intake chamber.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)

(1) Connect the 2 PS air hoses.



6. CONNECT HYDRAULIC MOTOR PRESSURE PIPE

Connect the pressure pipe to the air intake chamber and water inlet with the 2 bolts.


Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



7. INSTALL NO.2 EGR PIPE

Install 2 new gaskets and the EGR pipe with the 4 nuts.


Torque: 12 N-m (120 kgf-cm, 9 ft-lbf)



8. INSTALL EMISSION CONTROL VALVE SET


(a) Install the emission control valve set with 2 bolts.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)




(b) Connect the following connectors:

- (1) VSV connector for ACIS
- (2) VSV connector for EGR
- (3) VSV connector for fuel pressure control



(c) Connect the following vacuum hoses:


- (1) Vacuum hose to VSV for ACIS
- (2) Vacuum hose to EGR vacuum modulator
- (3) Vacuum hose to EGR valve
- (4) Vacuum hose (from cylinder head rear plate)
- (5) Vacuum hose from air intake chamber
- (6) Vacuum hose to fuel pressure regulator



9. INSTALL V-BANK COVER


Using a 5 mm hexagon wrench, install the V- bank cover with the 2 cap nuts.

HINT: For fixing the V – bank cover, push on the cover until sense of "click" is felt.



10. INSTALL AIR CLEANER HOSE

- (a) Connect the air cleaner hose with the 2 hose clamps.
- (b) Connect the PCV hose.



11. CONNECT THROTTLE CABLE

12. CONNECT ACCELERATOR CABLE

13. FILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts. 7.7 Imp. qts)

14. CONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY



FUEL TANK AND LINE COMPONENTS

INDEX-33

HINT:

- Before installing the sub heated oxygen sensor, twist the sensor wire counterclockwise 3 1/2 turns.
- After installing the sub heated oxygen sensor, check that the sensor wire is not twisted. If it is twisted, remove the sub heated oxygen sensor and reinstall it.

The location of Fuel Tank Cushion



N·m(kgf·cm, ft·lbf) : Specified torque

- ◆ Non-reusable part
- For use with SST

P02029

210795




PRECAUTIONS

1. Always use new gaskets when replacing the fuel tank or component parts.
2. Apply the proper torque to all parts tightened.


FUEL LINES AND CONNECTIONS INSPECTION

- (a) Check the fuel lines for cracks or leakage, and all connections for deformation.
- (b) Check the fuel tank vapor vent system hoses and connections for looseness, sharp bends or damage.
- (c) Check the fuel tank for deformation, cracks, fuel leakage or tank band looseness.
- (d) Check the filler neck for damage or fuel leakage.
- (e) Hose and pipe connections are as shown in the illustration.


If a problem is found, repair or replace the parts as necessary.




MASS AIR FLOW (MAF) METER



COMPONENTS FOR REMOVAL AND INSTALLATION






MAF METER REMOVAL

RM09-03

(See Components for Removal and Installation)


1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.




2. REMOVE AIR CLEANER NOSE

- Disconnect the PCV hose.
- Loosen the 2 hose clamps, and remove the air cleaner hose.



3. REMOVE MAP METER

- Disconnect the MAF meter connector.
- Remove the 2 bolts and MAF meter.



RM09-01


MAF METER INSPECTION

1. INSPECT MAF METER RESISTANCE

Using an ohmmeter, measure the resistance between terminals THA and E2.

Between terminals	Resistance	Temperature
THA – E2	10–20k Ω	– 20° C (–4° F)
THA – E2	4 –7k Ω	0° C (32° F)
THA – E2	2 –3k Ω	20° C (68° F)
THA – E2	0.9 – 1.3 k Ω	40° C (104° F)
THA = E2	0.4 – 0.7 k Ω	60° C (140° F)

If the resistance is not as specified, replace the MAF meter.



2. INSPECT MAF METER OPERATION

- Connect the MAF meter connector.
 - Using a voltmeter, connect the positive (+) tester probe to terminal VG, and negative (–) tester probe to terminal E21.
 - Blow air into the MAF meter, and check that the voltage fluctuates.
- If operation is not as specified, replace the MAF meter.

- Disconnect the MAF meter connector.

MAF METER INSTALLATION



(See Components for Removal and Installation)

1. INSTALL MAF METER

- Insert the MAF meter end into the air cleaner case.
- Install the MAF meter with the 2 bolts.

Torque: 6.9 N·m (70 kgf·cm, 61 in.-lbf)

- Connect the MAF meter connector.





2. INSTALL AIR CLEANER HOSE

- Install the air cleaner hose with the 2 hose clamps.
- Connect the PCV hose.

3. CONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY


THROTTLE BODY



ON-VEHICLE INSPECTION

1. INSPECT THROTTLE BODY


(a) Check that the throttle linkage moves smoothly.



(b) Check the vacuum at each port.


- Start the engine.
- Check the vacuum with your finger.

Port name	At idle	3,000 rpm or more
P	No vacuum	Vacuum
E	No vacuum	Vacuum
R	No vacuum	Vacuum




2. INSPECT THROTTLE POSITION SENSOR

- Apply vacuum to the throttle opener.
- Disconnect the sensor connector.
- Insert a thickness gauge between the throttle stop screw and stop lever.




- Using an ohmmeter, measure the resistance between each terminal.

Clearance between fever and stop screw	Between terminals	Resistance
0 mm (0 in.)	VTA - E2	0.28 - 6.4 kΩ
0.35 mm (0.014 in.)	IDL - E2	0.5 kΩ or less
0.70 mm (0.028 in.)	IDL - E2	Infinity
Throttle valve fully open	VTA - E2	2.0 - 11.6 kΩ
—	VC - E2	2.7 - 7.7 kΩ



- Reconnect the sensor connector.



3. INSPECT THROTTLE OPENER


A. Warm up engine

Allow the engine to warm up to normal operating temperature.

B. Check idle speed


Idle speed:

700 ± 50 rpm



C. Check throttle opener setting speed

- Disconnect the vacuum hose from the throttle opener, and plug the hose end.




(b) Check the throttle opener setting speed.

Throttle opener setting speed:


900–1,950 rpm

If the throttle opener setting is not as specified, replace the throttle body.

(c) Stop the engine.




(d) Reconnect the vacuum hose to the throttle opener.




(e) Start the engine and check that the idle speed returns to the correct speed.

COMPONENTS FOR REMOVAL AND INSTALLATION

88134-06



88134-06




THROTTLE BODY REMOVAL


(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.


2. DRAIN ENGINE COOLANT
3. DISCONNECT ACCELERATOR CABLE
4. DISCONNECT THROTTLE CABLE






5. REMOVE AIR CLEANER HOSE

- (a) Disconnect the PCV hose.
- (b) Loosen the 2 hose clamps, and remove the air cleaner hose.




6. REMOVE THROTTLE BODY


- (a) Disconnect the throttle position sensor connector.
- (b) Disconnect the IAC valve connector.
- (c) Remove the hose clamp.
- (d) Disconnect the following vacuum hoses:
 - (1) Vacuum hose (from charcoal canister)
 - (2) Vacuum hose (from port R of EGR vacuum modulator)
 - (3) Vacuum hose (from port E of EGR vacuum modulator)
 - (4) Vacuum hose (from upper port of TVV)
 - (5) Vacuum hose (from lower port of TVV)



- (e) Disconnect the following hoses:
 - (1) Water bypass hose (from intake manifold)
 - (2) Water bypass hose (from water inlet housing)
 - (3) Air assist hose



- (f) Remove the 2 bolts, 2 nuts, EGR gas temperature sensor bracket, throttle body and gasket.




THROTTLE BODY INSPECTION

1. CLEAN THROTTLE BODY


- Using a soft brush and carburetor cleaner, clean the cast parts.
- Using compressed air, clean all the passages and apertures.

NOTICE: To prevent deterioration, do not clean the throttle position sensor.



2. INSPECT THROTTLE VALVE


- Apply vacuum to the throttle opener.
- Check that there is no clearance between the throttle stop screw and throttle lever when the throttle valve is fully closed.



3. INSPECT THROTTLE POSITION SENSOR


- Apply vacuum to the throttle opener.
- Insert a thickness gauge between the throttle stop screw and stop lever.
- Using an ohmmeter, measure the resistance between each terminal.


Clearance between lever and stop screw	Between terminals	Resistance
0 mm (0 in.)	VTA – E2	0.28 – 6.4 k Ω
0.35 mm (0.014 in.)	IDL – E2	0.5 k Ω or less
0.70 mm (0.028 in.)	IDL – E2	Infinity
Throttle valve fully open	VTA – E2	2.0 – 11.6 k Ω
–	VC – E2	2.7 – 7.7 k Ω



4. IF NECESSARY, ADJUST THROTTLE POSITION SENSOR

- Loosen the 2 set screws of the sensor.






(b) Apply vacuum to the throttle opener.

(c) Insert a 0.54 mm (0.021 in.) thickness gauge, between the throttle stop screw and stop lever.


(d) Connect the test probe of an ohmmeter to the terminals IDL and E2 of the sensor.

(e) Gradually turn the sensor clockwise until the ohmmeter deflects, and secure it with the 2 set screws.



(f) Recheck the continuity between terminals IDL and E2.

Clearance between lever and stop screw	Continuity (IDL – E2)
0.35 mm (0.014 in.)	Continuity
0.70 mm (0.028 in.)	No continuity




THROTTLE BODY INSTALLATION

(See Components for Removal and Installation)


1. INSTALL THROTTLE BODY

(a) Place a new gasket on the air intake chamber.




(b) Install the throttle body, EGR gas temperature sensor bracket with the 2 bolts and 2 nuts.

Torque: 19.5 N-m (200 kgf-cm, 14 ft-lbf)




(c) Connect the following hoses:

- (1) Water bypass hose (from intake manifold)
- (2) Water bypass hose (from water inlet housing)
- (3) Air assist hose




- (d) Connect the following vacuum hoses:
- (1) Vacuum hose (from charcoal canister)
 - (2) Vacuum hose (from port R of EGR vacuum modulator)
 - (3) Vacuum hose (from port R of EGR vacuum modulator)
 - (4) Vacuum hose (from upper port of TVV)
 - (5) Vacuum hose (from lower port of TVV)
- (e) Install the hose clamp.
- (f) Connect the IAC valve connector.
- (g) Connect the throttle position sensor connector.



2. INSTALL AIR CLEANER HOSE

- (a) install the air cleaner hose with the 2 hose clamps.
- (b) Connect the PCV hose.



3. CONNECT THROTTLE CABLE

4. CONNECT ACCELERATOR CABLE


5. FILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts, 7.7 Imp.qts)

6. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

IDLE AIR CONTROL (IAC) VALVE




ON-VEHICLE INSPECTION

1. INSPECT IAC VALVE OPERATION

(a) Initial conditions:

- Engine at normal operating temperature
- Idle speed set correctly
- Transmission in neutral position
- A/C switch OFF




(b) Using SST, connect terminals TE1 and E1 of the DLC 1.


SST 09843-18020

(c) After engine speed are kept at approx. 1,000 rpm for 5 seconds, check that they return to idle speed.

If the engine speed operation is not as specified, check the IAC valve, wiring and ECM.



- (d) Remove the SST from the DLC1.
SST 09843-18020



2. INSPECT IAC VALVE RESISTANCE

- (a) Disconnect the IAC valve connector.
(b) Using an ohmmeter, measure the resistance between terminal +B and other terminals (RSC, RSO).

Resistance:

19.3 – 22.3Ω at 20°C (68°F)


If resistance is not as specified, replace the IAC valve.

- (c) Reconnect the IAC valve connector.

3. INSPECT AIR ASSIST SYSTEM

- (a) Initial conditions:


- Engine at normal operating temperature
- Idle speed set correctly
- Transmission in neutral position
- A/C switch OFF



- (b) Using SST, connect terminals TE1 and E1 of the DLC 1.

SST 09843-18020

- (c) After engine speed are kept at 900 – 1,300 rpm for 10 seconds, check that they return to idle speed.




- (d) Stop the engine.

- (e) Disconnect the air assist hose from the air pipe, and block off the IAC valve exit and the entry to the pipe.

- (f) Start the engine and check that the idle speed reaches 500 rpm or below (the engine may stall).

If the idle does not reach 500 rpm or below, check for a leak between the air pipe and injector.





(g) Remove the SST from the DLC 1.

SST 09843-18020

(h) Reconnect the air assist hose to the air pipe.

COMPONENTS FOR REMOVAL AND INSTALLATION





IAC VALVE REMOVAL


(See Components for Removal and Installation)

1. REMOVE THROTTLE BODY

(See page [EG2-266](#))

2. REMOVE IAC VALVE


Remove the 4 screws, IAC valve and gasket.



IAC VALVE INSPECTION


INSPECT IAC VALVE OPERATION

(a) Connect the positive (+) lead from the battery to terminal +B and negative (-) lead to terminal RSC, and check that the valve is closed.



(b) Connect the positive (+) lead from the battery to terminal +B and negative (-) lead to terminal RSO, and check that the valve is open.

If operation is not as specified, replace the IAC valve.




IAC VALVE INSTALLATION

(See Components for Removal and Installation)

1. INSTALL IAC VALVE

(a) Place a new gasket on the throttle body.





(b) Install the IAC valve with the 4 screws.

2. INSTALL THROTTLE BODY


(See page [EG2-269](#))

ACOUSTIC CONTROL INDUCTION SYSTEM (ACIS)





ON-VEHICLE INSPECTION INSPECT INTAKE AIR CONTROL VALVE

- Using a 3-way connector, connect vacuum gauge to the actuator hose.
- Start the engine.
- While the engine is idling, check that the vacuum gauge needle does not move.



- Rapidly depress the accelerator pedal to fully open position and check that the vacuum gauge needle momentarily fluctuates up to approx. 26.7 kPa (200 mmHg, 7.9 in.Hg). (The actuator rod is pulled out.)

COMPONENTS FOR INTAKE AIR CONTROL VALVE REMOVAL AND INSTALLATION




INTAKE AIR CONTROL VALVE REMOVAL

(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.




2. DISCONNECT HOSES FROM INTAKE AIR CONTROL VALVE

(a) Disconnect the following hoses:


- (1) Brake booster vacuum hose
- (2) A/C idle-up air hose
- (3) Actuator vacuum hose

(b) Disconnect the DLC1.



3. REMOVE INTAKE AIR CONTROL VALVE


- (a) Remove the 4 nuts and DLC1 bracket, and disconnect the 2 ground straps.
- (b) Remove the intake air control valve by prying a screwdriver between the intake air control valve and air intake chamber.
- (c) Remove the gasket.



INTAKE AIR CONTROL VALVE AND COMPONENTS INSPECTION

1. INSPECT INTAKE AIR CONTROL VALVE


- (a) With 26.7 kPa (200 mmHg, 7.9 in.Hg) of vacuum applied to the actuator, check that the actuator rod moves.
 - (b) One minute after applying the vacuum in (a), check that the actuator rod does not return.
- If the operation is not as specified, replace the intake air control valve.



2. INSPECT VACUUM TANK

LOCATION: The LH side member under the battery tray.


- (a) Check that air flows from port B to port A.
- (b) Check that air does not flow from port A to port B.



- (c) Plug port B with your finger, and apply 26.7 kPa (200 mmHg, 7.9 in.Hg) of vacuum to port A, and check that there is no change in vacuum after one minute.
- If the operation is not as specified, replace the vacuum tank.

3. INSPECT VSV

(See page [EG2-293](#))




INTAKE AIR CONTROL VALVE INSTALLATION

(See Components for Removal and Installation)

1. INSTALL INTAKE AIR CONTROL VALVE

(a) Install a new gasket to the air intake chamber.




(b) Apply a light coat of engine oil to the rubber portions.

(c) Apply seal packing to the positions of the intake air control valve shown in the


Seal packing:

Part No.08826-00080 or equivalent illustration.



(d) Install the intake air control valve, DLC 1 bracket and 2 ground straps with the 4 nuts.

Torque: 14.5 N-m (145 kgf-cm, 10 ft-lbf)



2. CONNECT HOSES TO INTAKE AIR CONTROL VALVE

(a) Connect the following hoses:

(1) Brake booster vacuum hose

(2) A/C idle-up air hose


(3) Actuator vacuum hose

(b) Install the DLC1.

3. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

4. CHECK FOR FUEL LEAKAGE

(See page [EG2-228](#))




EFI MAIN RELAY

ENGINE - 02

EFI MAIN RELAY INSPECTION


1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.



2. REMOVE EFI MAIN RELAY

LOCATION: In the engine compartment relay box.




3. INSPECT EFI MAIN RELAY

A. Inspect relay continuity

(a) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

(b) Check that there is no continuity between terminals 3 and 5.

If continuity is not as specified, replace the relay.



B. Inspect relay operation

(a) Apply battery voltage across terminals 1 and 2.



(b) Using an ohmmeter, check that there is continuity between terminals 3 and 5.

If operation is not as specified, replace the relay.

4. REINSTALL EFI MAIN RELAY

5. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

CIRCUIT OPENING RELAY COMPONENTS FOR REMOVAL AND NOW INSTALLATION



CIRCUIT OPENING RELAY INSPECTION

(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch 1s turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. REMOVE CIRCUIT OPENING RELAY

3. INSPECT CIRCUIT OPENING RELAY


A. Inspect relay continuity


(a) Using an ohmmeter, check that there is continuity between terminals ST and E1.

(b) Check that there is continuity between terminals +B and FC.

(c) Check that there is no continuity between terminals +B and FP.

If continuity is not as specified, replace the relay.






**B. Inspect relay operation**

(a) Apply battery voltage across terminals ST and EI.
M Using an ohmmeter, check that there is continuity between terminals +B and FP.

If operation is not as specified, replace the relay.

4. REINSTALL CIRCUIT OPENING RELAY**5. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY**



ENGINE COOLANT TEMPERATURE (ECT) SENSOR

8180M-66

ECT SENSOR INSPECTION

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.

2. DRAIN ENGINE COOLANT

3. REMOVE ECT SENSOR

- Disconnect the ECT sensor connector.
- Using a 19 mm deep socket wrench, remove the ECT sensor and gasket.

4. INSPECT ECT SENSOR

Using an ohmmeter, measure the resistance between the terminals.

Resistance:

Refer to the graph

If the resistance is not as specified, replace the ECT sensor.

5. REINSTALL ECT SENSOR

- Install a new gasket to the ECT sensor.
- Using a 19 mm deep socket, install the ECT sensor.

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

- Connect the ECT sensor connector.


6. REFILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts, 7.7 Imp. qts)

7. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY


VSV FOR FUEL PRESSURE CONTROL




ON-VEHICLE INSPECTION

CHECK FUEL PRESSURE
(See step 2 on page [EG2-231](#))

COMPONENTS FOR REMOVAL AND INSTALLATION






VSV INSPECTION

(See Components for Removal and Installation)


1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.



2. REMOVE V-BANK COVER

Using a 5 mm hexagon wrench, remove the 2 cap nuts and V-bank cover.




3. REMOVE EMISSION CONTROL VALVE SET

(See step 7 on page [EG2-246](#))

4. REMOVE VSV

(a) Disconnect the 2 vacuum sensing hoses from the VSV.

(b) Remove the screw and VSV.



5. INSPECT VSV


A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between the terminals.

Resistance:

33 – 39 Ω at 20₂ C (68₂ F)


If there is no continuity, replace the VSV.



B. Inspect VSV for ground


Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.



C. Inspect VSV operation


(a) Check that the air flows from ports E to G.



(b) Apply battery voltage across the terminals.

(c) Check that the air flows from port E to the filter.

If operation is not as specified, replace the VSV.




6. REINSTALL EMISSION CONTROL VALVE SET

(See step 8 on page [EG2-256](#))

7. REINSTALL VSV

(a) Install the VSV with the screw.

(b) Connect the 2 vacuum sensing hoses to the VSV.




8. REINSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V-bank cover with the 2 cap nuts.

HINT: For fixing the V-bank cover, push on the cover until sense of "click" is felt.

9. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

VSV FOR EGR




ON-VEHICLE INSPECTION


EGR SYSTEM INSPECTION

(See steps 2 to 6 on pages [EG2-207](#) and 208)

COMPONENTS FOR REMOVAL AND INSTALLATION

EG2-288






VSV INSPECTION

(See Components for Removal and Installation)


1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.



2. REMOVE V-BANK COVER

Using a 5 mm hexagon wrench, remove the 2 cap nuts and V – bank cover.




3. REMOVE EMISSION CONTROL VALVE SET

(See step 7 on page [EG2-246](#))

4. REMOVE VSV

- (a) Remove the filter.
- (b) Disconnect the 2 vacuum hoses from the VSV.
- (c) Remove the screw and VSV.



5. INSPECT VSV


A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between the terminals.

Resistance:

33 – 39 at 20° C (68° F)

If there is no continuity, replace the VSV.




B. Inspect VSV for ground

Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.


-Memo


VSV FOR ACIS



ON-VEHICLE INSPECTION
INSPECT INTAKE AIR CONTROL VALVE
(See page [EG2-275](#))

COMPONENTS FOR REMOVAL AND INSTALLATION






VSV INSPECTION

(See Components for Removal and Installation)


1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (–) terminal cable is disconnected from the battery.



2. REMOVE V – BANK COVER

Using a 5 mm hexagon wrench, remove the 2 cap nuts and V-bank cover.




3. REMOVE EMISSION CONTROL VALVE SET

(See step 7 on page [EG2-246](#))

4. REMOVE VSV

- (a) Disconnect the 2 vacuum hoses from the VSV.
- (b) Remove the screw and VSV.



5. INSPECT VSV


A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between each terminals.

Resistance:

33 – 39 Ω at 20°C (68°F)


If there is no continuity, replace the VSV.



B. Inspect VSV for ground


Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.



C. Inspect VSV operation


(a) Check that air flows from pipe E to the filter.



(b) Apply battery voltage across the terminals.

(c) Check that air flows from pipe E to pipe F.

If operation is not as specified, replace the VSV.




6. REINSTALL EMISSION CONTROL VALVE SET

(See step 8 on page [EG2-256](#))

7. REINSTALL VSV

(a) Install the VSV with the screw.

(b) Connect the 2 vacuum to the VSV.




8. REINSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V – bank cover with the 2 cap nuts.

HINT: For fixing the V-bank cover, push on the cover until sense of "click" is felt.

9. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

AC IDLE-UP VALVE




ON-VEHICLE INSPECTION

INSPECT A/C IDLE-UP VALVE OPERATION

(a) Initial conditions:

- Engine at normal operating temperature
- Idle speed set correctly
- Transmission in neutral position
- A/C switch ON





(b) Using SST, connect terminals TE1 and E1 of the DLC 1, check that idle-up occurs for approx. 3 seconds.
SST 09843-18020


Valve operation is faulty if during the idle-up period the engine speed drops by 100 rpm or more, rough idle occurs, or the engine stalls.

(c) Observe the idle speed for approx. 3 to 15 seconds. During this time the idle -up valve should go off, the IAC valve half -open and idle -up should occur.


- (d) Check that the idle speed after approx. 15 seconds, does not vary greatly from the idle speed observed in step
- (c). The idle-up valve should now be in ON position.



If the idle speed is increases by more 100 rpm, using a 4 mm hexagon wrench, turn the idle-up valve adjustment screw to correct the idle-up valve.




- (e) Remove the SST from the DLC1.
SST 09843-18020
- (f) A/C switch OFF.



A/C IDLE-UP VALVE INSPECTION


1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.



2. REMOVE A/C IDLE-UP VALVE

- Disconnect the idle-up valve connector.
- Disconnect the 2 air hoses.
- Remove the 2 bolts and idle-up valve.



3. INSPECT A/C IDLE-UP VALVE


A. Inspect idle-up valve for open circuit

Using an ohmmeter, check that there is continuity between the terminals.

Resistance:

30 – 33 Ω at 20°C (68°F)


If there is no continuity, replace the idle-up valve.



B. Inspect A/C idle-up valve for ground


Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the idle-up valve.




C. Inspect A/C idle-up valve operation

- Check that the air does not flow from port E to port F.



- (b) Apply battery voltage across the terminals.
- (c) Check that the air flows from port E to port F. If operation is not as specified, replace the idle-up valve.




4. REINSTALL A/C IDLE- UP VALVE

- (a) Install the idle-up valve with the 2 bolts.
- (b) Connect the air hose.
- (c) Connect the idle-valve connector.


5. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

KNOCK SENSOR COMPONENTS FOR REMOVAL AND INSTALLATION



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part




KNOCK SENSORS INSPECTION

(See Components for Removal and Installation)

1. REMOVE AIR INTAKE CHAMBER ASSEMBLY

(See steps 1 to 10 on pages [EG2-246](#) to 249)


2. DISCONNECT INJECTOR CONNECTORS



3. REMOVE INTAKE MANIFOLD ASSEMBLY

(a) Disconnect the heater hose from the intake manifold.


(b) Remove the 9 bolts, 2 nuts, 2 plates washers and intake manifold assembly.




4. REMOVE RH ENGINE MOUNTING STAY AND WATER OUTLET

(a) Disconnect the following hoses and connectors:

- (1) Radiator inlet hose
- (2) Engine coolant reservoir hose
- (3) ECT sensor connector
- (4) ECT switch connector
- (5) Ground strap connector



(b) Remove the 3 bolts and RH mounting stay.



(c) Remove the wire band.

(d) Disconnect the water bypass hose from the inlet housing.


(e) Remove the 2 bolts, 2 nuts, 2 plate washers and water outlet.



(f) Remove the 2 gaskets.

5. REMOVE KNOCK SENSORS

- (a) Disconnect the knock sensor connector.
- (b) Remove the knock sensor.



6. INSPECT KNOCK SENSORS

Using an ohmmeter, check that there is no continuity between the terminal and body.

If there is continuity, replace the sensor.



7. REINSTALL KNOCK SENSORS


- (a) Install the knock sensor.

Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)

- (b) Connect the knock sensor connector.

8. REINSTALL WATER OUTLET AND RH ENGINE MOUNTING STAY

- (a) Install 2 new gaskets on the cylinder head.




- (b) Install the water outlet with the 2 bolts, 2 plate washers and 2 nuts.

Torque: 15 N·m (150 kgf·cm, 11 ft·lbf)


NOTICE: Do not scratch the seal surface of the water outlet with the stud bolt.

- (c) Connect the water bypass hose to the inlet housing.
- (d) Install the wire band.




- (e) Install the RH mounting stay with the 3 bolts.

Torque: 31.4 N·m (320 kgf·cm, 23 ft·lbf)



(f) Connect the following hoses and connectors:

- (1) Radiator inlet hose
- (2) Engine coolant reservoir hose
- (3) ECT sensor connector
- (4) ECT switch connector
- (5) Ground strap connector




9. REINSTALL INTAKE MANIFOLD ASSEMBLY


(a) Install the intake manifold assembly with the 9 bolts, 2 plate washers and 2 nuts.

Torque: 15 N-m (150 kgf-cm, 11 ft-lbf)

(b) Connect the heater hose to the intake manifold.



10. RECONNECT INJECTOR CONNECTORS




11. RETIGHTENING WATER OUTLET MOUNTING BOLTS AND NUTS

Torque: 15 N-m (150 kgf-cm, 11 ft-lbf)

12. REINSTALL AIR INTAKE CHAMBER ASSEMBLY

(See steps 5 to 14 on pages [EG2-254](#) to 257)



EGR GAS TEMPERATURE SENSOR

EGR GAS TEMPERATURE SENSOR INSPECTION

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY


CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.

2. REMOVE NO.2 EGR PIPE

Remove the 4 nuts, EGR pipe and 2 gaskets.



3. DISCONNECT EGR GAS TEMPERATURE SENSOR CONNECTOR AND CLAMP







4. REMOVE EGR VALVE AND VACUUM MODULATOR ASSEMBLY

(a) Disconnect the following hoses:

- (1) Vacuum hose from port P of EGR vacuum modulator
- (2) Vacuum hose from port Q of EGR vacuum modulator
- (3) Vacuum hose from port R of EGR vacuum modulator
- (4) Vacuum hose from EGR valve

(b) Remove the 3 nuts, EGR valve and vacuum modulator assembly and gasket.



**5. REMOVE EGR GAS TEMPERATURE SENSOR****6. INSPECT EGR GAS TEMPERATURE SENSOR**

Using an ohmmeter, measure the resistance between the terminals.


Resistance:

64 – 97 k at 50°C (112°F)


11 – 16 k at 100°C (212°F)

2 – 4 k at 150°C (302°F)

If the resistance is not as specified, replace the sensor.



**7. REINSTALL EGR GAS TEMPERATURE SENSOR**

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)


**8. REINSTALL EGR VALVE AND VACUUM MODULATOR ASSEMBLY**

(a) Install the EGR valve and vacuum modulator assembly with the 3 nuts.

Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)



- (b) Connect the following vacuum hoses:
- (1) Vacuum hose to port P of EGR vacuum modulator
 - (2) Vacuum hose to port Q of EGR vacuum modulator
 - (3) Vacuum hose to port R of EGR vacuum modulator
 - (4) Vacuum to EGR valve



9. RECONNECT EGR GAS TEMPERATURE SENSOR CONNECTOR AND CLAMP




10. REINSTALL N0.2 EGR PIPE

Install 2 new gaskets and the EGR pipe with the 4 nuts.

Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)

11. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY




OXYGEN SENSOR

88300-01

OXYGEN SENSORS INSPECTION


1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.



2. INSPECT HEATER RESISTANCE OF MAIN HEATED OXYGEN SENSORS

(a) Disconnect the oxygen sensor connectors.



(b) Using an ohmmeter, measure the resistance between the terminals + B and HT.

Resistance:

11 – 16Ω at 20₂ C (68₂ F)


If the resistance is not as specified, replace the sensor.

Torque: 44 N·m (450 kgf·cm, 31 ft·lbf)

(c) Reconnect the oxygen sensor connectors.


3. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

Sub Heated Oxygen Sensor COMPONENTS FOR REMOVAL AND INSTALLATION



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part




OXYGEN SENSOR INSPECTION

(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.



2. INSPECT HEATER RESISTANCE OF SUB HEATED OXYGEN SENSOR

- Remove the passenger's seat.
- Take out the consol box side of the floor carpet.
- Disconnect the oxygen sensor connector.
- Using an ohmmeter, measure the resistance between the terminals + B and HT.

Resistance:


11 – 16 at 20₂ C (68₂ F)

If the resistance is not as specified, replace the sensor.

- Reconnect the oxygen sensor connector.
- Reinstall the floor carpet.
- Reinstall the passenger's seat.

3. RECONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY

-Memo



FUEL CUT RPM

FUEL CUT OFF INSPECTION

1. REMOVE V- BANK COVER

Using a 5 mm hexagon wrench, remove the 2 cap nuts and V-bank cover.

2. WARM UP ENGINE



Allow the engine to warm up to normal operating temperature.

3. CONNECT TACHOMETER TO ENGINE

Connect the test probe of a tachometer to terminal IG (1) of the DLC1.

NOTICE:

- **NEVER** allow the tachometer terminal to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your until before use.




4. INSPECT FUEL CUT OFF PRM

- Increase the engine speed to at least 3,500 rpm.
 - Use a sound scope to check for injector operating noise.
 - Check that when the throttle lever is released, injector operation noise stops momentarily and then resumes.
- HINT: Measure with the A/C OFF.

Fuel return rpm:

1,200 rpm

5. DISCONNECT TACHOMETER



6. REINSTALL V-BANK COVER

Using a 5 mm hexagon wrench, install the V- bank cover with the 2 cap nuts.

HINT: For fixing the V- bank cover, push on the cover until sense of "click" is felt.

SERVICE SPECIFICATIONS

B980Y-02

SERVICE DATA

Fuel pressure regulator	Fuel pressure at no vacuum	285 - 304 kPa (2.7 - 3.1 kgf/cm ² , 38 - 44 psi)
Fuel pump	Resistance at 20°C (68°F)	0.2 - 3.0 Ω
Injector	Resistance	Approx. 13.8 Ω
	Injection volume	54 - 64 cm ³ (3.5 - 3.9 cu in.) per 15 sec.
	Difference between each cylinder	5 cm ³ (0.31 cu in.) or less
	Fuel leakage	1 drop or less per minute
MAF meter	Resistance (THA - E2) at -20°C (-4°F)	10 - 20 kΩ
	at 0°C (32°F)	4 - 7 kΩ
	at 20°C (68°F)	2 - 3 kΩ
	at 40°C (104°F)	0.9 - 1.3 kΩ
	at 60°C (140°F)	0.4 - 0.7 kΩ
Throttle body	Throttle body fully closed angle	10°
	Throttle opener setting speed	900 - 1,950 rpm
Throttle position sensor	Clearance between stop screw and lever	
	0 mm (0 in.) VTA - E2	0.28 - 6.4 kΩ
	0.35 mm (0.014 in.) IDL - E2	0.5 kΩ or less
	0.70 mm (0.028 in.) IDL - E2	Infinity
	Throttle valve fully open VTA - E2	2.0 - 11.6 kΩ
IAC valve	- VC - E2	2.7 - 7.7 kΩ
	Resistance +B - RSO (or RSC)	19.3 - 22.3 Ω
VSV for Fuel pressure control	Resistance at 20°C (68°F)	33 - 39 Ω
VSV for ACIS	Resistance at 20°C (68°F)	33 - 39 Ω
VSV for EGR	Resistance at 20°C (68°F)	33 - 39 Ω
A/C idle-up valve	Resistance at 20°C (68°F)	30 - 33 Ω
ECT sensor	Resistance at -20°C (-4°F)	10 - 20 kΩ
	at 0°C (32°F)	4 - 7 kΩ
	at 20°C (68°F)	2 - 3 kΩ
	at 40°C (104°F)	0.9 - 1.3 kΩ
	at 60°C (140°F)	0.4 - 0.7 kΩ
	at 80°C (176°F)	0.2 - 0.4 kΩ
EGR gas temperature sensor	Resistance at 50°C (122°F)	64 - 97 kΩ
	at 100°C (212°F)	11 - 18 kΩ
	at 150°C (302°F)	2 - 4 kΩ
Main heated oxygen sensor	Heater coil resistance at 20°C (68°F)	11 - 16 Ω
Sub heated oxygen sensor	Heater coil resistance at 20°C (68°F)	11 - 16 Ω
Fuel cut rpm	Fuel return rpm	1,200 rpm

TORQUE SPECIFICATIONS


Part tightened	N·m	kgf·cm	ft·lbf
Fuel line (Union bolt type)	29	300	22
Fuel line (Flare nut type for fuel pump side)	28	285	21
Fuel line (Flare nut type for others)	30	310	22
Fuel tank band x Body	39	400	29
Fuel pump x Fuel tank	4	40	35 in·lbf
Fuel pressure regulator x Delivery pipe	8	80	69 in·lbf
Delivery pipe x Cylinder head	10	100	7
No.1 fuel pipe x Intake manifold	19.5	200	14
No.2 fuel pipe x Delivery pipe	19.5	200	14
Air intake chamber x Intake manifold	43	440	32
EGR pipe x EGR vacuum modulator	12	120	9
EGR pipe x RH exhaust manifold	12	120	9
No. 1 engine hanger x Air intake chamber	39	400	29
Air intake chamber stay x Air intake chamber	19.5	200	14
Ground stop x Intake air control valve	14.5	145	10
Emission control valve set x Air intake chamber	8	80	69
MAF meter x Air cleaner	6.9	70	61
Throttle body x air intake chamber	19.5	200	14
Intake air control valve x Air intake chamber	14.5	145	10
ECT switch x Water outlet	20	200	14
Knock sensor x Cylinder head	39	400	29
Water outlet x Cylinder head	15	150	11
RH engine mounting stay x Water outlet	31.4	320	23
RH engine mounting stay x No.2 RH engine mounting bracket	31.4	320	23
Intake manifold x Cylinder head	15	150	11
EGR gas temperature sensor x EGR valve	20	200	14
EGR valve x Air intake chamber	12	120	9
Main heated oxygen sensor x Exhaust manifold	44	450	31
Sub heated oxygen sensor x Exhaust pipe	44	450	31


COOLING SYSTEM

DESCRIPTION

This engine utilizes a pressurized forced circulation cooling system which includes a thermostat equipped with a bypass valve mounted on the inlet side.

OPERATION





The cooling system is composed of the water jacket (inside the cylinder block and cylinder head), radiator, water pump, thermostat, electronically controlled hydraulic cooling fan, hoses and other components.

Coolant which is heated in the water jacket is pumped to the radiator, through which a cooling fan blows air to cool the coolant as it passes through. Coolant which has been cooled is then sent back to the engine by the water pump, where it cools the engine.

The water jacket is a network of channels in the shell of the cylinder block and cylinder head through which coolant passes. It is designed to provide adequate cooling of the cylinders and combustion chambers which become heated during engine operation.

RADIATOR

The radiator, mounted in the front of the vehicle, performs the function of cooling the coolant which has passed through the water jacket and become hot. The radiator consists of an upper tank and lower tank, and a core which connects the two tanks. The upper tank contains the inlet for coolant from the water jacket. The lower tank has an outlet and drain plug for the coolant. The core contains many tubes through which coolant flows from the upper tank to the lower tank as well as cooling fins which radiate heat away from the coolant in the tubes.

The air sucked through the radiator by the cooling fan, as well as the wind generated by the vehicle's travel, passes through the radiator, cooling the coolant. Models with an automatic transmission include an automatic transmission fluid cooler built into the lower tank of the radiator. A cooling fan is mounted behind the radiator to assist the flow of air through the radiator. When the coolant temperature is low, the fan operates slowly to help the engine warm up, and when the coolant temperature becomes high, the fan speed is increased to provide the air flow required for cooling.

RADIATOR CAP (on water outlet)

The radiator cap is a pressure-type cap which seals the engine coolant circuit and the resulting pressurization of the engine as the coolant expands. The pressurization prevents the coolant from boiling even when the coolant temperature exceeds 100°C (212°F). A relief valve (pressurization valve) and a vacuum valve (negative pressure valve) are built into the radiator cap. The relief valve opens and lets steam escape through the overflow pipe when the pressure generated inside the cooling system exceeds the limit (coolant temperature: 110 – 120°C (230 – 248°F), pressure: 83 – 113 kPa (0.85 – 1.15 kgf/cm², 12.1 – 16.4 psi). The vacuum valve opens to alleviate the vacuum which develops in the coolant system after the engine is stopped and the coolant temperature drops. The valve's opening allows the coolant in the reservoir tank to return to the cooling system.

RESERVOIR TANK

The reservoir tank is used to catch coolant which overflows the cooling system as a result of volumetric expansion when the coolant is heated. The coolant in the reservoir tank returns to the water outlet when the coolant temperature drops thus keeping the radiator full at all times and avoiding needless coolant loss. Check the reservoir tank level to learn if the coolant needs to be replenished.

WATER PUMP

The water pump is used for forced circulation of coolant through the cooling system. It is mounted on the front of the cylinder block and driven by a timing belt.









THERMOSTAT

The thermostat has a wax type bypass valve and is mounted in the water inlet housing. The thermostat includes a type of automatic valve operated by fluctuations in the coolant temperature. This valve closes when the coolant temperature drops, preventing the circulation of coolant through the engine and thus permitting the engine to warm up rapidly. The valve opens when the coolant temperature has risen, allowing the circulation of coolant. Wax inside the thermostat expands when heated and contracts when cooled. Heating the wax thus generates pressure which overpowers the force of the spring which keeps the valve closed, thus opening the valve. When the wax cools, its contraction allows the force of the spring to take effect once more, closing the valve. The thermostat in this engine operates at a temperature of 82°C (180°F).

ELECTRONICALLY CONTROLLED HYDRAULIC COOLING FAN (See page [EG2-346](#))




PREPARATION**SST (SPECIAL SERVICE TOOLS)**

80081-21

	09230-01010 Radiator Service Tool Set	
	09249-63010 Torque Wrench Adaptor	RH camshaft timing pulley
	09620-30010 Steering Gear Box Replacer Set	
	(09627-30010) Steering Sector Shaft Bushing Replacer	Hydraulic motor oil seal
	(09631-00020) Handle	Hydraulic motor oil seal
	09843-18020 Diagnosis Check Wire	
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	

RECOMMENDED TOOLS

80081-22

	09025-00010 Smell Torque Wrench	For measuring preload
	09082-00050 TOYOTA Electrical Tester Set	
	09905-00013 Snap Ring Pliers	

EQUIPMENT

B0001-01

Caliper gauge	
Heater	ECT sensor
Precision straight edge	
Radiator cap tester	
Micrometer	
Thermometer	ECT sensor
Torque wrench	
Vernier calipers	

LUBRICANT


B0007-02

Item	Capacity	Classification
Power steering fluid (Total) (Hydraulic cooling fan fluid)	2.2 liters (2.3 US qts, 1.9 Imp. qts)	ATF DEXRON ₂ II

COOLANT

B0008-03

Item	Capacity	Classification
Engine coolant	8.7 liters (9.2 US qts, 7.7 Imp. qts)	Ethylene–glycol base




COOLANT CHECK

1. CHECK ENGINE COOLANT LEVEL AT RESERVOIR TANK

The engine coolant level should be between the "LOW" and "FULL" lines.


If low, check for leaks and add engine coolant up to the "FULL" line.



2. CHECK ENGINE COOLANT QUALITY


(a) Remove the radiator cap from the water outlet.

CAUTION: To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.




(b) There should not be any excessive deposits of rust or scale around the radiator cap or water outlet filler hole, and the coolant should be free from oil.

If excessively dirty, clean the coolant passages and replace the coolant.



(c) Reinstall the radiator cap.




COOLANT REPLACEMENT

1. DRAIN ENGINE COOLANT

(a) Remove the radiator cap from the water outlet.

CAUTION: To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.




(b) Loosen the drain cock (for the radiator) and drain plugs (for the engine), and drain the coolant.

(c) Close the drain plugs and cock.

Torque:

7 N·m (70 kgf·cm, 61 in.-lbf) for RH drain plug

13 N·m (130 kgf·cm, 9 ft-lbf) for LH drain plug



2. FILL ENGINE COOLANT

(a) Slowly fill the system with coolant.

- Use a good brand of ethylene-glycol base coolant and mix it according to the manufacturer's directions.
- Using coolant which includes more than 50% ethylene-glycol (but not more than 70 96) is recommended.

NOTICE:



- Do not use an alcohol type coolant.
- The coolant should be mixed with demineralized water or distilled water.

Capacity:

8.7 liters (9.2 US qts. 7.7 Imp. qts)

(b) Install the radiator cap.

(c) Start the engine, and bleed the cooling system.




(d) If necessary, refill coolant into the reservoir tank up to the "FULL" line.

3. CHECK ENGINE COOLANT FOR LEAKS

WATER PUMP


COMPONENTS FOR REMOVAL AND INSTALLATION

90960-08



N·m (kgf·cm, ft·lbf) : Specified torque



◆ Non-reusable part



N·m (kgf-cm, ft-lbf) : Specified torque

◆ Non-reusable part

* For use with SST



WATER PUMP REMOVAL

(See Components for Removal and Installation)


1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. DRAIN ENGINE COOLANT


3. REMOVE TIMING BELT

(See steps 2 to 20 on pages [EG2-41](#) to 45)




4. REMOVE CAMSHAFT TIMING PULLEYS


(a) Using SST, remove the bolt and RH timing pulley.
SST 09249-63010, 09960-10010 (09962-01000)



(b) Using SST, remove the bolt and LH timing pulley.
SST 09960-01000 (09962-01000)




HINT: Arrange the camshaft timing pulleys (RH and LH sides).




5. REMOVE NO.2 IDLER PULLEY


Remove the bolt and idler pulley.

**6. DISCONNECT ENGINE WIRE**


Disconnect the 3 clamps and engine wire from the No. 3 timing belt cover.

**7. REMOVE NO.3 TIMING BELT COVER**


Remove the 6 bolts and belt cover.

**8. REMOVE WATER PUMP**

Remove the 4 bolts, 2 nuts, water pump and gasket.

**WATER PUMP INSPECTION****INSPECT WATER PUMP**

Turn the pulley and check that the water pump bearing moves smoothly and quietly.



WATER PUMP INSTALLATION


(See Components for Removal and Installation)

1. INSTALL WATER PUMP

Install a new gasket and the water pump with the 4 bolts and 2 nuts.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)

NOTICE: Do not get oil on the gasket.



2. INSTALL NO.3 TIMING BELT COVER .

(a) Check that the timing belt cover gaskets have no cracks or peeling, etc.

If the gaskets do have cracks or peeling, etc., replace them using the following steps.

(1) Using a screwdriver and gasket scraper, remove all the old gasket material.


(2) Thoroughly clean all components to remove all the loose material.

(3) Remove the backing paper from a new gasket and install the gasket evenly to the part of the belt cover shaded black in the illustration.

NOTICE: When joining gaskets, do not leave a gap between them. Cut off any excess gasket.


(4) After installing the gasket, press down on it so that the adhesive firmly sticks to the belt cover.

(b) Install new gaskets to the No.3 belt cover.




(c) Install the belt cover with the 6 bolts.

Torque: 8.5 N-m (85 kgf-cm, 74 in.-lbf)



3. CONNECT ENGINE WIRE

Connect the engine wire with the 3 clamps.




4. INSTALL NO.2 IDLER PULLEY

(a) Install the idler pulley with the bolt.

Torque: 43 N-m (440 kgf-cm, 32 ft-lbf)


(b) Check that the idler pulley moves smoothly.



5. INSTALL RH CAMSHAFT TIMING PULLEY

(a) Install the timing pulley, facing the flange side outward.

(b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.




(c) Using SST, install and torque the bolt.


SST 09249-63010, 09960-10010 (09962-01000)

Torque: 88 N-m (900 kgf-cm, 65 ft-lbf)

HINT: Use a torque wrench with a fulcrum length of 340 mm (13.39 in.)

**6. INSTALL LH CAMSHAFT TIMING PULLEY**

- (a) Install the timing pulley, facing the flange side inward.
- (b) Align the knock pin hole of the camshaft with the knock pin groove of the timing pulley as shown.



- (c) Using SST, install and torque the bolt.

SST 09960-10010 (09962-01000)

Torque: 125 N-m (1,300 kgf-cm, 94 ft-lbf)

7. INSTALL TIMING BELT

(See steps 6 to 27 on pages [EG2-51](#) to 56)

8. FILL WITH ENGINE COOLANT


Capacity:

8.7 liters (9.2 US qts, 7.7 Imp. qts)

9. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTERY**10. START ENGINE AND CHECK FOR LEAKS****11. RECHECK ENGINE COOLANT LEVEL**

THERMOSTAT COMPONENTS FOR REMOVAL AND INSTALLATION

80102-68




P13374

THERMOSTAT REMOVAL

80102-61

(See Components for Removal and Installation)


HINT: Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.



1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY


CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.

2. DRAIN ENGINE COOLANT




3. REMOVE AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE

- (a) Disconnect the volume air flow meter connector and wire clamp.
- (b) Disconnect the accelerator cable clamp.
- (c) Disconnect the PCV hose.
- (d) Loosen the air cleaner hose clamp bolt.
- (e) Disconnect the 4 air cleaner cap clips.
- (f) Remove the air cleaner cap and volume air flow meter together with the air cleaner hose.



4. DISCONNECT HEATER HOSE




5. DISCONNECT PRESSURE HOSE OF HYDRAULIC MOTOR


Remove the bolt and disconnect the pressure hose from the water inlet.

6. DISCONNECT ENGINE WIRE

Remove the 2 nuts and disconnect the engine wire from the water inlet and cylinder head.




7. DISCONNECT ENGINE COOLANT TEMPERATURE (ECT) SENSOR CONNECTOR




8. DISCONNECT WATER INLET PIPE


- (a) Remove the bolt holding the water inlet pipe to the cylinder head.
- (b) Disconnect the water inlet pipe and remove the O-ring.

**8. REMOVE WATER INLET**

Remove the 3 nuts and water inlet from the water inlet housing.

10. REMOVE THERMOSTAT AND GASKET**THERMOSTAT INSPECTION****INSPECT THERMOSTAT**

HINT: The thermostat is numbered with the valve opening temperature.




(a) Immerse the thermostat in water and gradually heat the water.

(b) Check the valve opening temperature.

Valve opening temperature:

80 – 84° C (176 – 183° F)

If the valve opening temperature is not as specified, replace the thermostat.



(c) Check the valve lift.


Valve lift:

10.0 mm (0.394 in.) or more at 95° C (203° F)

If the valve lift is not as specified, replace the thermostat.

(d) Check that the valve spring is tight when the thermostat is fully closed.

If not closed, replace the thermostat.




THERMOSTAT INSTALLATION

(See Components for Removal and Installation)


1. PLACE THERMOSTAT IN WATER PUMP

(a) Install a new gasket to the thermostat.



(b) Align the jiggle valve of the thermostat with stud bolt (A), and insert the thermostat in the water inlet housing.


HINT: The jiggle valve may be set within 30° of either side of the prescribed position.



2. INSTALL WATER INLET


Install the water inlet with the 3 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



3. INSTALL WATER INLET PIPE

(a) Install a new O – ring to the water inlet pipe.




(b) Apply soapy water to the O – ring.

(c) Connect the water inlet pipe to the water inlet.

(d) Install the bolt holding the water inlet pipe to the cylinder head.

Torque: 19.5 N·m (200 kgf·cm, 14 ft-lbf)



4. CONNECT ENGINE COOLANT TEMPERATURE SENSOR (ECT) CONNECTOR




5. CONNECT ENGINE WIRE

Connect the engine wire to the water inlet and cylinder head with the 2 nuts.


6. CONNECT HYDRAULIC MOTOR PRESSURE HOSE

Connect the pressure hose with the bolt.

Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



7. CONNECT HEATER HOSE



8. REINSTALL AIR CLEANER CAP, VOLUME AIR FLOW METER AND AIR CLEANER HOSE

(a) Connect the air cleaner hose, and install the air cleaner cap and volume air flow meter with the 4 clips.

(b) Tighten the air cleaner hose clamp bolt.

(c) Connect the PCV hose.

(d) Connect the accelerator cable clamp.

(e) Connect the volume air flow meter connector and wire clamp.

9. FILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts, 7.7 Imp. qts)

10. CONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

11. START ENGINE AND CHECK FOR LEAKS

12. RECHECK ENGINE COOLANT LEVEL

RADIATOR


B00001-01

RADIATOR CLEANING

Using water or a steam cleaner, remove any mud and dirt from the radiator core.

NOTICE: If using a high pressure type cleaner, be careful not to deform the fins of the radiator core. If the cleaner nozzle pressure is 2,942 – 3,432 kPa (30 – 35 kgf/cm², 427 – 498 psi), keep a distance of at least 40 cm (15.75 in.) between the radiator core and cleaner nozzle.

B00001-01




P12789

RADIATOR INSPECTION

1. REMOVE RADIATOR CAP FROM WATER OUTLET

CAUTION: To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.



C01242

200570

2. INSPECT RADIATOR CAP

NOTICE: When performing steps (a) and (b) below, keep the radiator pump tester at an angle of over 30° above the horizontal.

(a) Using a radiator cap tester, slowly pump the tester and check that air is coming from the relief valve.

Pump speed:

1 push/3 seconds or more

NOTICE: Push the pump at a constant speed.

If air is not coming from the relief valve, replace the radiator cap.

(b) Pump the tester several times and measure the relief valve opening pressure.

Pump speed:

1 at time

1 push/1 second or less

2nd time or more

Any speed

Standard opening pressure:


83 – 113 kPa

(0.85 – 1.15 kgf/cm², 12.1 – 16.4 psi)

Minimum opening pressure:

69 kPa (0.7 kgf/cm², 10.0 psi)


If the opening pressure is less than minimum, replace the radiator cap.



3. INSPECT COOLING SYSTEM FOR LEAKS

- (a) Fill the radiator and engine with coolant and attach a radiator cap tester.
- (b) Warm up the engine.
- (c) Pump it to 127 kPa (1.3 kgf/cm², 18.5 psi), and check that the pressure does not drop.


If the pressure drops, check the hoses, radiator or water pump for leaks. If no external leaks are found, check the heater core, cylinder block and cylinder head.



4. REINSTALL RADIATOR CAP


COMPONENTS FOR REMOVAL AND INSTALLATION

90082-04



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part




RADIATOR REMOVAL

(See Components for Removal and Installation)

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.




2. DRAIN ENGINE COOLANT

3. DISCONNECT PRESSURE HOSE


Remove the union bolt and gasket, and disconnect the pressure hose from the hydraulic motor.

NOTICE: Catch leaking oil in a container.



4. DISCONNECT UPPER RADIATOR HOSE


5. DISCONNECT HYDRAULIC MOTOR RETURN HOSE



6. DISCONNECT LOWER RADIATOR HOSE FROM WATER INLET PIPE


7. DISCONNECT OIL COOLER HOSES FROM OIL COOLER PIPES

Disconnect the 2 hoses.




8. Canada only:

REMOVE NO.7 RELAY BLOCK




9. DISCONNECT CRUISE CONTROL ACTUATOR WIRE CLAMP



10. REMOVE RADIATOR AND HYDRAULIC COOLING FAN


- (a) Remove the 2 bolts and 2 upper supports.
- (b) Lift out the radiator.



11. REMOVE A/T OIL COOLER HOSES


Remove the 2 hoses.

12. REMOVE RADIATOR LOWER HOSE



13. REMOVE HYDRAULIC COOLING FAN FROM RADIATOR



Remove the 6 bolts and cooling fan.



14. REMOVE LOWER RADIATOR SUPPORTS

Remove the 2 lower radiator supports.

COMPONENTS FOR DISASSEMBLY AND ASSEMBLY



RADIATOR DISASSEMBLY


(See Components for Disassembly and Assembly)

ASSEMBLY OF SST

09230 – 01010

- (a) Install the claw to the overhaul handle, inserting it in the hole in part "A" as shown in the diagram.
- (b) While gripping the handle, adjust the stopper bolt so that dimension "B" shown in the diagram is 0.2–0.5 mm (0.008–0.020 in.).


NOTICE: If this adjustment is not performed, the claw may be damaged.



2. UNCAULK LOCK PLATES

Using SST to release the caulking, squeeze the handle until stopped by the stopper bolt.


SST 09230 - 01010



3. REMOVE TANKS AND O-RINGS

(a) Lightly tap the bracket of the radiator (or radiator hose inlet or outlet) with a soft-faced hammer and remove the tank.

(b) Remove the O-ring.




4. REMOVE OIL COOLER FROM LOWER TANK

(a) Remove the pipes.

HINT: Make a note of the direction to face the pipes.

(b) Remove the nuts, and plate washers.

(c) Remove the oil cooler and O-rings.



RADIATOR ASSEMBLY

(See Components for Disassembly and Assembly)

1. INSTALL OIL COOLER TO LOWER TANK

(a) Clean the O-ring contact surface of the lower tank and oil cooler.

(b) Install new O-rings (1) to the oil cooler (2).

(c) Install the oil cooler with the O-rings to the lower tank (3).


(d) Install the plate washers (4), and nuts (5). Torque the nuts.


Torque: 8.3 N-m (85 kgf-cm, 74 ft-lbf)

(e) Install the pipes (6).

Torque: 14.7 N-m (150 kgf-cm, 11 ft-lbf)

HINT: Face the pipes in the same direction as before disassembly.






2. INSPECT LOCK PLATE

Inspect the lock plate for damage.

HINT:


- If the sides of the lock plate groove are deformed, reassembly of the tank will be impossible.
- Therefore, first correct any deformation with pliers or similar object. Water leakage will result if the bottom of the lock plate groove is damaged or dented. Therefore, repair or replace if necessary.



3. INSTALL NEW O-RINGS AND TANKS


(a) After checking that there are no foreign objects in the lock plate groove, install the new O-ring without twisting it.

HINT: When cleaning the lock plate groove, lightly rub it with sand paper without scratching it.



(b) Install the tank without damaging the O – ring.

(c) Tap the lock plate with a soft-faced hammer so that there is no gap between it and the tank.




4. ASSEMBLY OF SST

SST 09230 – 01010

(a) Install the punch assembly to the overhaul handle, inserting it in the hole in part "A" as shown in the illustration.





(b) While gripping the handle, adjust the stopper bolt so that dimension "B" shown in the diagram is 7.7 mm (0.30 in.).



5. CAULK LOCK PLATE

(a) Lightly press SST against the lock plate in the order shown in the illustration. After repeating this a few times, fully caulk the lock plate by squeezing the handle until stopped by the stopper plate.

SST 09230 – 01010

**HINT:**

- Do not stake the areas protruding around the pipes, brackets or tank ribs.

- The points shown in the illustration and oil cooler near here cannot be staked with the SST. Use a plier or similar object and be careful not to damage the core plates.


(b) Check the lock plate height (H) after completing the caulking.

Plate height:

7.75 – 8.25 mm (0.305 – 0.325 in.)

If not within the specified height, adjust the stopper bolt of the handle again and perform the caulking again.

6. PAINT LOCK PLATES




RADIATOR INSTALLATION

(See Components for Removal and Installation)

1. INSTALL RADIATOR SUPPORTS


Install the 2 supports.



2. INSTALL HYDRAULIC COOLING FAN TO RADIATOR

Install the cooling fan with the 6 bolts.


Torque: 4.9 N-m (50 kgf-cm, 43 in.-lbf)



3. INSTALL RADIATOR LOWER HOSE

4. INSTALL A/T OIL COOLER HOSES

Install the 2 hoses.




6. INSTALL RADIATOR AND HYDRAULIC COOLING FAN


Place the radiator in position, and install the 2 upper supports with the 2 bolts.

Torque: 12.8 N-m (130 kgf-cm, 9 ft-lbf)


HINT: After installation, check that the rubber cushion (A) of the support is not depressed.




6. CONNECT CRUISE CONTROL ACTUATOR WIRE CLAMP




**7. Canada only:
INSTALL NO.7 RELAY BLOCK**



**8. CONNECT OIL COOLER HOSES
9. CONNECT LOWER RADIATOR HOSE**



**10. CONNECT HYDRAULIC MOTOR RETURN HOSE
11. CONNECT UPPER RADIATOR HOSE**



12. CONNECT PRESSURE HOSE TO HYDRAULIC MOTOR

Connect the pressure hose with a new gasket and the union bolt.

Torque: 63.7 N·m (650 kgf·cm, 47 ft·lbf)

13. FILL WITH ENGINE COOLANT

Capacity:

8.7 liters (9.2 US qts, 7.7 Imp. qts)

14. FILL COOLING FAN (PS) RESERVOIR TANK WITH FLUID

15. CONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

16. START ENGINE AND CHECK FOR LEAKS

**17. BLEED ELECTRONICALLY CONTROLLED
HYDRAULIC COOLING FAN SYSTEM**

(See page [EG2-348](#))

**18. CHECK AUTOMATIC TRANSMISSION FLUID
LEVEL**

NOTICE: Do not overfill.


19. RECHECK ENGINE COOLANT LEVEL

ELECTRONICALLY CONTROLLED HYDRAULIC COOLING FAN SYSTEM


Description

In this system, the cooling fan ECU controls the hydraulic pressure acting on the hydraulic motor, thus controlling the speed of the cooling fan steplessly in response to the condition of the engine and air conditioning.

System Circuit




Operation



The hydraulic pump is integrated with the PS pump and is driven by a drive belt. The solenoid valve adjusts the volume of oil sent from the hydraulic pump to the hydraulic motor which drive; the fan directly, thereby controlling the fan speed.

Oil which has passed through the hydraulic motor is cooled by the oil cooler before returning to the PS pump reservoir tank.

The solenoid valve is controlled by the cooling fan ECU in accordance with the engine rpm, engine coolant temperature and A/C signals.



On-Vehicle Inspection FLUID LEVEL INSPECTION

1. KEEP VEHICLE LEVEL

2. INSPECT FLUID LEVEL

(a) Using SST, connect terminals OP1 and E1 of the data link connector 1.

SST 09843-18020



HINT: When terminals OP1 and E1 are connected, the circuit of the ECT sensor is grounded, fixing the cooling fan speed at approx. 1,100 rpm. (Fail-safe operation occurs.)

(b) Keep the engine speed at 2,000 rpm until the fluid temperature reaches the specified temperature.

Fluid temperature:

70 – 90°C (158 – 195°F)

(c) Check that there is no foaming and emulsification of the fluid in the reservoir tank.




(d) Measure the fluid level with the engine running.

(e) Stop the engine, and measure the fluid level.

(f) Subtract level (d) from (e).

Maximum level difference:

5 mm (0.20 in.)




(g) Check the fluid level.

If low, add fluid.

Fluid:


ATF DEXRON[®] II

HINT: Check that fluid level is within the "HOT" level on reservoir tank. If the fluid is cold, check that it is within the "COLD" level on the reservoir tank.



(h) Remove the SST from the data link connector 1.

SST 09843-18020



HYDRAULIC COOLING FAN SYSTEM BLEEDING

1. CHECK FLUID LEVEL IN RESERVOIR TANK

If low, add fluid.

Fluid:

ATF DEXRON®II

HINT: Check that fluid level is within the "HOT" level on reservoir tank. If the fluid is cold, check that it is within the "COLD" level on the reservoir tank.

2. BLEED COOLING SYSTEM

(a) Using SST, connect terminals OP1 and E1 of the data link connector 1.




SST 09843-18020

HINT: When terminals OP1 and E1 are connected, the circuit of the ECT sensor is grounded, fixing the cooling fan speed at approx. 1,100 rpm. (Fail-safe operation occurs.)

(b) Start the engine without depressing the accelerator pedal.


(c) Leave the engine running for several seconds.

(d) Check that there is no foaming and emulsification of the fluid in the reservoir tank.



(e) Remove the SST from the data link connector 1.


SST 09843-18020




OIL PRESSURE INSPECTION

1. DISCONNECT PRESSURE HOSE FROM HYDRAULIC MOTOR, AND INSTALL OIL PRESSURE GAUGE

(a) Remove the union bolt and gasket, and disconnect the pressure hose from the hydraulic motor.



(b) Connect the gauge side of a pressure gauge to pressure hose, and the valve side to the hydraulic motor.



2. INSPECT OIL PRESSURE

HINT: Before inspecting the oil pressure, first check that the A/C is off.

(a) Using SST, connect terminals OP1 and E1 of the data link connector 1.

SST 09843-18020

HINT: When terminals OP1 and E1 are connected, the circuit of the ECT sensor is grounded, fixing the cooling fan speed at approx. 1,100 rpm. (Fail-safe operation occurs.)

(b) Bleed the hydraulic cooling system.


(See page [EG2-348](#))


(c) Keep the engine speed at 2,000 rpm until the fluid temperature reaches the specified temperature.

Fluid temperature:

70 – 90° C (158 – 195° F)

(d) Check the fluid level is correct.






(e) Measure the oil pressure at idling.

Oil pressure:


981 – 1,961 kPa

(10 – 20 kgf/cm², 142 – 284 psi)




(f) Remove the SST from the data link connector 1.

SST 09843-18020



(g) Check that the oil pressure decreases.



3. REMOVE OIL PRESSURE GAUGE, AND RECONNECT PRESSURE HOSE TO HYDRAULIC MOTOR

(a) Remove the pressure gauge.


(b) Connect the pressure hose to the hydraulic motor with a new gasket and the union bolt.

Torque: 63.7 N·m (650 kgf·cm, 47 ft·lbf)

Hydraulic Pump (PS pump)


(See SR section)

Hydraulic Motor COMPONENTS FOR REMOVAL AND INSTALLATION



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part




HYDRAULIC MOTOR REMOVAL

(See Components for Removal and Installation)


1. REMOVE RADIATOR

(See page [EG2-336](#))




2. REMOVE HYDRAULIC COOLING FAN

Remove the 6 bolts and hydraulic cooling fan.



3. REMOVE COOLING FAN FROM HYDRAULIC MOTOR



Loosen the fan mounting nut clockwise, and remove the nut, plate washer and fan.



4. REMOVE HYDRAULIC MOTOR FROM FAN SHROUD

Remove the 3 bolts and hydraulic motor.

COMPONENTS FOR DISASSEMBLY AND ASSEMBLY



HYDRAULIC MOTOR DISASSEMBLY

(See Components for Disassembly and Assembly)

1. MOUNT MOTOR HOUSING

Carefully mount the motor housing in a vise.

NOTICE: Be careful not to damage the motor housing.


2. REMOVE MOTOR COVER


(a) Remove the 4 bolts and motor cover.

(b) Remove the O-ring from the motor housing.


3. REMOVE REAR THRUST WASHER

4. REMOVE DRIVE SHAFT






- 5. REMOVE DRIVE AND DRIVEN ROTORS
- 6. REMOVE FRONT THRUST WASHER



HYDRAULIC MOTOR INSPECTION

1. INSPECT DRIVE AND DRIVEN ROTORS

(a) Install the drive and driven rotors to the motor housing with the dot mark facing upward.



(b) Using a feeler gauge and precision straight edge, measure the side clearance between the rotor and precision straight edge.

Standard side clearance:


0.01 – 0.04 mm (0.0004 – 0.0016 in.)

Maximum side clearance:

0.05 mm (0.0020 in.)

If the clearance is greater than maximum, replace the rotors as a set. If necessary, replace the motor assembly.

HINT: When replacing the rotors, select a new rotor set according to the imprinted mark on the motor housing.



Imprinted mark on housing	Rotor set
1	16906-50010
2	16906-50020
3	16906-50030

2. INSPECT CLEARANCE OF DRIVE SHAFT

(a) Using a caliper gauge, measure the shaft hole inside diameter of the housing and cover.

Shaft hole inside diameter:

14.000 – 14.011 mm (0.5512 – 0.5516 in.)

(b) Using a micrometer, measure the drive shaft diameter.

Shaft diameter:

13.973 – 13.984 mm (0.5501 – 0.5506 in.)

(c) Subtract the drive shaft diameter measurement from the shaft hole diameter measurement.


Standard clearance:


0.016 – 0.038 mm (0.0006 – 0.0015 in.)

Maximum clearance:

0.04 mm (0.0016 in.)

If the clearance is greater than maximum, replace the shaft. If necessary, replace the motor assembly.






OIL SEAL REPLACEMENT


1. REMOVE OIL SEAL

(a) Using snap ring pliers, remove the snap ring and plate washer.



(b) Using a screwdriver, pry out the oil seal.


NOTICE: Be careful not to damage the housing.



2. INSTALL OIL SEAL

(a) Using SST and a hammer, tap in a new oil seal to a depth of 4.5 – 5.5 mm (0.177 – 0.217 in.) from the housing edge.

SST 09620-30010 (09627-30010, 09631- 00020)



(b) Using snap ring pliers, install the plate washer and snap ring.


(c) Apply fluid to the oil seal lip.

HYDRAULIC MOTOR ASSEMBLY

(See Components for Disassembly and Assembly)

HINT:

- Thoroughly clean all parts to be assembled.
- Before installing the parts, apply new fluid to all sliding and rotating surfaces.



1. MOUNT MOTOR HOUSING


Slightly mount the motor housing in a vise.

NOTICE: Be careful not to damage the motor housing.

2. INSTALL FRONT THRUST WASHER


3. INSTALL DRIVEN AND DRIVE ROTORS

Install the drive and driven rotors with the dot mark facing upward.




4. INSTALL DRIVE SHAFT

5. INSTALL REAR THRUST WASHER




6. INSTALL MOTOR COVER

(a) Install a new O-ring to the motor housing groove.



(b) Install the motor cover with the 4 bolts.

Torque: 28 N-m (290 kgf-cm, 21 ft-lbf)




7. INSPECT DRIVE SHAFT PRELOAD

- (a) Check that the drive shaft rotates smoothly without abnormal noise.
- (b) Temporarily install the pulley nut, and check the rotating torque.

Rotating torque:

0.3 N·m (3.0 kgf·cm, 2.6 in.-lbf)




HYDRAULIC MOTOR INSTALLATION

(See Components for Removal and Installation)

1. INSTALL HYDRAULIC MOTOR TO FAN SHROUD

Install the hydraulic motor with the 3 bolts.


Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)



2. INSTALL COOLING FAN TO HYDRAULIC MOTOR

Install the fan with the plate washer and nut. Tighten the nut by turning it counterclockwise.

Torque: 15 N·m (150 kgf·cm, 11 ft-lbf)



3. INSTALL HYDRAULIC COOLING FAN


Install the hydraulic cooling fan with the 6 bolts.

Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)

4. INSTALL RADIATOR

(See page [EG2-342](#))

Oil Cooler COMPONENTS FOR REMOVAL AND INSTALLATION




OIL COOLER REMOVAL

(See Components for Removal and Installation)


1. REMOVE UPPER RADIATOR SEAL


Remove the 12 clips and radiator seal.




2. REMOVE RADIATOR GRILLE

Remove the 2 mounting screws and radiator grille.




**3. REMOVE RH PARKING LIGHT ASSEMBLY**

- (a) Remove the screw.
- (b) Disconnect the connector and remove the parking light assembly.


**4. REMOVE RH HEADLIGHT ASSEMBLY**

- (a) Remove the 3 bolts and nut.
- (b) Disconnect the 2 connectors and remove the headlight assembly.


**5. DISCONNECT HOSES FROM OIL COOLER**

Disconnect the following hoses:


- (1) Outlet hose (to reservoir tank)
- (2) Inlet hose (from hydraulic motor)

6. REMOVE UNDERCOVER**7. REMOVE OIL COOLER**

- (a) Pull aside the shroud to expose the bolt in the stay. Remove the bolt.




- (b) Remove the 2 nuts and remove the oil cooler.



OIL COOLER INSPECTION

INSPECT OIL COOLER

Check the oil cooler for damage or clogging.
If necessary, replace the oil cooler.




OIL COOLER INSTALLATION

(See Components for Removal and Installation)

1. INSTALL OIL COOLER


(a) Install the oil cooler with the 2 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



(b) Install the bolt while pulling aside the shroud.


2. INSTALL UNDERCOVER



3. CONNECT HOSES TO OIL COOLER

Connect the following hoses:


- (1) Outlet hose (to reservoir)
- (2) Inlet hose (from hydraulic motor)




4. INSTALL RH HEADLIGHT ASSEMBLY

(a) Connect the 2 connectors.


(b) Install the headlight assembly with the 3 bolts and nut.

**5. INSTALL RH PARKING LIGHT ASSEMBLY**

- (a) Connect the connector.
- (b) Install the parking light assembly with the screw.

**6. INSTALL RADIATOR GRILLE**

Install the radiator grille with the 2 mounting screws.

**7. INSTALL UPPER RADIATOR SUPPORT SEAL**

Install the support seal with the 12 clips.



8. FILL PS RESERVOIR TANK WITH FLUID

(See page [EG2-347](#))

9. BLEED ELECTRONICALLY CONTROLLED HYDRAULIC COOLING FAN SYSTEM

(See page [EG2-348](#))

Cooling Fan ECU COMPONENTS FOR REMOVAL AND INSTALLATION



COOLING FAN ECU INSPECTION


80131-01

1. DISCONNECT NEGATIVE (-) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the ignition switch is turned to the 'LOCK' position and the negative (-) terminal cable is disconnected from the battery.

2. DISCONNECT COOLING FAN ECU CONNECTOR (See Components)

- Remove the instrument panel undercover.
- Remove the instrument lower panel.
- Remove the glove compartment door.
- Remove the glove compartment.
- Disconnect the cooling fan ECU connector.



3. INSPECT COOLING FAN ECU

- (a) Connect the cable to the negative (–) terminal of the battery.
- (b) Check the connector on the wiring harness side as shown in the chart.

Check for	Tester connection	Condition	Specified value
Voltage	1 – Ground	Ignition switch ON	Battery voltage
Resistance	2–3	Solenoid valve at cold (25°C (77°F))	7.6 – 8.0Ω
Continuity	4 – Ground	–	Continuity
Continuity	5 – Ground	Throttle valve open	No continuity
		Throttle valve closed	Continuity
Continuity	8 – Ground	A/C pressure SW connector disconnected	No continuity
		A/C pressure SW connector connected	Continuity
Resistance	9–10	Coolant temperature at 80°C (176°F)	1.48 – 1.58 kΩ

V00331

- (c) Disconnect the cable from the negative (–) terminal of the battery.

4. RECONNECT COOLING FAN ECU CONNECTOR

5. RECONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

ECT SENSOR INSPECTION

00304-01


INSPECT ECT SENSOR

Using an ohmmeter, measure the resistance between the terminals.

Resistance:

1.48 – 1.58 Ω at 80° C (176° F)

If the resistance is not as specified, replace the sensor.



80000-05


A/C High –Pressure Switch

A/C HIGH-PRESSURE SWITCH INSPECTION

1. DISCONNECT A/C HIGH-PRESSURE SWITCH CONNECTOR

2. INSTALL MANIFOLD GAUGE SET

(See page [AC-23](#))



3. INSPECT A/C HIGH-PRESSURE SWITCH


(a) When the A/C switch is OFF, check that there is continuity between terminals 2 and 3. (When the pressure is 1,226 kPa (12.5 kgf/cm², 178 psi) or lower.)

(b) When the A/C and blower switches are ON, check that there is no continuity between terminals 2 and 3. (When the pressure is 1,520 kPa (15.5 kgf/cm², 220 psi) or higher.)

If continuity is not as specified, replace the switch.

4. REMOVE MANIFOLD GAUGE SET

5. RECONNECT A/C HIGH-PRESSURE SWITCH CONNECTOR



80000-01

Solenoid Valve

SOLENOID VALVE INSPECTION

INSPECT SOLENOID VALVE

Using an ohmmeter, measure the resistance between the terminals

Resistance:

7.6 – 8.0Ω at 25°C (77°F)

If the resistance is not as specified, replace the solenoid valve.

SERVICE SPECIFICATIONS

SERVICE DATA


9004W-04

Thermostat	Valve opening pressure Valve lift at 95°C (203°F)	80 – 84°C (176 – 183°F) 10.0 mm (0.394 in.) or more
Radiator cap	Relief valve opening pressure (STD) Relief valve opening pressure (Limit)	83 – 113 kPa (0.85 – 1.15 kgf/cm², 12.1 – 16.4 psi) 69 kPa (0.7 kgf/cm², 10.0 psi)
Radiator	Plate height	7.75 – 8.25 mm (0.3051 – 0.3248 in.)
On-vehicle inspection for hydraulic-driven cooling motor	Oil pressure	981 – 1,961 kPa (10 – 20 kgf/cm², 142 – 284 psi)
Hydraulic motor	Rotor side clearance (STD) Rotor side clearance (Limit) Drive shaft hole inside diameter Drive shaft diameter Drive shaft oil clearance (STD) Drive shaft oil clearance (Limit) Drive shaft preload (rotating torque)	0.01 – 0.04 mm (0.0004 – 0.0016 in.) 0.05 mm (0.0020 in.) 14.000 – 14.011 mm (0.5512 – 0.5516 in.) 13.973–13.984 mm (0.5501 – 0.5506 in.) 0.016 – 0.038 mm (0.0006 – 0.0015 in.) 0.04 mm (0.0031 in.) 0.03 N·m (3.0 kgf·cm, 2.6 in.-lbf)
ECT sensor	Resistance at 80°C (176°F)	1.48 – 1.58 kΩ

TORQUE SPECIFICATIONS

9004W-04

Part tightened	N·m	kgf·cm	ft·lbf
RH Drain plug x Cylinder block	7	70	61 in.-lbf
LH Drain plug x Cylinder block	13	130	9
Water pump x Cylinder block	8	80	69 in.-lbf
No.3 timing belt cover x Cylinder head	8.5	85	74 in.-lbf
No.2 idler pulley x Cylinder heads	43	440	32
Camshaft pulley x Camshaft	125	1,300	94
Camshaft pulley x Camshaft (For use with SST)	88	900	65
Water inlet x Water inlet housing	8	80	69 in.-lbf
Water inlet pipe x LH cylinder head	19.5	200	14
Hydraulic motor pressure hose x Water inlet	8	80	69 in.-lbf
Radiator oil cooler x Radiator lower tank	8.3	85	7.4 in.-lbf
Radiator pipe x Radiator lower tank	14.7	150	11
Pressure hose x Hydraulic motor	63.7	650	47
Radiator support bolt	12.8	130	9
Hydraulic motor housing x Motor cover	28	290	21
Hydraulic motor x Fan shroud	4.9	50	43 in.-lbf
Cooling fan x Hydraulic motor	15	150	11
Hydraulic cooling fan x Radiator	4.9	50	43 in.-lbf
Oil cooler (for hydraulic cooling fan) x Radiator lower support	8	80	69 in.-lbf



A pressure feeding lubrication system has been adopted to supply oil to the moving parts of this engine. The lubrication system consists of an oil pan, oil pump, oil filter and other external parts which supply oil to the moving parts in the engine block. The oil circuit is shown in the illustration at the top of the previous page. Oil from the oil pan is pumped up by the oil pump. After it passes through the oil filter, it is fed through the various oil holes in the crankshaft and cylinder block. After passing through the cylinder block and performing its lubricating function, the oil is returned by gravity to the oil pan. A dipstick on the center left side of the cylinder block is provided to check the oil level.

OIL PUMP

The oil pump pumps up oil from the oil pan and feeds it under pressure to the various parts of the engine. An oil strainer is mounted in front of the inlet to the oil pump to remove impurities. The oil pump itself is a trochoid type pump, inside of which there is a drive rotor and a driven rotor. When the drive rotor rotates, the driven rotor rotates in the same direction, and since the axis of the drive rotor shaft is different from the center of the driven rotor, the space between the two rotors changes as they rotate. Oil is drawn in when the space is wide and is discharged when the space is narrow.

OIL PRESSURE REGULATOR (RELIEF VALVE)

At high engine speeds, the engine oil supplied by the oil pump exceeds the capacity of the engine to utilize it. For that reason, the oil pressure regulator works to prevent an oversupply of oil.

–During normal oil supply, a coil spring and valve keep the bypass closed, but when too much oil is being fed, the pressure become extremely high, overpowering the force of the spring and opening the valves. This allows the excess oil to flow through the relief valve and return to the oil pan.





OIL FILTER

The oil filter is a full flow type filter with a built-in paper filter element. Particles of metal from wear, airborne dirt, carbon and other impurities can get into the oil during use and could cause accelerated wear or seizing if allowed to circulate through the engine. The oil filter, integrated into the oil line, removes these impurities as the oil passes through it. The filter is mounted outside the engine to simplify replacement of the filter element. A relief valve is also included ahead of the filter element to relieve the high oil pressure in case the filter element becomes clogged with impurities. The relief valve opens when the oil pressure overpowers the force of the spring. Oil passing through the relief valve bypasses the oil filter and flows directly into the main oil hole in the engine.

PREPARATION


90001-02

SST (SPECIAL SERVICE TOOLS)

	09032-00100 Oil Pan Seal Cutter	No.2 oil pan
	09223-00010 Cover & Seal Replacer	Crankshaft front oil seal
	09226-07500 Oil Filter Wrench	
	09816-30010 Oil Pressure Switch Socket	

90002-02

RECOMMENDED TOOLS

	09200-00010 Engine Adjust Kit	
---	-------------------------------	--

90003-02

EQUIPMENT

Oil pressure gauge	
Precision straight edge	Oil pump
Torque wrench	


90004-02

LUBRICANT

Item	Capacity	Classification
Engine oil		
Dry fill	5.5 liters (5.8 US qts, 4.8 Imp. qts)	API grade SG or SH, Energy-Conserving II or ILSAC multigrade and recommended viscosity oil with SAE 5W-30 being the preferred engine oil
Drain and refill	4.7 liters (5.0 US qts, 4.1 Imp. qts)	
w/ Oil filter change	4.5 liters (4.8 US qts, 4.0 Imp. qts)	
w/o Oil filter change		

SSM (SPECIAL SERVICE MATERIALS)

08826-00080 Seal packing or equivalent	Oil pump No.1 oil pan No.2 oil pan
08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Oil pressure switch



OIL PRESSURE CHECK

SSM-32

1. CHECK ENGINE OIL QUALITY

Check the oil for deterioration, entry of water, discoloring or thinning.

If the quality is visibly poor, replace the oil.

Oil grade:

API grade SG or SH, Energy – Conserving II or ILSAC multigrade engine oil. Recommended viscosity is as shown in the illustration with SAE 5W-30 being the preferred engine oil.



2. CHECK ENGINE OIL LEVEL

The oil level should be between the "L" and "F" marks on the dipstick.


If low, check for leakage and add oil up to the "F" mark.

NOTICE:

- Do not fill with engine oil above the "F" mark.




- Install the oil dipstick facing the direction shown in the illustration.



3. REMOVE OIL PRESSURE SWITCH, AND INSTALL OIL PRESSURE GAUGE

- (a) Using SST, remove the oil pressure switch.
SST 09816 – 30010



(b) Install the oil pressure gauge.

4. WARM UP ENGINE

Allow the engine to warm up to normal operating temperature.

5. CHECK OIL PRESSURE


Oil pressure:

At idle speed

29 kPa (0.3 kgf/cm², 4.3 psi) or more

At 3,000 rpm

294 – 539 kPa (3.0 – 5.5 kgf/cm², 43 – 78 psi)




6. REMOVE OIL PRESSURE GAUGE AND REINSTALL OIL PRESSURE SWITCH

(a) Remove the oil pressure gauge.

(b) Apply adhesive to 2 or 3 threads of the oil pressure switch.

Adhesive:

Part No. 08833-00080, THREE BOND 1344,
LOCTITE 242 or equivalent



(c) Using SST, reinstall the oil pressure switch.

SST 09816-30010

Torque: 13 N-m (130 kgf-cm, 9 ft-lbf)


7. START ENGINE AND CHECK FOR LEAKS

OIL AND FILTER REPLACEMENT

CAUTION:


KRM-21

- Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.
- Exercise caution in order to minimize the length and frequency of contact of your skin to used oil. Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use waterless hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.
- In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.




1. DRAIN ENGINE OIL

- (a) Remove the oil filler cap.
- (b) Remove the oil drain plug, and drain the oil into a container.




2. REPLACE OIL FILTER

- (a) Using SST, remove the oil filter.
SST 09228-07500



- (b) Check and clean the oil filter installation surface.



(c) Apply clean engine oil to the gasket of a new oil filter.



(d) Lightly screw the oil filter into place, and tighten it until the gasket contacts the seat.

(e) Using SST, tighten it an additional 3/4 turn.

SST 09228-07500



3. REFILL WITH ENGINE OIL

(a) Clean and install the oil drain plug with a new gasket.

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

(b) Fill with fresh engine oil.

Oil grade:

API grade SG or SH, Energy – Conserving II or ILSAC multigrade and recommended viscosity oil, with SAE 5W-30 being the preferred engine oil.

Capacity:

Drain and refill

w/ Oil filter change

4.7 liters (5.0 US qts, 4.1 Imp. qts)

w/o Oil filter change

4.5 liters (4.8 US qts, 4.0 Imp. qts)

Dry fill

5.5 liters (5.8 US qts, 4.8 Imp. qts)

(c) Reinstall the oil filler cap.


4. START ENGINE AND CHECK FOR OIL LEAKS

5. RECHECK ENGINE OIL LEVEL

OIL PUMP


COMPONENTS FOR REMOVAL AND INSTALLATION

K385A-02




N·m (kgf·cm, ft·lbf) : Specified torque


◆ Non-reusable part



N-m (kgf-cm, ft-lbf) : Specified torque

- ◆ Non-reusable Part
- For use with SST





OIL PUMP REMOVAL

(See Components for Removal and Installation)

HINT: When repairing the oil pump, the oil pan and strainer should be removed and cleaned.

1. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY

CAUTION: Work must be started after 90 seconds from the time the Ignition switch is turned to the 'LOCK' position and the negative (–) terminal cable is disconnected from the battery.

2. DRAIN ENGINE OIL


3. REMOVE OIL DIPSTICK

4. REMOVE TIMING BELT

(See step 2 to 20 on pages [EG2-41](#) to 45)

5. REMOVE TIMING PULLEYS


(See step 21 to 24 on pages [EG2-45](#) to 47)



6. DISCONNECT ENGINE WIRE

(a) Disconnect the crankshaft position sensor connector.


(b) Disconnect the engine wire from the wire clamp.



(c) Disconnect the generator connector.


(d) Remove the nut and disconnect the generator wire.

(e) Disconnect the engine wire from the 3 clamps.




7. REMOVE No.3 TIMING BELT COVER


Remove the 6 bolts and belt cover.

**8. REMOVE GENERATOR**


Remove the 2 bolts and generator.

**9. REMOVE CRANKSHAFT POSITION SENSOR**


Remove the bolt and position sensor.

**10. REMOVE OIL HOLE COVER PLATE**


Remove the 4 bolts and cover plate.

**11. REMOVE A/C COMPRESSOR WITHOUT DISCONNECTING HOSES**


- (a) Disconnect the A/C compressor connector.
- (b) Remove the drive belt.
- (c) Remove the 5 bolts, 2 nuts and drive belt adjusting bar bracket, and disconnect the A/C compressor.
- (d) Move the compressor aside and suspend it.

**12. REMOVE A/C COMPRESSOR HOUSING BRACKET**

Remove the 3 bolts and A/C compressor housing bracket.

**13. REMOVE FRONT EXHAUST PIPE**

(a) Remove the 2 bolts and exhaust pipe clamp.



(b) Remove the 2 bolts, and disconnect the bracket.


(c) Remove the 2 bolts and 2 nuts holding the front exhaust pipe to the three-way catalytic converter.

(d) Remove the 4 nuts holding the front exhaust pipe to the exhaust manifolds.


(e) Remove the front exhaust pipe and 3 gaskets.

14. REMOVE FRONT EXHAUST PIPE STAY


Remove the 2 bolts and pipe stay.

**15. REMOVE FLYWHEEL HOUSING UNDERCOVER**


Remove the 2 bolts and undercover.

**16. REMOVE BOLTS HOLDING NO.1 OIL PAN TO TRANSAXLE**

Remove the 2 bolts.

**17. REMOVE NO.2 OIL PAN**

(a) Remove the 10 bolts and 2 nuts.




(b) Insert the blade of SST between the No. 1 and No.2 oil pans, and cut off applied sealer and remove the No. 1 oil pan.


SST 09032 – 00100

NOTICE:


- Be careful not to damage the No.2 oil pan contact surface of the No.1 oil pan.
- Be careful not to damage the No.2 oil pan flange.

**18. REMOVE OIL STRAINER**

Remove the bolt, 2 nuts, oil strainer and gasket.


**19. REMOVE NO.1 OIL PAN**

(a) Remove the 17 bolts.




(b) Using a screwdriver, remove the No. 1 oil pan by prying the portions between the cylinder block and No.1 oil pan.

NOTICE: Be careful not to damage the contact surfaces of the cylinder block and No.1 oil pan.




20. REMOVE OIL PAN BAFFLE PLATE

Remove the 6 bolts and baffle plate.



21. REMOVE OIL PUMP


(a) Remove the 9 bolts.



(b) Remove the oil pump by prying a screwdriver between the oil pump and main bearing cap.

(c) Remove the O-ring.

COMPONENTS FOR DISASSEMBLY AND ASSEMBLY




50/5A-02

OIL PUMP DISASSEMBLY


1. REMOVE RELIEF VALVE


Remove the plug, gasket, spring and relief valve.



2. REMOVE DRIVE AND DRIVEN ROTORS

Remove the 9 screws, pump body cover, drive and driven rotors.






OIL PUMP INSPECTION

1. INSPECT RELIEF VALVE

Coat the valve with engine oil and check that it falls smoothly into the valve hole by its own weight.


If it does not, replace the relief valve. If necessary, replace the oil pump assembly.



2. INSPECT DRIVE AND DRIVEN ROTORS

A. Place drive and driven rotors into oil pump body

Place the drive and driven rotors into the oil pump body with the mark facing upward.



B. Inspect rotor side clearance

Using a feeler gauge and precision straight edge, measure the clearance between the rotors and precision straight edge.


Standard side clearance:

0.030 – 0.090 mm (0.0012 – 0.0035 in.)

Maximum side clearance:

0.15 mm (0.0059 in.)

If the side clearance is greater than maximum, replace the rotors as a set. If necessary, replace the oil pump assembly.



C. Inspect rotor tip clearance

Using a feeler gauge, measure the clearance between the drive and driven rotor tips.


Standard tip clearance:

0.110 – 0.240 mm (0.0043 – 0.0094 in.)

Maximum tip clearance:

0.35 mm (0.0138 in.)

If the tip clearance is greater than maximum, replace the rotors as a set.



D. Inspect rotor body clearance

Using a feeler gauge, measure the clearance between the driven rotor and body.

Standard body clearance:

0.100 – 0.175 mm (0.0039 – 0.0069 in.)

Maximum body clearance:


0.30 mm (0.0118 in.)

If the body clearance is greater than maximum, replace the rotors as a set. If necessary, replace the oil pump assembly.

SSMC-08

CRANKSHAFT FRONT OIL SEAL REPLACEMENT


HINT: There are 2 methods (A and B) to replace the oil seal which are as follows:



REPLACE CRANKSHAFT FRONT OIL SEAL

A. If oil pump is removed from cylinder block:


(a) Using a screwdriver, pry out the oil seal.



(b) Using SST and a hammer, tap in a new oil seal until its surface is flush with the oil pump body edge.

SST 09223 – 00010

(c) Apply MP grease to the oil seal lip.



B. If oil pump is installed to the cylinder block:


(a) Using a knife, cut off the oil seal lip.

(b) Using a screwdriver, pry out the oil seal.

NOTICE: Be careful not to damage the crankshaft. Tape the screwdriver tip.



- (c) Apply MP grease to a new oil seal lip.
 - (d) Using SST and a hammer, tap in the oil seal until its surface is flush with the oil pump body edge.
- SST 09223 – 00010




OIL PUMP ASSEMBLY


(See Components for Disassembly and Assembly)

1. INSTALL DRIVE AND DRIVEN ROTORS

- (a) Place the drive and driven rotors into pump body with the marks facing the pump body cover side.



- (b) Install the pump body cover with the 9 screws.




2. INSTALL RELIEF VALVE

- (a) Insert the relief valve and spring into the pump body hole.

- (b) Install the plug with a new gasket.

Torque: 36.8 N·m (375 kgf·cm, 37 ft·lbf)



OIL PUMP INSTALLATION

(See Components for Removal and Installation)

1. INSTALL OIL PUMP

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the oil pump and cylinder block.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

(b) Apply seal packing to the oil pump as shown in the illustration.


Seal packing:

Part No. 08826-00080 or equivalent


- Install a nozzle that has been cut to a 2–3 mm (0.08–0.12 in.) opening.

HINT: Avoid applying an excessive amount to the surface.


- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.



(c) Place a new O – ring in position on the cylinder block.



(d) Engage the spline teeth of the oil pump drive gear with the large teeth of the crankshaft, and slide the oil pump on the crankshaft.




(e) Install the oil pump with the 9 bolts.

Torque:

8 N·m (80 kgf·cm, 69 in.-lbf) for 10 mm head bolt


19.5 N·m (200 kgf·cm, 14 ft.-lbf) for 12 mm head bolt



2. INSTALL OIL PAN BAFFLE PLATE

Install the baffle plate with the 6 bolts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



3. INSTALL NO.1 OIL PAN

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the oil pan, oil pump and cylinder block.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

(b) Apply seal packing to the oil pan as shown in the illustration.

Seal packing:

Part No. 08826-00080 or equivalent


Region "X" is at the outer side of the bolt hole.

Region "Y" is at the inner side of the bolt hole.

- Install a nozzle that has been cut to a 4–5 mm (0.16–0.20 in.) opening.

HINT: Avoid applying an excessive amount to the surface.

- Parts must be assembled within 3 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.




(c) Install the oil pan with the 17 bolts.

Torque:

8 N·m (80 kgf·cm, 69 in.-lbf) for 10 mm head bolt


19.5 N·m (200 kgf·cm, 14 ft.-lbf) for 12 mm head bolt



4. INSTALL OIL STRAINER

Install a new gasket and the oil strainer with the bolt and 2 nuts.

Torque: 8 N·m (80 kgf·cm, 69 in.-lbf)



5. INSTALL NO.2 OIL PAN

(a) Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surface of the No. 1 and No.2 oil pans.

- Using a razor blade and gasket scraper, remove all the old packing (FIPG) material from the gasket surfaces and sealing grooves.
- Thoroughly clean all components to remove all the loose material.
- Using a non-residue solvent, clean both sealing surfaces.

NOTICE: Do not use a solvent which will affect the painted surfaces.

(b) Apply seal packing to the No.2 oil pan as shown in the illustration.


Seal packing:

Part No. 088218-00080 or equivalent


- Install a nozzle that has been cut to a 4–5 mm (0.16 – 0.20 in.) opening.

HINT: Avoid applying an excessive amount to the surface.

- Parts must be assembled within 3 minutes an application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.




(c) Install the No.2 oil pan with the 10 bolts and 2 nuts.
Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)



6. INSTALL BOLTS HOLDING NO.1 OIL PAN TO TRANSAXLE

Install the 2 bolts.

Torque: 37 N-m (380 kgf-cm, 27 ft-lbf)



7. INSTALL FLYWHEEL HOUSING UNDERCOVER

Install the undercover with the 2 bolts.

Torque: 7.8 N-m (80 kgf-cm, 69 in.-lbf)

8. INSTALL FRONT EXHAUST PIPE STAY

Install the pipe stay with the 2 bolts.

Torque: 21 N-m (210 kgf-cm, 15 ft-lbf)

9. INSTALL FRONT EXHAUST PIPE

(a) Temporarily install 3 new gaskets and the front exhaust pipe with the 2 bolts and 6 nuts.

(b) Tighten the 4 nuts holding the exhaust manifolds to the front exhaust pipe.


Torque: 62 N-m (630 kgf-cm, 46 ft-lbf)


(c) Tighten the 2 bolts and 2 nuts holding the three-way catalytic converter to the front exhaust pipe.

Torque: 56 N-m (570 kgf-cm, 41 ft-lbf)


(d) Connect the bracket with the 2 bolts.

Torque: 19 N-m (195 kgf-cm, 14 ft-lbf)






(e) Connect the front exhaust pipe clamp with the 2 bolts.
Torque: 29 N-m (300 kgf-cm, 22 ft-lbf)




10. INSTALL A/C COMPRESSOR HOUSING BRACKET
Install the housing bracket with the 3 bolts.
Torque: 26 N-m (250 kgf-cm, 18 ft-lbf)




11. INSTALL A/C COMPRESSOR
(a) Install the A/C compressor and drive belt adjusting bar bracket with the 5 bolts.
Torque: 25 N-m (250 kgf-cm, 18 ft-lbf)



12. INSTALL OIL HOLE COVER PLATE
Install a new gasket and the hole cover plate (J mark facing outward) with the 4 bolts.
Torque: 8 N-m (80 kgf-cm, 69 in.-lbf)




13. INSTALL CRANKSHAFT POSITION SENSOR
Install the position sensor with the bolt.
Torque: 8 N-m (80 kgf-cm, 89 in.-lbf)



14. INSTALL GENERATOR

Install the generator with the 2 bolts. Do not tighten the bolts yet.



15. INSTALL NO.3 TIMING BELT COVER

(a) Check that the timing belt cover gaskets have no cracks or peeling, etc.


If the gaskets do have cracks or peeling etc., replace them using the following steps.

- (1) Using a screwdriver and gasket scraper, remove all the old gasket material.
- (2) Thoroughly clean all components to remove all the loose material.
- (3) Remove the backing paper from a new gasket and install the gasket evenly to the part of the belt cover shaded black in the illustration.

NOTICE: When joining gaskets, do not leave a gap between them. Cut off any excess gasket.


- (4) After installing the gasket, press down on it so that the adhesive firmly sticks to the belt cover.

(b) Install new gaskets to the No.3 belt cover.




(c) Install the belt cover with the 6 bolts.

Torque: 8.5 N-m (85 kgf-cm. 74 in.-lbf)



16. CONNECT ENGINE WIRE

- (a) Connect the generator connector.
- (b) Connect the generator wire with the nut.
- (c) Connect the engine wire with the 3 clamps.



(d) Connect the crankshaft position sensor connector.

(e) Connect the engine wire with the wire clamp.

17. INSTALL TIMING PULLEYS

(See steps 1 to 5 on pages [EG2-49](#), 50)

18. INSTALL TIMING BELT

(See steps 6 to 27 on pages [EG2-51](#) to 66)

19. FILL ENGINE WITH OIL

Capacity:

Drain and refill

w/ Oil filter change

4.7 liters (5.0 US qts, 4.1 Imp. qts)

w/o Oil filter change

4.5 liters (4.8 US qts, 4.0 Imp. qts)

20. CONNECT NEGATIVE (–) TERMINAL CABLE TO BATTERY

21. START ENGINE AND CHECK FOR LEAKS

22. RECHECK ENGINE OIL LEVEL

SERVICE SPECIFICATIONS

EG2-393

SERVICE DATA

Oil pressure	At idle speed (normal operating temperature) At 3,000 rpm (normal operating temperature)	29 kPa (0.3 kgf/cm ² , 43 psi) or more 294 – 539 kPa (3.0 – 5.5 kgf/cm ² , 43 – 78 psi)
Oil pump	Side clearance	STD 0.030 – 0.090 mm (0.0012 – 0.0035 in.)
		Maximum 0.15 mm (0.0059 in.)
	Body clearance	STD 0.100 – 0.175 mm (0.0039 – 0.0069 in.)
		Maximum 0.30 mm (0.0118 in.)
	Tip clearance	STD 0.110 – 0.240 mm (0.0043 – 0.0094 in.)
		Maximum 0.35 mm (0.0138 in.)

EG2-393

TORQUE SPECIFICATIONS

Pert tightened	N-m	kgf-cm	ft-lbf
Oil pressure switch x Cylinder block	13	130	9
No.2 oil pan x Drain plug	37	375	27
Oil pump x Plug (for relief valve)	36.8	375	37
Oil pump x Cylinder block (10 mm head bolt)	8	80	69 in.-lbf
Oil pump x Cylinder block (12 mm head bolt)	19.5	200	14
Oil pan baffle plate x No.1 oil pan	8	80	69 in.-lbf
No.1 idler pulley x Oil pump	34	350	25
No. 1 oil pan x Cylinder block	19.5	200	14
No. 1 oil pan x Oil pump	8	80	69 in.-lbf
No.1 oil pan x Rear oil seal retainer	8	80	69 in.-lbf
Oil strainer x Main bearing cap	8	80	69 in.-lbf
Oil strainer x Oil pump	8	80	69 in.-lbf
No.2 oil pan x No. 1 oil pan	8	80	69 in.-lbf
Flywheel housing under cover x Transaxle	8	80	69 in.-lbf
Exhaust pipe stay x No.1 oil pan	21	210	15
Exhaust pipe clamp x Exhaust pipe stay	29	300	22
A/C compressor housing bracket x Cylinder block	25	250	18
A/C compressor x A/C compressor housing bracket	25	255	18
Oil hole cover plate x No.2 oil pan	8	80	69 in.-lbf
No.1 oil pan x Transaxle case	37	380	27
Front exhaust pipe x Exhaust manifold	62	630	46
Front exhaust pipe x Converter	56	570	41
Crankshaft position sensor x Oil pump	8	80	69 in.-lbf
No.3 timing belt cover x Cylinder head	8.5	85	74 in.-lbf

1MZ-FE ENGINE TROUBLESHOOTING

HOW TO PROCEED WITH TROUBLESHOOTING

The Engine Control System broadly consists of the sensors, ECM and actuators. The ECM receives signals from various sensors, judges the operating conditions and determines the optimum injection duration, timing, ignition timing and idle speed.

In general, the Engine Control System is considered to be a very intricate system to troubleshoot. But, the fact is that if you inspect each circuit in order following the procedures in this manual, troubleshooting of this system is not complex.

When troubleshooting OBDII vehicles, use an OBDII scan tool complying with SAE J1978 or TOYOTA hand-held –tester to confirm the diagnostic trouble codes, freezed frame data and engine data.

This will enable you to determine the system causing the problem.

This section explains the best method of troubleshooting and how to carry out the necessary repairs.

(1) CUSTOMER PROBLEM ANALYSIS

Using the customer problem analysis check sheet for reference, ask the customer in detail about the problem.

(2) CONNECT OBDII SCAN TOOL OR TOYOTA HAND-HELD TESTER TO DLC 3

Connect the OBDII scan tool complying with SAE J1978 or TOYOTA hand-held tester to the vehicle's data link connector 3.

NOTICE: For OBDII scan tool or TOYOTA hand-held tester operating instructions, see the instruction booklet accompanying the scan tool or tester.

If your display shows "UNABLE" TO CONNECT TO VEHICLE" when you have connected the scan tool/TOYOTA hand-held tester cable to DLC 3, turn the ignition switch ON and operate the scan tool/TOYOTA hand-held tester, inspect DLC (See page [EG2-401](#))

(3) CHECK DIAGNOSTIC TROUBLE CODE AND FREEZED FRAME DATA (PRECHECK)

First check the diagnostic trouble codes. If a code is output, make a note of it.

Also check and note the freezed frame data.

HINT: Output of the malfunction code indicates a circuit malfunction. However, it does not indicate whether the malfunction is still occurring or occurred in the past and returned to normal. To determine this, first confirm the problem symptoms in (7) and then recheck the diagnostic trouble code in (9). If troubleshooting started based only on the malfunction code in the diagnostic trouble code check in (3), it could result in a misdiagnosis and troubleshooting of circuits which are normal, making it more difficult to locate the cause of the problem.

(4) CLEAR DIAGNOSTIC TROUBLE CODE AND FREEZED FRAME DATA

Use the OBDII scan tool or TOYOTA hand-held tester to erase the diagnostic trouble codes and freezed frame data.

NOTICE: For OBDII scan tool or TOYOTA hand-held tester operating instructions, see the instruction booklet accompanying the scan tool.

(5) VISUAL INSPECTION

(6) SETTING CHECK MODE DIAGNOSIS**(7) PROBLEM SYMPTOM CONFIRMATION**

If the engine does not start, first carry out steps (10) and (12) while referring to the diagnostic trouble codes confirmed in step (4) .

(8) SYMPTOM SIMULATION

To find the trouble more quickly, set the diagnosis check to check mode and confirm the problem symptoms with the higher sensing ability of the ECM. If the trouble does not reappear, use the symptom simulation method to make sure the trouble can be reproduced.

(9) DIAGNOSTIC TROUBLE CODE CHECK IN CHECK MODE

Check the diagnostic trouble code in check mode. If a malfunction code is output, proceed to step (11) of the Diagnostic Trouble Code Chart. If a malfunction code is not output, proceed to step (10) Basic Inspection.

(10) BASIC INSPECTION

Carry out basic inspection such as the spark check and fuel pressure check, etc.

(11) DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed, inspect the circuit indicated by the chart for each code.

(12) MATRIX CHART OF PROBLEM SYMPTOMS

If a diagnostic trouble code is not displayed in the diagnosis in check mode, troubleshoot according to the inspection order in the Matrix Chart of Problem Symptoms.

(13) CIRCUIT INSPECTION

Determine if the malfunction is in the sensor, actuator, wire harness, connector or the ECM.

(14) PARTS INSPECTION

When the Matrix Chart of Problem Symptoms instructs you to check the parts, refer to the parts inspection section in this manual.

(15) CHECK FOR INTERMITTENT PROBLEMS


By checking for intermittent problems, you can isolate the place where momentary interruptions or momentary shorts are occurring due to poor contacts.

(16) ADJUSTMENT, REPAIR

After you locate the cause of the problem, follow the inspection and replacement procedures in this manual and adjust or repair as necessary.

(17) CONFIRMATION TEST

After completing adjustment or repairs, confirm not only that the malfunction is eliminated, but also test drive the vehicle, to make sure the entire Engine Control System is operating normally.



Condition of Malfunction Indicator Lamp		<input type="checkbox"/> Remains on	<input type="checkbox"/> Sometimes lights up	<input type="checkbox"/> Does not light up
Diagnostic Trouble Code Inspection	Normal Mode (Precheck)	<input type="checkbox"/> Normal	<input type="checkbox"/> Malfunction code(s) [code] <input type="checkbox"/> Frozen frame data []	
	Check Mode	<input type="checkbox"/> Normal	<input type="checkbox"/> Malfunction code(s) [code] <input type="checkbox"/> Frozen frame data []	



DIAGNOSIS SYSTEM

DESCRIPTION

When troubleshooting OBDII vehicles, the only difference from the usual troubleshooting procedure is that you connect to the vehicle the OBDII scan tool complying with SAE J1978 or TOYOTA hand-held tester, and read off various data output from the vehicle's ECM.

OBDII regulations require that the vehicle's on-board computer lights up the Malfunction Indicator Lamp (MIL) on the instrument panel when the computer detects a malfunction in the computer itself or in drive system components which affect vehicle emissions. In addition to the MIL lighting up when a malfunction is detected, the applicable diagnostic trouble codes prescribed by SAE J2012 are recorded in the ECM memory. (See page [EG2-404](#))

If the malfunction does not reoccur in 3 trips, the MIL goes off but the diagnostic trouble codes remain recorded in the ECM memory.

To check the diagnostic trouble codes, connect the OBDII scan tool or TOYOTA hand-held tester to Data Link Connector 3 on the vehicle. The OBDII scan tool or TOYOTA hand-held tester also enables you to erase the diagnostic trouble codes and check freeze frame data and various forms of engine data. (For operating instructions, see the OBDII scan tool's instruction book.)

Diagnostic trouble codes include SAE controlled codes and Manufacturer controlled codes.

SAE controlled codes must be set as prescribed by the SAE, while Manufacturer controlled codes can be set freely by the manufacturer within the prescribed limits.

(See diagnostic trouble code chart on page [EG2-404](#))


The diagnosis system operates in normal mode during normal vehicle use. It also has a check mode for technicians to simulate malfunction symptoms and troubleshoot. Most diagnostic trouble codes use 2 trip detection logic* to prevent erroneous detection and ensure thorough malfunction detection. By switching the ECM to check mode when troubleshooting, the technician can cause the MIL to light up for a malfunction that is only detected once or momentarily. (TOYOTA hand-held tester only)

(See page [EG2-403](#))

*2 trip detection logic

When a logic malfunction is first detected, the malfunction is temporarily stored in the ECM memory. If the same malfunction is detected again during the second drive test, this second detection causes the MIL to light up.

The 2 trip repeats the same mode a 2nd time. (However, the IG switch must be turned OFF between the 1st trip and 2nd trip).



Freeze frame data:

Freeze frame data records the engine condition when a misfire (DTC P0300 – P0306) or fuel trim malfunction (DTC P0171, P0172), or other malfunction (first malfunction only), is detected.

Because freeze frame data records the engine conditions (fuel system, calculator load, engine coolant temperature, fuel trim, engine speed, vehicle speed, etc.) when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.

Priorities for Troubleshooting:

If troubleshooting priorities for multiple diagnostic codes are given in the applicable diagnostic chart, these should be followed.

If no instructions are given, troubleshoot diagnostic trouble codes according to the following priorities.


(1) Diagnostic trouble codes other than fuel trim malfunction (DTC P0171, P0172) and EGR (DTC P0401, P0402) and misfire (DTC P0300 – P0306).

(2) Fuel trim malfunction (DTC P0171, P0172) and EGR (DTC P0401, P0402)

(3) Misfire (DTC P0300 – P0306).

DATA LINK CONNECTOR 3 INSPECTION

The vehicle's ECM uses V.P.W. (Variable Pulse Width) for communication to comply with SAE J1850. The terminal arrangement of DLC 3 complies with SAE J1962 and matches the V. P.W. format.




Terminal No.	Connection	Voltage or Resistance	Condition
2	Bus (+) Line	Pulse generation	During transmission
4	Chassis Ground	↔ Body Ground 1 Ω or less	Always
5	Signal Ground	↔ Body Ground 1 Ω or less	Always
16	Battery Positive	↔ Body Ground 9 – 14 V	Always

HINT: If your display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the cable of the OBDII scan tool or TOYOTA hand-held tester to DLC 3, turned the ignition switch ON and operated the scan tool, there is a problem on the vehicle side or tool side.

1) If communication is normal when the tool is connected to another vehicle, inspect DLC 3 on the original vehicle.

2) If communication is still not possible when the tool is connected to another vehicle, the problem is probably in the tool itself, so consult the Service Department listed in the tool's instruction manual.



Diagnosis Inspection (Normal Mode) MALFUNCTION INDICATOR LAMP CHECK

1. The malfunction indicator lamp comes on when the ignition switch is turned ON and the engine is not running.


HINT: If the malfunction indicator lamp does not light up, troubleshoot the combination meter.

(See page [BE-64](#)).

2. When the engine is started, the malfunction indicator lamp should go off. If the lamp remains on, the diagnosis system has detected a malfunction or abnormality in the system.

DIAGNOSTIC TROUBLE CODE CHECK

NOTICE (TOYOTA hand-held tester only): When the diagnosis system is switched from normal mode to check mode, it erases all diagnostic trouble codes and frozen frame data recorded in normal mode. So before switching modes, always check the diagnostic trouble codes and frozen frame data, and note them down.



1. Prepare the OBDII scan tool (complying with SAE J1978) or TOYOTA hand-held tester.

2. Connect the OBDII scan tool or TOYOTA hand-held tester to data link connector 3 in the fuse box at the lower left of the instrument panel.

3. Turn the ignition switch ON and turn the OBDII scan tool or TOYOTA hand-held tester switch ON.

4. Use the OBDII scan tool or TOYOTA hand-held tester to check the diagnostic trouble codes and frozen frame data, note them down. (For operating instructions, see the OBDII scan tool's instruction book.)

5. See page [EG2-404](#) to confirm the details of the diagnostic trouble codes.



NOTICE: When simulating symptoms with an OBDII scan tool (excluding TOYOTA hand-held tester) to check the diagnostic trouble codes, use normal mode. For codes on the diagnostic trouble code chart subject to "2 trip detection logic", turn the ignition switch OFF after the symptom is simulated the first time. Then repeat the simulation process again. When the problem has been simulated twice, the MIL lights up and the diagnostic trouble codes are recorded in the ECM.

Diagnosis Inspection (Check Mode)

TOYOTA HAND-HELD TESTER only

Compared to the normal mode, the check mode has an increased sensitivity to detect malfunctions.

Furthermore, the same diagnostic items which are detected in the normal mode can also be detected in the check mode.




DIAGNOSTIC TROUBLE CODE CHECK

1. Initial conditions.
 - (a) Battery positive voltage 11 V or more.
 - (b) Throttle valve fully closed.
 - (c) Transmission in park or neutral position.
 - (d) Air conditioning switched OFF.
2. Turn ignition switch OFF.
3. Prepare the TOYOTA hand-held tester.
4. Connect the TOYOTA hand-held tester to data link connector 3 in the fuse box at the lower left of the instrument panel.
5. Turn the ignition switch ON and switch the TOYOTA hand-held tester ON.
6. Switch the TOYOTA hand-held tester normal mode to check mode. (Check that the MIL flashes.)
7. Start the engine. (The MIL goes out after the engine start.)
8. Simulate the conditions of the malfunction described by the customer.

NOTICE: Leave the ignition switch ON until you have checked the diagnostic trouble codes, etc.

9. After simulating the malfunction conditions, use the TOYOTA hand-held tester diagnosis selector to check the diagnostic trouble codes and freeze frame data, etc.

HINT: Take care not to turn the ignition switch OFF. Turning the ignition switch OFF switches the diagnosis system from check mode to normal mode, so all diagnostic codes, etc. are erased.
10. After checking the diagnostic trouble code, inspect the applicable circuit.



DIAGNOSTIC TROUBLE CODE CLEARANCE

The following actions will erase the diagnostic trouble codes and freeze frame data.

1. Operating the OBDII scan tool (complying with SAE J1978) or TOYOTA hand-held tester to erase the codes. (See the OBDII scan tool's instruction book for operating instructions.)
2. Disconnecting the battery terminals or EFI fuse.

NOTICE: If the TOYOTA hand-held tester switches the ECM from normal mode to check mode or vice-versa, or if the ignition switch is turned from ON to ACC or OFF during check mode, the diagnostic trouble codes and freeze frame data will be erased.

DIAGNOSTIC TROUBLE CODE CHART (SAE Controlled)

HINT: Parameters listed in the chart may not be exactly the same as your reading due to the type of instrument or other factors.

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P0100	Mass Air Flow Circuit Malfunction	Open or short in mass air flow meter circuit with engine speed 4,000 rpm or less.
P0101	Mass Air Flow Circuit Range/ Performance Problem	Conditions a) and b) continue with engine speed 900 rpm or less. (2 trip detection logic) a) Closed throttle position switch: ON b) Mass air flow meter output) ≥ 2.2 V
P0110	Intake Air Temp. Circuit Malfunction	Open or short in intake air temp. sensor circuit.
P0115	Engine Coolant Temp. Circuit Malfunction	Open or short in engine coolant temp. sensor circuit.
P0116	Engine Coolant Temp. Circuit Range/ Performance Problem	20 min. or more after starting engine, engine coolant temp. sensor value is 30°C (86°F) or less. (2 trip detection logic)
P0120	Throttle Position Circuit Malfunction	Condition a) or b) continues. a) VTA \leq (0.1 V, and closed throttle position switch is OFF. b) VTA) ≥ 4.9 V
P0121	Throttle Position Circuit Range/ Performance Problem	When closed throttle position switch is ON, condition a) continues. (2 trip detection logic) a) VTA) ≥ 2.0 V
P0125	Insufficient Coolant Temp. for Closed Loop Fuel Control	After the engine is warmed up, heated oxygen sensor output does not indicate RICH even once when conditions a) and b) continue for at least 2 minutes. a) Engine speed: 1,500 rpm or more b) Vehicle speed: 40 km/h (25 mph) or more
P01 30	Heated Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 1)	Voltage output of heated oxygen sensor remains at 0.4 V or more, or 0.55 V or less, during idling after the engine is warmed up. (2 trip detection logic)
P0133	Heated Oxygen Sensor Circuit Slow Response (Bank 1 Sensor 1)	Response time for the heated oxygen sensor's voltage output to change from rich to lean, or from lean to rich, is 1 sec. or more during idling after the engine is warmed up. (2 trip detection logic)

If a malfunction code is displayed during the diagnostic trouble code check in check mode, check the circuit for that code listed in the table below (Proceed to the page given for that circuit).

Trouble Area	MIL	Memory	See Page
<ul style="list-style-type: none"> • Open or short in mass air flow meter circuit. • Mass air flow meter • ECM 	○	○	EG2-444
<ul style="list-style-type: none"> • Mass air flow meter 	○	○	EG2-450
<ul style="list-style-type: none"> • Open or short in intake air temp. sensor circuit. • Intake air temp. sensor • ECM 	○	○	EG2-451
<ul style="list-style-type: none"> • Open or short in engine coolant temp. sensor circuit. • Engine coolant temp. sensor • ECM 	○	○	EG2-457
<ul style="list-style-type: none"> • Engine coolant temp. sensor • Coolant system 	○	○	EG2-462
<ul style="list-style-type: none"> • Open or short in throttle position sensor circuit. • Throttle position sensor. • ECM 	○	○	EG2-463
<ul style="list-style-type: none"> • Throttle position sensor 	○	○	EG2-472
<ul style="list-style-type: none"> • Open or short in heated oxygen sensor circuit. • Heated oxygen sensor. 	○	○	EG2-473
<ul style="list-style-type: none"> • Heated oxygen sensor • Fuel trim malfunction 	○	○	EG2-476
<ul style="list-style-type: none"> • Heated oxygen sensor 	○	○	EG2-480

DIAGNOSTIC TROUBLE CODE CHART (Cont'd)

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P0135	Heated Oxygen Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)	When the heater operates, heater current exceeds 2 A or voltage drop for the heater circuit exceeds 5 V. (2 trip detection logic)
		Heater current of 0.25 A or less when the heater operates. (2 trip detection logic)
P0136	Heated Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 2)	Voltage output of the heated oxygen sensor (bank1 sensor 2) remains at 0.4 V or more or 0.5 V or less when the vehicle is driven at 50 km/h (31 mph) or more after the engine is warmed up. (2 trip detection logic)
P0141	Heated Oxygen Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)	Same as DTC No. P01 35.
P0150	Heated Oxygen Sensor Circuit Malfunction (Bank 2 Sensor 1)	Same as DTC No. P01 30.
P0153	Heated Oxygen Sensor Circuit Slow Response (Bank 2 Sensor 1)	Same as DTC No. P01 33.
P0155	Heated Oxygen Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)	Same as DTC No. P01 35.
P0171	System too Lean (Fuel Trim)	When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the RICH side. (2 trip detection logic)
P0172	System too Rich (Fuel Trim)	When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the LEAN side. (2 trip detection logic)
P0201 P0202 P0203 P0204 P0205 P0206	Injector Circuit Malfunction – Cylinder 1 – Cylinder 2 – Cylinder 3 – Cylinder 4 – Cylinder 5 – Cylinder 6	A specified cylinder misfire continuously. (2 trip detection logic)

Trouble Area	MIL	Memory	See Page
<ul style="list-style-type: none"> Open or short in heater circuit of heated oxygen sensor. Heated oxygen sensor heater ECM 	○	○	EG2-481
<ul style="list-style-type: none"> Heated oxygen sensor 	○	○	EG2-484
<ul style="list-style-type: none"> Same as DTC No. P01 35. 	○	○	EG2-481
<ul style="list-style-type: none"> Same as DTC No. P01 30. 	○	○	EG2-476
<ul style="list-style-type: none"> Same as DTC No. P01 33. 	○	○	EG2-480
<ul style="list-style-type: none"> Same as DTC No. P01 35. 	○	○	EG2-481
<ul style="list-style-type: none"> Air intake (hose loose) Fuel line pressure Injector blockage Heated oxygen sensor malfunction Mass air flow meter Engine coolant temp. sensor 	○	○	EG2-486
<ul style="list-style-type: none"> Fuel line pressure Injector leak, blockage Heated oxygen sensor malfunction Mass air flow meter Engine coolant temp. sensor 	○	○	EG2-486
<ul style="list-style-type: none"> Open or short in injector circuit Injector blockage, seized Ignition system Valve clearance not to specification Compression pressure 	○	○	EG2-491

DIAGNOSTIC TROUBLE CODE CHART (Cont'd)

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P0300	Random Misfire Detected	Misfiring of multiple cylinders is detected during the same 200 or 1,000 revolutions.
P0301 P0302 P0303 P0304 P0305 P0306	Misfire Detected – Cylinder 1 – Cylinder 2 – Cylinder 3 – Cylinder 4 – Cylinder 5 – Cylinder 6	For each 200 revolutions of the engine, misfiring is detected which can cause catalyst overheating. (This causes MIL to blink.) For each 1,000 revolutions of the engine, misfiring is detected which causes emissions deterioration. (2 trip detection logic)
P0325	Knock Sensor 1 Circuit Malfunction	No knock sensor 1 signal to ECM with engine speed 2,000 rpm or more.
P0330	Knock Sensor 2 Circuit Malfunction	No knock sensor 2 signal to ECM with engine speed 2,000 rpm or more.
P0335	Crankshaft Position Sensor Circuit Malfunction	No crankshaft position sensor signal to ECM during cranking. (2 trip detection logic)
		No crankshaft position sensor signal to ECM during engine running.
P0336	Crankshaft Position Sensor Circuit Range/ Performance	Deviation in crankshaft position sensor signal and camshaft position sensor signal. (2 trip detection logic)
P0340	Camshaft Position Sensor Circuit Malfunction	No camshaft position sensor signal to ECM during cranking. (2 trip detection logic)
		No camshaft position sensor signal to ECM during engine running.
P0401	Exhaust Gas Recirculation Flow Insufficient Detected	After the engine is warmed up and run at 80 km/h (50 mph) for 3 to 5 minutes, the EGR gas temperature sensor value does not exceed 40°C (104°F) above the ambient air temperature, (2 trip detection logic)

Trouble Area	MIL	Memory	See Page
<ul style="list-style-type: none"> Ignition system Injector Fuel line pressure EG R Compression pressure Valve clearance not to specification Valve timing Mass air flow meter Engine coolant temp. sensor 	○	○	EG2-493
<ul style="list-style-type: none"> Open or short in knock sensor 1 circuit. Knock sensor 1 (looseness) ECM 	○	○	EG2-499
<ul style="list-style-type: none"> Open or short in knock sensor 2 circuit. Knock sensor 2 (looseness) ECM 	○	○	EG2-499
<ul style="list-style-type: none"> Open or short in crankshaft position sensor circuit. Crankshaft position sensor Starter ECM 	○	○	EG2-503
<ul style="list-style-type: none"> Mechanical system malfunction (skipping teeth of timing belt, belt stretched) ECM 	○	○	EG2-507
<ul style="list-style-type: none"> Open or short in camshaft position sensor circuit. Camshaft position sensor Starter ECM 	○	○	EG2-508
<ul style="list-style-type: none"> EGR valve stuck closed Short in EGR VSV circuit Open in EGR gas temp. sensor circuit EGR hose disconnected ECM 	○	○	EG2-512

DIAGNOSTIC TROUBLE CODE CHART (Cont'd)

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P0402	Exhaust Gas Recirculation Flow Excessive Detected	EG R gas temp. sensor value is high during EGR cut-off when engine is cold (Race engine at about 4,000 rpm without load so that vacuum is applied to port E). (2 trip detection logic)
		EG R valve is always open. (2 trip detection logic)
P0420	Catalyst System Efficiency Below Threshold	After the engine is warmed up and the vehicle driven for 5 min. at 32 – 80 km/h (20 – 50 mph), the waveforms of the heated oxygen sensors, bank 1, 2 sensor 1 and bank 1 sensor 2 have the same amplitude.
P0500	Vehicle Speed Sensor Malfunction	No vehicle speed sensor signal to ECM under conditions a) and b). a) Park/neutral position switch is OFF. b) Vehicle is being driven.
P0505	Idle Control System Malfunction	Idle speed continues to vary greatly from the target speed. (2 trip detection logic)
P0510	Closed Throttle Position Switch Malfunction	The closed throttle position switch does not turn ON even once when the vehicle is driven. (2 trip detection logic)

Trouble Area	MIL*1	Memory	See Page
<ul style="list-style-type: none"> EGR valve stuck open EGR VSV open malfunction Open in EGR VSV circuit Short in EGR gas temp. sensor circuit ECM 	○	○	EG2-527
<ul style="list-style-type: none"> Three-way catalytic converter Open or short in heated oxygen sensor circuit Heated oxygen sensor 	○*2	○	EG2-534
<ul style="list-style-type: none"> Open or short in vehicle speed sensor circuit. Vehicle speed sensor Combination meter ECM 	○	○	EG2-537
<ul style="list-style-type: none"> IAC valve is stuck or closed Open or short in IAC valve circuit Air conditioner idle up VSV Air intake (hose loose) 	○	○	EG2-541
<ul style="list-style-type: none"> Open in closed throttle position switch circuit. Closed throttle position switch ECM 	○	○	EG2-546

*1.... MIL does not light up

○ MIL lights up

◎ MIL lights up, O/D OFF indicator light blinks

*2.... MIL lights up only on USA specification vehicles.

DIAGNOSTIC TROUBLE CODE CHART (Cont'd)

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P0720	Output Speed Sensor Circuit Malfunction (for Electronically Controlled Transaxle)	DTC No. P0500 is detected.
P0750	Shift Solenoid A Malfunction (Shift Solenoid Valve No.1)	During normal driving the gear required by the ECM does not match the actual gear, (2 trip detection logic)
P0753	Shift Solenoid A Electrical (Shift Solenoid Valve No.1)	Open or short in shift solenoid valve No.1 circuit.
P0755	Shift Solenoid6 Malfunction (Shift Solenoid Valve No.2)	Same as for DTC No. P0750.
P0758	Shift Solenoid B Electrical (Shift Solenoid Valve No.2)	Open or short in shift solenoid valve No.2 circuit.
P0770	Shift Solenoid E Malfunction (Shift Solenoid Valve SL)	Lock-up does not occur when driving in the lock-up range (normal driving at 80 km/h [50 mph]), or lock-up remains ON in the lock-up OFF range. (2 trip detection logic)
P0773	Shift Solenoid E Electrical (Shift Solenoid Valve SL)	Open or short in shift solenoid valve SL circuit. (2 trip detection logic)

Trouble Area	MIL*	Memory	See Page
<ul style="list-style-type: none"> Same as for DTC No. P0500. 	⊙	○	AX2-92
<ul style="list-style-type: none"> Shift solenoid valve No.1 is stuck open or closed. Valve body is blocked up or stuck. 	⊙	○	AX2-96
<ul style="list-style-type: none"> Open or short in shift solenoid valve No.1 circuit. Shift solenoid valve No.1 ECM 	⊙	○	AX2-98
<ul style="list-style-type: none"> Shift solenoid valve No.2 is stuck open or closed. 	⊙	○	AX2-96
<ul style="list-style-type: none"> Open or short in shift solenoid valve No.2 circuit. Shift solenoid valve No.2 ECM 	⊙	○	AX2-98
<ul style="list-style-type: none"> Shift solenoid valve SL is stuck open or closed. Lock-up clutch 9 Valve body is blocked up or stuck. 	⊙	○	AX2-102
<ul style="list-style-type: none"> Open or short in shift solenoid valve SL circuit. Shift solenoid valve SL ECM 	⊙	○	AX2-104

* – MIL does not light up

○ MIL lights up

⊙ MIL lights up, O/D OFF indicator light blinks

DIAGNOSTIC TROUBLE CODE CHART

(Manufacturer Controlled)

DTC No.	Detection Item	Diagnostic Trouble Code Detecting Condition
P1300	Igniter Circuit Malfunction	No IGF signal to ECM for 6 consecutive IGT signals during engine running.
P1500	Starter Signal Circuit Malfunction	No starter signal to ECM.
P1600	ECM BATT Malfunction	Open in back up power source circuit.
P1605	Knock Control CPU Malfunction	Engine control computer malfunction (for knock control).
P1705	"NC2" Revolution Sensor Circuit Malfunction (Direct Clutch Speed Sensor)	Output of direct clutch speed sensor (NC2) is 300 rpm or less under conditions a) and b). (2 trip detection logic) a) Vehicle speed: 32 km/h (20 mph) or more b) Park/neutral position switch: OFF
P1765	Linear Solenoid for Accumulator Pressure Control Circuit Malfunction (Shift Solenoid Valve SLN)	After the engine is warmed up, the current flow to the shift solenoid valve SLN is 0.2 A or less for at least 1 sec. under condition a) or b). (2 trip detection logic) a) Engine speed: 500 rpm or more b) Park/neutral position switch: ON (P or N position)
P1780	Park/Neutral Position Switch Malfunction	Two or more switches are ON simultaneously for "N", "2" and "L" position. (2 trip detection logic)
		When driving under conditions a) and b) for 30 sec. or more, the park/neutral position switch is ON (N position). (2 trip detection logic) a) Vehicle speed: 70 km/h (44 mph) or more b) Engine speed: 1,500 – 2,500 rpm

Trouble Area	MIL*	Memory	See Page
<ul style="list-style-type: none"> • Open or short in IGF or IGT circuit from igniter to ECM. • Igniter • ECM 	○	○	EG2-550
<ul style="list-style-type: none"> • Open or short in starter signal circuit. • Open or short in ignition switch or starter relay circuit, • ECM 	-	○	EG2-557
<ul style="list-style-type: none"> • Open in back up power source circuit. • ECM 	○	○	EG2-559
<ul style="list-style-type: none"> • ECM 	○	○	EG2-561
<ul style="list-style-type: none"> • Open or short in direct clutch speed sensor circuit. • Direct clutch speed sensor • ECM 	●	○	AX2-108
<ul style="list-style-type: none"> • Open or short in shift solenoid valve SLN circuit. • Shift solenoid valve SLN • ECM 	-	○	AX2-112
<ul style="list-style-type: none"> • Short in park/neutral position switch circuit. • Park/neutral position switch • ECM 	○	○	EG2-562

*: – MIL does not light up

○ MIL lights up

● MIL lights up, O/D OFF indicator light blinks

FAIL-SAFE CHART

If any of the following codes is recorded, the ECM enters fail-safe mode.

DTC No.	Fail-Safe Operation	Fail-safe Deactivation Conditions
P0100	<ul style="list-style-type: none"> Ignition timing fixed at 5₂ BTDC. Injection time fixed Starting 11.0 m sec. CTP Switch ON 3.5 m sec. CTP Switch OFF 6.3 m sec.	Returned to normal condition
P0110	Intake air temp. is fixed at 68 ₂ F (20 ₂ C).	Returned to normal condition
P0115	Engine coolant temp. is fixed at 176 ₂ F (80 ₂ C).	Returned to normal condition
P0120	VTA is fixed at 0 ₂ .	The following condition must be repeated at least 2 times consecutively. When closed throttle position switch is ON: $0.1\text{ V} \leq \text{VTA} \leq 0.95\text{ V}$
P0135 P0141 P0155	The heater circuit in which an abnormality is detected is turned off.	Ignition switch OFF
P0325 P0330	Max. timing retardation.	Ignition switch OFF
P0720	Gears are shifted according to the engine rpm and throttle angle.	Returned to normal condition
P0753	Power to the solenoid valve and lock-up solenoid valve is cut off.	Returned to normal condition
P0758	Power to the solenoid valve and lock-up solenoid valve is cut off.	Returned to normal condition
P0773	Power to the solenoid valve is cut off.	Returned to normal condition
P1300	Fuel cut	IGF signal is detected for 6 consecutive ignitions.
P1605	Max. timing retardation.	Returned to normal condition
P1766	Power to the solenoid valve is cut off.	Returned to normal condition

Back-up Function

If there is trouble with the program in the ECM and ignition signals (IGT) are not output from the microcomputer, the ECM controls fuel injection and ignition timing at predetermined levels as a back-up function to make it possible to continue to operate the vehicle.

Furthermore, the injection duration is calculated from the starting signal (STA) and the closed throttle position switch signal (IDL). Also, the ignition timing is fixed at 5₂ BTDC, without relation to the engine speed,

HINT: If the engine is controlled by the back-up function, the malfunction indicator lamp lights up to warn the driver of the malfunction but the diagnostic trouble code is not output.

CHECK FOR INTERMITTENT PROBLEMS

TOYOTA HAND-HELD TESTER only

By putting the vehicle's ECM in check mode, 1 trip detection logic is possible instead of 2 trip detection logic and sensitivity to detect open circuits is increased. This makes it easier to detect intermittent problems.

CLEAR DIAGNOSTIC TROUBLE CODES

See page [EG2-403](#)



SET CHECK MODE



See page [EG2-403](#)

PERFORM A SIMULATION TEST

Using the symptom simulation (see page [IN-24](#)), shake and pull lightly on the wire harness, connector or terminals in the circuit indicated by the malfunction code. In this test, if the malfunction indicator lamp lights up, it indicates that the place where the wire harness, connector or terminals being pulled or shake has faulty contact. Check that point for loose connections, dirt on the terminals, poor fit or other problems and repair as necessary.

HINT: After cancelling out the diagnostic trouble code in memory and setting the check mode, if the malfunction indicator lamp does not go off after the engine is started, check thoroughly for faulty contacts, etc., then try the check again. If the malfunction indicator lamp still does not go off, check and replace the ECM.





CONNECTOR CONNECTION AND TERMINAL INSPECTION

When checking for an open circuit or short circuit, it is important to check the connector connection and the condition of the terminals.

OPEN CIRCUIT:

This could be due to a disconnected wire harness, faulty contact in the connector, a connector terminal pulled out, etc.

HINT:


1. A wire rarely breaks in the middle of its length. Most cases occur at the connector. In particular, carefully check the connectors of sensors and actuators.
2. Faulty contact could be due to rusting of the connector terminals, to foreign materials entering the terminals or a drop in the contact pressure between the male and female terminals of the connector. Simply disconnecting and reconnecting the connectors once changes the condition of the connection and may result in a return to normal operation. Therefore, in troubleshooting, if no abnormality is found in the wire harness and connector check, but the problem disappears after the check, then the cause is considered to be in the wire harness or connectors.

SHORT CIRCUIT:

This could be due to a short circuit between the wire harness and the body ground or to a short inside the switch, etc.


HINT:

When there is a short between the wire harness and body ground, check thoroughly whether the wire harness is caught in the body or is clamped properly.



VISUAL CHECK AND CONTACT PRESSURE CHECK


- (a) Disconnect the connectors at both ends.
- (b) Check for rust or foreign material, etc. on the terminals of the connectors.
- (c) Check crimped portions for looseness or damage and check if the terminals are secured in the lock position.
HINT: The terminals should not come out when pulled lightly.



- (d) Prepare a test male terminal and insert it in the female terminal, then pull it out.

NOTICE: When testing a gold-plated female terminal, always use a gold-plated male terminal.

HINT: When the test terminal is pulled out more easily than others, there may be poor contact in that section.



CONNECTOR HANDLING

When inserting tester probes into a connector, insert them from the rear of the connector. When necessary, use mini test leads. For water resistant connectors which cannot be accessed from behind, take good care not to deform the connector terminals.

BASIC INSPECTION

When the normal code is displayed in the diagnostic trouble code check, troubleshooting should be performed in the order for all possible circuits to be considered as the causes of the problems.

In many cases, by carrying out the basic engine check shown in the following flow chart, the location causing the problem can be found quickly and efficiently. Therefore, use of this check is essential in engine troubleshooting.

1

Is battery positive voltage 11 V or more when engine is stopped?

YES**NO**

Charge or replace battery.

2

Is engine cranked?

YES**NO**

Proceed to page ST-47, 63 and continue to troubleshoot.

3


Does engine start?

YES**NO**

Go to step **7**

4

Check air filter.



P02495

P

Remove air filter.

C

Visually check that the air cleaner element is not damaged or excessively oily.

Flow

If necessary, clean element with compressed air. First blow from inside thoroughly, then blow from outside of element.


OK**NG**

Repair or replace.

Go to step **5**

5

Check idle speed.



- P** (1) Warm up engine to normal operating temperature.
 (2) Switch off all accessories.
 (3) Switch off air conditioning.
 (4) Shift transmission into "N" position.
 (5) Connect the OBDII scan tool or TOYOTA hand-held tester to data link connector 3 on the vehicle.

C Use CURRENT DATA to check the engine idle speed.

OK Idle speed: 650 – 750 rpm


OK

NG

Proceed to matrix chart of problem symptoms on page [EG2-435](#).

6

Check ignition timing.



- P** (1) Warm up engine to normal operating temperature.
 (2) Shift transmission into "N" position.
 (3) Keep the engine speed at idle.
 (4) Using SST, connect terminals TE1 and E1 of data link connector 1.
 SST 09843-18020
 (5) Using a timing light, connect the tester to check wire. (See page IG-81)

C Check ignition timing.



OK Ignition timing: 10₂ BTDC at idle

OK

NG

Proceed to page IG-80 and continue to troubleshoot.

Proceed to matrix chart of problem symptoms on page [EG2-435](#).

7**Check fuel pressure.****P**


- (1) Be sure that enough fuel is in the tank.
- (2) Turn ignition switch ON.
- (3) Connect the TOYOTA hand-held tester to data link connector 3 on the vehicle.
- (4) Use ACTIVE TEST mode to operate the fuel pump.

C

Check that the pulsation damper screw rises up when the fuel pump operates.

OK**NG**

Proceed to page [EG2-230](#) and continue to troubleshoot.

8**Check for spark.****P**

- (1) Remove ignition coil (See page IG-89).
- (2) Remove spark plug.
- (3) Install the spark plug to the ignition coil, and connect the ignition coil connector.
- (4) Ground the spark plug.
- (5) Disconnect injector connector.

C

Check if spark occurs while engine is being cranked.


NOTICE: To prevent excess fuel being injected from the injectors during this test, don't crank the engine for more than 5 –10 seconds at a time.

OK**NG**


Proceed to page IG-87 and continue to troubleshoot.


Proceed to matrix chart of problem systems on page [EG2-435](#).

PARTS LOCATION




WIRING DIAGRAM





TERMINALS OF ECM

When measuring the voltage or resistance of the connector part of the ECM, always insert the test probe into the connector from the wire harness side.

ECM Terminals					
E7			E8		
E9			E10		
					
FM810					
Terminal No.	Symbol	Connection	Terminal No.	Symbol	Connection
E7- 1	-	_____	E7-15	IG T3	Igniter
2	-	_____	16	IG T2	Igniter
3	SLN ⊖	Shift solenoid SLN	17	S2	Shift Solenoid No.2
4	-		18	-	
5	#60	Injector (No.6)	19	-	_____
6	#50	Injector (No.5)	20	-	_____
7	#40	Injector (No.4)	21	-	_____
8	#30	Injector (No.3)	22	RSC	IAC valve
9	#20	Injector (No.2)	23	RSO	IAC valve
10	#10	Injector (No.1)	24	IGT1	Igniter
11	S1	Shift solenoid No.1	25	FPU	Fuel pressure up VSV
12	IGF	Igniter	26	IGT4	Igniter
13	STA	Starter relay	27	SL	Shift solenoid SL
14	NSW	Park/Neutral position switch	28	E03	Oxygen sensor heater ground

Terminal No.	Symbol	Connection	Terminal No.	Symbol	Connection
E7-29	IGT6	Igniter	E8-19	OXL	Heated oxygen sensor (Bank 2 Sensor 1)
30	IGT5	Igniter	20	THW	Engine coolant temp. sensor
31	—	—	21	THA	Intake air temp. sensor
32	IDL	Throttle position sensor	22	E2	Sensor ground
33	E02	Power ground	E9- 1	ACV	A/C idle-up VSV
34	E01	Power ground	2	—	—
E8- 1	VC	Throttle position sensor	3	W	Malfunction indicator lamp
2	—	—	4	—	—
3	—	—	5	TE1	Data link connector 1
4	NC2 ⊖	Direct clutch speed sensor	6	ACIS	Intake air control valve VSV
5	NE ⊕	Crankshaft position sensor	7	VG ⊖	Mass air flow meter
6	NE ⊖	Crankshaft position sensor	8	—	—
7	VTA	Throttle position sensor	9	—	—
8	VG	Mass air flow meter	10	HTL	Heated oxygen sensor heater (Bank 2 Sensor 1)
9	NC2 ⊕	Direct clutch speed sensor	11	HTR	Heated oxygen sensor heater (Bank 1 Sensor 1)
10	—	—	12	EGR	EGR VSV
11	—	—	13	—	—
12	—	—	14	THG	EG R gas temp. sensor
13	OXR	Heated oxygen sensor (Bank 1 Sensor 1)	15	—	—
14	KNKL	Knock sensor 2	16	E1	ECM ground
15	KNKR	Knock sensor 1	E10- 1	—	—
16	G22 ⊕	Camshaft position sensor	2	L	Park/Neutral position switch
17	G22 ⊖	Camshaft position sensor	3	P	Electronically controlled transmission select switch
18	FC	Circuit opening relay	4	—	—

TERMINALS OF ECM (Cont'd)


ECM Terminals

E7

E8

E9

E10



F16810

Terminal No.	Symbol	Connection	Terminal No.	Symbol	Connection
E10- 5	ACT	A/C control assembly	E10-17	-	_____
6	OD2	O/D main switch	18	-	_____
7	OD1	Cruise control ECU	19	-	_____
8	-	_____	20	A/C	A/C control assembly
9	-	_____	21	ELS	Defogger relay Taillight relay
10	2	Park/Neutral position switch	22	+ B	EFI Main relay
11	-	_____	23	+ B1	EFI Main relay
12	SP1	Vehicle speed sensor	24	STP	Stop light switch Stop light
13	TACO	Tachometer	25	HTS	Heated oxygen sensor heater (Bank 1 Sensor 2)
14	BATT	Battery	26	OXS	Heated oxygen sensor (Bank 1 Sensor 2)
15	R	Park/Neutral position switch	27	-	_____
16	-	_____	28	SDL	Data link connector 3

- MEMO -

STANDARD VALUE OF ECM TERMINALS

Symbols (Terminals No.)	Wiring Color	STD Voltage (V)	Condition
BATT (E10-14) - E1 (E9-16)	W-L ↔ BR	9 ~ 14	Always
+B (E10-22) +B1 (E10-23) - E1 (E9-16)	B-O B-O ↔ BR	9 ~ 14	IG switch ON
VC (E8-1) - E2 (E8-22)	L-R ↔ BR	4.5 ~ 5.5	IG switch ON
IDL (E7-32) - E2 (E8-22)	L ↔ BR	0 ~ 3	IG switch 0 N Throttle valve fully closed.
		9 ~ 14	IG switch ON Throttle valve fully open.
VTA (E10-7) - E2 (E8-22)	B-Y ↔ BR	0.3 ~ 0.8	IG switch ON Throttle valve fully closed.
		3.2 ~ 4.9	IG switch 0 N Throttle valve fully open.
VG (E8-8) - VG - (E9-7)	R ↔ R-B	1.1 - 1.5	Idling, P or N Position, A/C switch off.
THA (E8-21) - E2 (E8-22)	L-B ↔ BR	0.5 ~ 3.4	Idling, Intake air temp. 20°C (68°F)
THW (E8-20) - E2 (E8-22)	G-B ↔ BR	0.2 ~ 1.0	Idling, Engine coolant temp. 80°C (176°F)
STA (E7-13) - E1 (E9-16)	B-W ↔ BR	6.0 or more	Cranking
#10 (E7-10) #20 (E7-9) #30 (E7-8) - E01 (E7-34) #40 (E7-7) #50 (E7-6) #60 (E7-5)	W Y GR L ↔ W-B R G	9 ~ 14	IG switch 0 N
		Pulse generation (See page EG2-492)	Idling
IGT1 (E7-24) IGT2 (E7-16) IGT3 (E7-15) IGT4 (E7-26) - E1 (E9-16) IGT5 (E7-30) IGT6 (E7-29)	W-G Y-R GR-B L-B ↔ BR R-B G-R	Pulse generation (See page EG2-556)	Idling
IGF (E7-12) - E1 (E9-16)	W-R ↔ BR	4.5 ~ 5.5	IG switch ON
		Pulse generation (See page EG2-556)	Idling
G22 ⊕ (E8-16) - G22 ⊖ (E8-17)	B-W ↔ L	Pulse generation (See page EG2-505)	Idling
NE ⊕ (E8-5) - NE ⊖ (E8-6)	R ↔ G	Pulse generation (See page EG2-505)	Idling
FPU (E7-25) - E1 (E9-16)	B-R ↔ BR	9 ~ 14	IG switch ON
		0 ~ 3	Restarting at high engine coolant temp.
ELS (E10-21) - E1 (E9-16)	B-R ↔ BR	7.5 ~ 14	Defogger switch and taillight switch ON.
		0 ~ 1.5	Defogger switch and taillight switch OFF.
EGR (E9-12) - E1 (E9-16)	B-L ↔ BR	9 ~ 14	IG switch ON
ACIS (E9-6) - E1 (E9-16)	R-Y ↔ BR	9 ~ 14	IG switch ON

STANDARD VALUE OF ECM TERMINALS (Cont'd)

Symbols (Terminals No.)	Wiring Color	STD Voltage (V)	Condition
RSC (E7-22) RSO (E7-23) – E1 (E9-16)	Y-B G-B ↔ BR	9 ~ 14	IG switch ON Disconnect (E7) of ECM connector
ACV (E9-1) – E1 (E9-16)	W-L ↔ BR	0 ~ 3	Idling, A/C switch ON
		9 ~ 14	Idling, A/C switch OFF
OXR (E8-13) OXL (E8-19) – E1 (E9-16)	R-L R-L ↔ BR	Pulse generation	Maintain engine speed at 2,500 rpm for 2 mins. after warming up.
HTL (E9-10) HTR (E9-11) – E03 (E7-28) HTS (E10-25)	V-R L-B ↔ W-B P-B	Below 3.0	Idling
		9 ~ 14	IG switch 0 N
KNKR (E8-15) KNKL (E8-14) – E1 (E9-16)	W W ↔ BR	Pulse generation (See page EG-502)	Idling
NSW (E7-14) – E1 (E9-16)	B-W ↔ BR	9 ~ 14	IG switch ON Other shift position in "P", "N" position
		0 ~ 3.0	IG switch ON Shift position in "P", "N" position
SP1 (E10-12) – E1 (E9-16)	V-Y ↔ BR	Pulse generation	IG switch 0 N Rotate driving wheel slowly.
TE1 (E9-5) – E1 (E9-16)	GR-B ↔ BR	4.5 ~ 5.5	IG switch ON
OD1 (E10-7) – E1 (E9-16)	Y-B ↔ BR	4.5 ~ 5.5	IG switch ON
ACT (E10-5) – E1 (E9-16)	LG-B ↔ BR	4.5 ~ 5.5	Idling, A/C switch ON
		Below 2.0	Idling, A/C switch OFF
A/C (E10-20) – E1 (E9-16)	B-Y ↔ BR	Below 2.0	Idling, A/C switch ON
		4.5 ~ 5.5	Idling, A/C switch OFF

ENGINE OPERATING CONDITION

NOTICE: The values given below for "Normal Condition" are representative values, so a vehicle may still be normal even if its value varies from those listed here. So do not decide whether a part is faulty or not solely according to the "Normal Condition" here.

CARB Mandated Signals

TOYOTA hand-held tester display	Measurement Item	Normal Condition *
FUEL SYS #1	Fuel System Bank 1 OPEN: Air-fuel ratio feedback stopped CLOSED: Air-fuel ratio feedback operating	Idling after warming up: CLOSED
FUEL SYS #2	Fuel System Bank 2 OPEN: Air-fuel ratio feedback stopped CLOSED: Air-fuel ratio feedback operating	Idling after warming up, CLOSED
CALC LOAD	Calculator Load: Current intake air volume as a proportion of max. intake air volume	Idling: 12.9 – 25.2% Racing without load (2,500 rpm): 11.7 – 23.9%
COOLANT TEMP	Engine Coolant Temperature Sensor Value	After warming up: 80 – 95°C (176 – 203°F)
SHORT FT #1	Short-term Fuel Trim Bank 1	0 ± 20%
LONG FT #1	Long-term Fuel Trim Bank 1	0 ± 20%
SHORT FT #2	Short-term Fuel Trim Bank 2	0 ± 20%
LONG FT #2	Long-term Fuel Trim Bank 2	0 ± 20%
ENGINE SPD	Engine Speed	Idling: 700 ± 50 rpm
VEHICLE SPD	Vehicle Speed	Vehicle Stopped: p km/h mph
IGN ADVANCE	Ignition Advance Ignition Timing of Cylinder No.1	Idling: BTDC 12 ± 5°
INTAKE AIR	Intake Air Temperature Sensor Value	Equivalent to Ambient Temp.
MAF	Air Flow Rate Through Mass Air Flow Meter	Idling: 2.4 – 4.8 gm/sec Racing without load (2,500 rpm): 7.9 – 16.2 gm/sec
THROTTLE POS	Voltage Output of Throttle Position Sensor Calculated as a Percentage 0 V → 0%, 5 V → 100%	Throttle Fully Closed: 7 – 11% Fully Open: 65 – 75%
O2S B1, S1	Voltage Output of Oxygen Sensor Bank 1, Sensor 1	Idling: 0.1 – 0.9 V

If no conditions are specifically stated for "Idling", it means the shift lever is at N or P position, the A/C switch is OFF and all accessory switches are OFF.

TOYOTA hand-held tester display	Measurement Item	Normal Condition *
O2FT B1, S1	Oxygen Sensor Fuel Trim Bank 1, Sensor 1 (Same as SHORT FT #1)	0 ± 20%
O2S B1, S2	Voltage Output of Oxygen Sensor Bank 1, Sensor 2	Driving (50 km/h, 31 mph): 0.1 – 0.9 V
O2S B2, S1	Voltage Output of Oxygen Sensor Bank 2, Sensor 1	Idling: 0.1 – 0.9 V
O2FT B2, S1	Oxygen Sensor Fuel Trim Bank 2, Sensor 1 (Same as SHORT FT #2)	0 ± 20%

TOYOTA Enhanced Signals

TOYOTA hand-held tester display	Measurement Item	Normal Condition *
MISFIRE RPM	Engine RPM for first misfire range	Misfire 0: 0 RPM
MISFIRE LOAD	Engine load for first misfire range	Misfire 0: 0 g/r
INJECTOR	Fuel injection time for cylinder No.1	Idling: 2.2 – 5.1 ms
IAC DUTY RATIO	Intake Air Control Valve Duty Ratio Opening ratio rotary solenoid type IAC valve	Idling: 30 – 40%
STARTER SIG	Starter Signal	Cranking: ON
CTP SW	Closed Throttle Position Switch Signal	Throttle Fully Closed: ON
A/C SIG	A/C Switch Signal	A/C ON: ON
PNP SW	Park/Neutral Position Switch Signal	P or N position: ON
ELCTRCL LOAD SIG	Electrical Load Signal	Defogger S/W ON: ON
STOP LIGHT SW	Stop Light Switch Signal	Stop light switch ON: ON
FC IDL	Fuel Cut Idle: Fuel cut when throttle valve fully closed, during deceleration	Fuel cut operating: ON
FC TAU	Fuel Cut TAU: Fuel cut during very light load	Fuel cut operating: ON
CYL #1 CYL #6	Ratio of revolution variation for each cylinder when variation is large	0 %
IGNITION	Ignition rate for all cylinders every 1,000 revolutions	0 – 3,000
EGRT GAS	EGR Gas Temperature Sensor Value	EG R not operating: Temperature between intake air temp. and engine coolant temp.
INTAKE CTRL VSV	Intake Air Control Valve VSV Signal	VSV operating: ON
EGR SYSTEM	EG R system operating condition	Idling: OFF
FUEL PRES UP VSV	Fuel Pressure Up VSV Signal	High temp. restarting: ON
A/C CUT SIG	A/C Cut Signal	A/C S/W OFF: ON
A/C IDLE U P VSV	A/C Idle Up Signal	A/C S/W ON & D position & headlight ON: ON

TOYOTA hand-held tester display	Measurement Item	Normal Condition *
TOTAL FT B1	Total Fuel Trim Bank 1: Average value for fuel trim system of bank 1	Idling: 0.8 – 1.2
TOTAL FT B2	Total Fuel Trim Bank 2: Average value for fuel trim system of bank 2	Idling: 0.8 – 1.2
02 LR B1, S1	Oxygen Sensor Lean Rich Bank 1, Sensor 1 Response time for oxygen sensor output to switch from lean to rich.	Idling after warmed up: 0 – 1,000 m sec.
02 LR B2, S1	Oxygen Sensor Lean Rich Bank 2, Sensor 1 Response time for oxygen sensor output to switch from lean to rich.	Idling after warmed up: 0 – 1,000 msec.
02 RL B1, S1	Oxygen Sensor Rich Lean Bank 1, Sensor 1 Response time for oxygen sensor output to switch from rich to lean.	Idling after warmed up: 0 – 1,000 msec.
02 RL B2, S1	Oxygen Sensor Rich Lean Bank 2, Sensor 1 Response time for oxygen sensor output to switch from rich to lean.	Idling after warmed up: 0 – 1,000 msec.

*; If no conditions are specifically stated for "Idling", it means the shift lever is at Nor P position, the A/C switch is OFF and all accessory switches are OFF.


MATRIX CHART OF PROBLEM SYMPTOMS

When the malfunction code is not confirmed in the diagnostic trouble code check and the problem still can not be confirmed in the basic inspection, then proceed to this step and perform troubleshooting according to the numbered order given in the table below.

See page		EG2-557	EG2-565	EG2-575	EG2-586	AC-36	ST-47, 63	EG2-36	AX2-81	IN-36
Suspect area		Starter signal circuit	ECM power source circuit	Fuel pump control circuit	Fuel pressure control VSV circuit	A/C signal circuit (Compressor circuit)	Starter and Starter relay	Compression	A/T faulty	Engine control module (ECM)
Does not start	Engine does not crank						1			
	No initial combustion		1	2						
	No complete combustion			1						
Difficult to start	Under normal condition	1		2				3		
	Cold engine	1		2						
	Hot engine	1		3	2					
Poor Idling	High engine idle speed		2			1				
	Low engine idle speed			2		1				
	Rough idling			2				1		
	Hunting		1	2						
Poor Drive-ability	Hesitation/Poor acceleration			1					2	
	Surging			1						
Engine stall	Soon after starting			1						
	During A/C operation					1				2

LOCATION OF CONNECTORS

Location of Connectors in Engine Compartment



N09612

C17

Camshaft
Position Sensor

Ie-2-1-D


C18

Crankshaft
Position Sensor

Ie-2-1-D

D1

Data Link Connector 1



Iel-23-1

E1

EGR Gas
Temp. Sensor

Ie-2-1-C

E4

Engine Coolant Temp.
Sensor

V-2-1-C

H11

Heated Oxygen
Sensor
(Bank 1 Sensor 1)

Ie-4-1-D

H12


Heated Oxygen
Sensor
(Bank 2 Sensor 1)

Ie-4-1-D


I1

Idle Air Control
Valve


Ie-3-1-H



Location of Connectors in Engine Compartment (Cont'd)



Location of Connectors in Instrument Panel



N09614

A10

A/C Amplifier



e-14-1-A

D3

Data Link Connector 2



S-17-1

D24


Data Link Connector 3



N09214

E7

Engine Control Module




n-34-1

E8

Engine Control Module




n-22-1

E9

n-16-1

E10

Engine Control Module



n-28-1

H9


Heated Oxygen
Sensor
(Bank 1 Sensor 2)



ie-4-1-D

I12

Ignition Switch




g-10-1-B


I11

e-10-1


e-10-2

IJ1

eg-18-1



eg-18-2

IM1

ie-6-1-A




ie-6-2-A

IQ1


e-6-1



e-6-2

IP1

e-20-1-B




e-20-2-B

IP3

ef-19-1




ef-19-2


J/B No.1

Location of Connectors in Instrument Panel (Cont'd)

J/B No.3




R/B No.1



N09663


R/B No.6



N09546


Location of Connectors in Body

Sedan




N09515

Coupe



N09703

Wagon



N08704

F15

Fuel Pump




le-5-1-A

BX1



e-5-1



e-5-2



DTC P0100 Mass Air Flow Circuit Malfunction

CIRCUIT DESCRIPTION

The mass air flow meter uses a platinum hot wire. The hot wire air flow meter consists of a platinum hot wire, thermistor and a control circuit installed in a plastic housing. The hot wire air flow meter works on the principle that the hot wire and thermistor located in the intake air bypass of the housing detect any changes in the intake air temperature.

The hot wire is maintained at the set temperature by controlling the current flow through the hot wire. This current flow is then measured as the output voltage of the air flow meter.

The circuit is constructed so that the platinum hot wire and thermistor provide a bridge circuit, with the power transistor controlled so that the potential of (A) and (B) remains equal to maintain the set temperature.




DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0100	Open or short in mass air flow meter circuit with engine speed 4,000 rpm or less.	<ul style="list-style-type: none">• Open or short in mass air flow meter circuit• Mass air flow meter• ECM

If the ECM detects diagnostic trouble code "P01 00" it operates the fail safe function, keeping the ignition timing and injection volume constant and making it possible to drive the vehicle.


HINT: After confirming DTC P01 00 use the OBDII scan tool or TOYOTA hand-held tester to confirm the mass air flow ratio from "CURRENT DATA".

Mass Air Flow Value (gm/sec.)	Malfunction
0.0	<ul style="list-style-type: none"> + B circuit open VG circuit open or short
271.0 or more	<ul style="list-style-type: none"> VG- circuit open

WIRING DIAGRAM




DIAGNOSTIC CHART



INSPECTION PROCEDURE

1

Connect the OBDII scan tool or TOYOTA hand-held tester, and read value of mass air flow rate.



BE6653
F17088

Type
I

- P** (1) Remove the fuse cover on the instrument panel.
(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.
(3) Turn ignition switch ON and OBDII scan tool or TOYOTA hand-held tester main switch ON.
(4) Start the engine.

- C** Read mass air flow rate on the OBDII scan tool or TOYOTA hand-held tester.

Result


	Mass air flow rate
Type I	0.0 gm/sec.
TypeII	271.0 gm/sec. or more

Type
II

Go to step **5**.

2

Check voltage of mass air flow meter power source.



BE6653
F16962


OK

- P** (1) Disconnect the mass air flow meter connector.
(2) Turn ignition switch ON.
- C** Measure voltage between terminal 1 of mass air flow meter connector and body ground.

OK Voltage: 9 -14 V

NG

Check for open in harness and connector between EFI main relay and mass air flow meter (See page [IN-31](#)).

3**Check voltage between terminal VG of ECM and body ground.**

FI7147

P

(1) Remove glove compartment.
(See page [EG2-309](#))

(2) Start the engine.

C

Measure voltage between terminal VG of ECM and body ground while engine is idling.

OK

Voltage: 1.1 – 1.5 V

(P position and A/C switch OFF)


NG**OK**

Check and replace ECM (See page [IN-36](#)).

4**Check for open and short in harness and connector between mass air flow meter and ECM (See page [IN-31](#)).****OK****NG**

Repair or replace harness or connector.

Replace mass air flow meter.

5**Check continuity between terminal VG of ECM and body ground.****P** Remove glove compartment (See page [EG2-309](#)).**C** Check continuity between terminal VG- of ECM and body ground.**OK** Continuity (1 or less)

FI7148

OK**NG**Check and replace ECM (See page [IN-36](#)).**6****Check for- open in harness and connector between mass air flow meter- and ECM (See page [IN-31](#)).****OK****NG**

Repair or replace harness or connector.

Replace mass air flow meter.

DTC P0101 Mass Air Flow Circuit Range Performance Problem

CIRCUIT DESCRIPTION


Refer to mass air flow circuit malfunction on page [EG2-444](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0101	Conditions a) and b) continue with engine speed 900 rpm or less. (2 trip detection logic) a) Closed throttle position switch: ON b) Mass air flow meter output) 2.2 V	<ul style="list-style-type: none">• Mass air flow meter

WIRING DIAGRAM

Refer to mass air flow circuit malfunction on page [EG2-445](#).

DIAGNOSTIC CHART



DTC P0110 Intake Air Temp Circuit Malfunction

CIRCUIT DESCRIPTION

The intake air temp. sensor is built into the air flow meter and senses the intake air temperature.


A thermistor built in the sensor changes the resistance value according to the intake air temperature.

The lower the intake air temperature, the greater the thermistor resistance value, and the higher the intake air temperature, the lower the thermistor resistance value (See Fig. 1.).

The intake air temperature sensor is connected to the ECM (See next page). The 5V power source voltage in the ECM is applied to the intake air temperature sensor from the terminal THA via a resistor R.

That is, the resistor R and the intake air temperature sensor are connected in series. When the resistance value of the intake air temperature sensor changes in accordance with changes in the intake air temperature, the potential at terminal THA also changes. Based on this-signal, the ECM increases the fuel injection volume to improve driveability during cold engine operation.

If the ECM records the diagnostic trouble code "P0110", it operates the fail safe function in which the intake temperature is assumed to be 20 C (68 F). Intake Air Ter



(Reference)

Intake Air Temp. °C (°F)	Resistance (kΩ)	Voltage M
-20 (-4)	16.2	4.3
0 (32)	5.9	3.4
20 (68)	2.5	2.4
40 (104)	1.1	1.4
60 (140)	0.6	0.9
80 (176)	0.3	0.5
100 (212)	0.1	0.2

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0110	Open or short in intake air temp. sensor circuit.	<ul style="list-style-type: none"> Open or short in intake air temp. sensor circuit. Intake air temp. sensor ECM

Hint; After confirming DTC P01 10 use the OBDII scan tool or TOYOTA hand-held tester to confirm the intake air temperature from "CURRENT DATA".

Temperature Displayed	Malfunction
- 40 C (-40 F)	Open circuit
120 C (248 F) or more	Short circuit

WIRING DIAGRAM





Fig448

DIAGNOSTIC CHART

HINT; If diagnostic trouble codes "P0110" (intake air temp. circuit malfunction), "P0115" (engine coolant temp. circuit malfunction), "P0120" (throttle position circuit malfunction) are output simultaneously, E2 (sensor ground) may be open.




INSPECTION PROCEDURE

HINT: If diagnostic trouble codes "P0110" (intake air temp. circuit malfunction), "P0115" (engine coolant temp. circuit malfunction), "P0120" (throttle position circuit malfunction) are output simultaneously, E2 (sensor ground) may be open.

1

Connect the OBDII scan tool or TOYOTA hand-held tester, and read value of intake air temperature.



BE6653
F17088

OK

P

(1) Remove the fuse cover on the instrument panel.

(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.

(3) Turn ignition switch ON and OBDII scan tool or TOYOTA hand-held tester main switch ON.

C

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK

Same as actual intake air temperature.

Hint

If there is open circuit, OBDII scan tool or TOYOTA hand-held tester indicates - 40 C (- 40 F).


If there is short circuit, OBDII scan tool or TOYOTA hand-held tester indicates 120 C (248 F) or more.

NG

- 40 C (- 40 F) Go to step 2

120 C (248 F) or more ... Go to step 3

**Check for intermittent problems.
(See page [EG2-417](#))**

2**Check for open in harness or ECM.**Intake Air
Temp. Sensor**P**



(1) Disconnect the mass air flow meter connector.

(2) Connect sensor wire harness terminals together.

(3) Turn ignition switch ON.

C

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK**Temperature value: 120 C (248 F) or more**BE0053
F17066**NG****OK****Confirm good connection at sensor.
If OK, replace mass air flow meter.****3****Check for open in harness or ECM.**Intake Air
Temp. SensorBE0053
F17067
F17031**NG****P**

(1) Remove glove compartment.

(See page [EG2-309](#))

(2) Connect between terminals THA and E2 of ECM E8 connector.

HINT: Mass air flow meter connector is disconnected. Before checking, do a visual and contact pressure check for the ECM connector. (See page [EG2-418](#))**C**


(3) Turn ignition switch ON.

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK**Temperature value: 120 C (248 F) or more****OK****Open in harness between terminals E2 or THA, repair or replace harness.****Confirm good connection at ECM.
If OK, replace ECM..**

4**Check for short in harness and ECM.**

IG ON

Intake Air
Temp. Sensor888853
F17084**NG****P**

(1) Disconnect the mass air flow meter connector.


(2) Turn ignition switch ON.

C

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK**Temperature value: - 40 C (- 40 F).****OK****Replace mass air flow meter.****5****Check for short in harness or ECM.**

IG ON

Intake Air
Temp. Sensor888853
F17086
F17034**NG****P**

(1) Remove glove compartment.

(See page [EG2-309](#))


(2) Disconnect the E8 connector of ECM.

HINT: Mass air flow meter connector is disconnected.

(3) Turn ignition switch ON.

C

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK**Temperature value: -40 C (-40 F)****OK****Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).**

DTC P0115 Engine Coolant Temp Circuit Malfunction

CIRCUIT DESCRIPTION

A thermistor built into the engine coolant temperature sensor changes the resistance value according to the coolant temperature.

The structure of the sensor and connection to the ECM is the same as in the intake air temp. circuit malfunction shown on page [EG2-451](#).

If the ECM records the diagnostic trouble code P01 15, it operates the fail safe function, keeping the engine coolant temp. at a constant 80₂C (176₂F).


DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0115	Open or short in engine coolant temp. sensor circuit.	<ul style="list-style-type: none"> • Open or short in engine coolant temp. sensor circuit. • Engine coolant temp. sensor. • ECM

HINT: After confirming DTC P01 15 use the OBDII scan tool or TOYOTA hand-held tester to confirm the engine coolant temperature from "CURRENT DATA".

Temperature Displayed Malfunction


– 40 ₂ C (– 40 ₂ F)	Open circuit
120 ₂ C (248 ₂ F) or more	Short circuit

WIRING DIAGRAM



DIAGNOSTIC CHART

HINT: If diagnostic trouble codes "P0110" (intake air temp. circuit malfunction), "P0115" (engine coolant temp. circuit malfunction) and "P0120" (throttle position circuit malfunction) are output simultaneously, E2 (sensor ground) may be open.




INSPECTION PROCEDURE

HINT; If diagnostic trouble codes "P0110" (intake air temp. circuit malfunction), "P0115" (engine coolant temp. circuit malfunction), "P0120" (throttle position circuit malfunction) are output simultaneously, E2 (sensor ground) may be open.

1

Connect the OBD II scan tool or TOYOTA hand-held tester, and read value of engine coolant temperature.



808853
F17088

P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.
- (3) Turn ignition switch ON and OBDII scan tool or TOYOTA hand-held tester main switch ON.

C

Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.

OK

Same as actual engine coolant temperature.

Hint

If there is open circuit, OBD II scan tool or TOYOTA hand-held tester indicates -40_2C (-40_2F).
If there is short circuit, OBD II scan tool or TOYOTA hand-held tester indicates 120_2C (248_2F) or more.


OK
NG

-40_2C (-40_2F) Go to step **2**.
 120_2C (248_2F) or more . . Go to step **3**.

Check for intermittent problems.
(See page [EG2-417](#))

2**Check for open in harness or ECM.**

Engine Coolant Temp. Sensor

BE6653
F17055**NG**


- P** (1) Disconnect the engine coolant temp. sensor connector.
 (2) Connect sensor wire harness terminals together.
 (3) Turn ignition switch ON.
- C** Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.
- OK** **Temperature value: 120₂C (248₂F) or more**

OK

Confirm good connection at sensor. If OK, replace engine coolant temp. sensor.

3**Check for open in harness or ECM.**

Engine Coolant Temp. Sensor

BE6653
F17057
F17032**NG**

- P** (1) Remove glove compartment.
 (See page [EG2-309](#))
 (2) Connect between terminals THW and E2 of ECM E8 connector.
 HINT: Engine coolant temp. sensor connector is disconnected. Before checking, do a visual and contact pressure check for the ECM connector.
- (See page [EG2-418](#))
- (3) Turn ignition switch ON.
- C** Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.
- OK** **Temperature value: 120₂C (248₂F) or more**


OK

Open in harness between terminals E2 or THW, repair or replace harness.

**Confirm good connection at ECM.
 If OK, replace ECM .**

4**Check for short in harness and ECM.**



Engine Coolant Temp. Sensor

BE6653
F17054

- P** (1) Disconnect the engine coolant temp. sensor connector.
(2) Turn ignition switch ON.
- C** Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.
- OK** **Temperature value: -40_2C (-40_2F)**

NG**OK****Replace engine coolant temp. sensor.****5****Check for short in harness or ECM.**

Engine Coolant Temp. Sensor



E8 Connector

BE6653
F17056
F17054

- P** (1) Remove glove compartment.
(See page [EG2-309](#))
(2) Disconnect the E8 connector of ECM.
HINT: Engine coolant temp. sensor connector is disconnected.
- (3) Turn ignition switch ON.
- C** Read temperature value on the OBDII scan tool or TOYOTA hand-held tester.
- OK** **Temperature value: -40_2C (-40_2F)**

NG**OK****Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).**

DTC P0116 Engine Coolant Temp Circuit Range Performance Problem

CIRCUIT DESCRIPTION

Refer to engine coolant temp. circuit malfunction on page [EG2-457](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0116	20 min. or more after starting engine, engine coolant temp. sensor value is 30°C (86°F) or less. (2 trip detection logic)	<ul style="list-style-type: none">• Engine coolant temp. sensor.• Cooling system.

DIAGNOSTIC CHART

HINT: If diagnostic trouble codes "P0115" (engine coolant temp. circuit malfunction) and "P0116" (engine coolant temp. circuit range/ performance) are output simultaneously, engine coolant temp. sensor circuit may be open.


Perform troubleshooting of diagnostic trouble code P0115 first.

1	Are there any other codes (besides DTC P0116) being output?	YES	Go to relevant diagnostic trouble code chart.
NO			
Replace engine coolant temp. sensor. (See page EG2-282)			

DTC P0120 Throttle Position Circuit Malfunction

CIRCUIT DESCRIPTION

The throttle position sensor is mounted in the throttle body and detects the throttle valve opening angle. When the throttle valve is fully closed, the IDL contacts in the throttle position sensor are on, so the voltage at the terminal IDL of the ECM becomes 0V. At this time, a voltage of approximately 0.7 V is applied to terminal VTA of the ECM. When the throttle valve is opened, the IDL contacts go off and thus the power source voltage of approximately 12 V in the ECM is applied to the terminal IDL of the ECM. The voltage applied to the terminal VTA of the ECM increases in proportion to the opening angle of the throttle valve and becomes approximately 3.5 – 5.0 V when the throttle valve is fully opened. The ECM judges the vehicle driving conditions from these signals input from terminals VTA and IDL, and uses them as one of the conditions for deciding the air-fuel ratio correction, power increases correction and fuel-cut control etc.



FI0571


DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0120	Condition a) or b) continues. a) VTA (0.1 V, and closed throttle position switch is OFF. b) VTA) 4.9 V	<ul style="list-style-type: none"> • Open or short in throttle position sensor circuit. • Throttle position sensor. • ECM

HINT:

- If there is open circuit in IDL line, diagnostic trouble code P0120 does not indicate,
- After confirming DTC P0120 use the OBDII scan tool or TOYOTA hand-held tester to confirm the throttle valve opening percentage and closed throttle position switch condition.

Throttle valve opening position expressed as percentage		Trouble Area
Throttle valve fully closed	Throttle valve fully open	
0%	0 %	VC line open VTA line open or short
Approx. 99%	Approx. 100%	E2 line open

WIRING DIAGRAM




FI6673

DIAGNOSTIC CHART

HINT: If diagnostic trouble codes P0110, P0115 and P0120 are output simultaneously, E2 (sensor ground) may be open.

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)

1	Connect the OBDII scan tool and read the throttle valve opening percentage.	OK	Check for intermittent problems.
NG			
2	Check voltage of terminal IDL and E2 of ECM.	OK	Go to step 5
NG			
3	Check voltage of terminal VC on wire harness side connector.	NG	Go to step 6
OK			
4	Check throttle position sensor.	NG	Replace throttle position sensor.
OK			
5	Check voltage of terminal VTA and E2 of ECM.	NG	Check for open and short in harness and connector between ECM and throttle position sensor (VTA line).
OK			
	Check and replace ECM.		
6	Check voltage of terminal VC and E2 of ECM.	NG	Check and replace ECM.
OK			
	Check for open in harness and connector between ECM and sensor (VC line).		


INSPECTION PROCEDURE

TOYOTA hand-held tester

HINT: If diagnostic trouble codes P01 10, P01 15 and P0120 are output simultaneously, E2 (sensor ground) may be open.

1

Connect the TOYOTA hand-held tester and read the throttle valve opening percentage.



- P** (1) Remove the fuse cover on the instrument panel.
 (2) Connect the TOYOTA hand-held tester to the DLC 3.
 (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.

C Read the throttle valve opening percentage.

OK

Throttle valve	Throttle valve opening position expressed as percentage
Fully open	Approx. 70%
Fully closed	Approx. 10%

8E0653
F17088
F17062


NG

OK

Check for intermittent problems
 (See page [EG2-417](#)).

2

Read closed throttle position switch condition.



- P** (1) Remove the fuse cover on the instrument panel.
 (2) Connect the TOYOTA hand-held tester to the DLC 3.
 (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.

C Read closed throttle position switch condition.

OK


Throttle valve	Closed throttle position switch condition
Fully open	OFF
Fully closed	ON

8E0653
F17088
F17062

NG

OK

Go to step 5



3**Check voltage between terminal VC of wire harness side connector and body ground.**8E8653
F17067**OK****P**

(1) Disconnect the throttle position sensor connector.

(2) Turn ignition switch ON.

C

Measure voltage between terminal VC of wire harness side connector and body ground.

OK**Voltage: 4.5 – 5.5 V****NG****Go to step 6****4****Check throttle position sensor.**Throttle
Position SensorF16561
F16562**OK****P**

Disconnect the throttle position sensor connector.


C

Measure resistance between terminals 4, 3 and 1 of throttle position sensor.

OK

Terminals	Throttle valve	Resistance
1 – 4	–	4.25 – 8.25 kΩ
1 – 3	Fully closed	0.3 – 6.3 kΩ
	Fully open	3.5 – 10.3 kΩ

NG**Replace throttle position sensor.**

5**Check voltage between terminals VTA and E2 of ECM.**

- P** (1) Remove glove compartment.
(See page [EG2-309](#))
(2) Turn ignition switch ON.
- C** Measure voltage between terminals VTA and E2 of ECM.


OK

Throttle Valve	Voltage
Fully closed	0.3 – 0.8 V
Fully open	2.7 – 5.2 V

OK**NG**

Check for open and short in harness and connector between ECM and throttle position sensor (VTA line) (See page [IN-31](#)).

Check and replace ECM (See page [IN-36](#)).

6**Check voltage between terminals VC and E2 of ECM.**

- P** (1) Remove glove compartment.
(See page [EG2-309](#))
(2) Turn ignition switch ON.
- C** Measure voltage between terminals VC and E2 of engine control module connector.

OK **Voltage: 4.5 – 5.5 V****OK****NG**

Check and replace ECM (See page [IN-36](#)).

Check for open in harness and connector between ECM and sensor (VC line) (See page [IN-31](#)).

INSPECTION PROCEDURE

OBD II scan tool (excluding TOYOTA hand-held tester)

HINT: If diagnostic trouble codes P0110, P0115, and P0120 are output simultaneously, E2 (sensor ground) may be open.

1


Connect the OBD II scan tool and read the throttle valve opening percentage (See page [EG2-467](#), step 1).

NG**OK**

Check for intermittent problems.
(See page [EG2-417](#))

2

Check voltage of terminal IDL and E2 of ECM.

**P**

(1) Remove glove compartment.
(See page [EG2-309](#))

(2) Turn ignition Switch ON.

C

Measure voltage between terminals IDL and E2 of ECM.

OK

Throttle Valve	Voltage
Fully closed	0 – 3.0 V
Fully open	9–14V

NG**OK**

Go to step

3

Check voltage between terminal VC of wire harness side connector and body ground (See page [EG2-468](#), step 3).

OK**NG**

Go to step **6**

4

Check throttle position sensor (See page [EG2-468](#), step 4).

OK**NG**

Replace throttle position sensor.

5

Check voltage between terminals VTA and E2 of ECM
(See page [EG2-469](#), step 5).

OK**NG**

Check for open and short in harness and connector between ECM and throttle position sensor (VTA line)
(See page [IN-31](#)).

Check and replace ECM (See page [IN-36](#)).

6

Check voltage terminals VC and E2 of ECM
(See page [EG2-469](#), step 6).

OK**NG**

Check and replace ECM (See page [IN-36](#)).

Check for open in harness and connector between ECM and sensor (VC line) (See page [IN-31](#)).


DTC P0121 Throttle Position Circuit Range Performance Problem

CIRCUIT DESCRIPTION

Refer to throttle position circuit malfunction on page [EG2-463](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0121	When closed throttle position switch is ON, condition a) continues. (2 trip detection logic) a) VTA) 2.0 V	<ul style="list-style-type: none">• Throttle position sensor.

DIAGNOSTIC CHART



DTC P0125 Insufficient Coolant Temp for Closed Loop Fuel Control

CIRCUIT DESCRIPTION

To obtain a high purification rate for the CO, HC and NOx components of the exhaust gas, a three-way catalytic converter is used, but for the most efficient use of the three-way catalytic converter, the air-fuel ratio must be precisely controlled so that it is always close to the stoichiometric air-fuel ratio.


The oxygen sensor has the characteristic whereby its output voltage changes suddenly in the vicinity of the stoichiometric air-fuel ratio. This characteristic is used to detect the oxygen concentration in the exhaust gas and provide feedback to the computer for control of the air-fuel ratio.

When the air-fuel ratio becomes LEAN, the oxygen concentration in the exhaust increases and the oxygen sensor informs the ECM of the LEAN condition (small electromotive force: 0 V).

When the air-fuel ratio is RICHER than the stoichiometric air-fuel ratio the oxygen concentration in the exhaust gas is reduced and the oxygen sensor informs the ECM of the RICH condition (large electromotive force: 1V)

The EMC judges by the electromotive force from the oxygen sensor whether the air-fuel ration is RICH or LEAN and controls the injection time accordingly. However, if malfunction of the oxygen sensor causes output of abnormal electromotive force, the EMC is unable to perform accurate air-fuel ration control.

The main heated oxygen sensors include a heater which heats the Zirconia element. The heater is controlled by the EMC. When the intake air volume is low (the temperature of the exhaust gas is low) current flows to the heater to heat the sensor for accurate oxygen concentration detection.



F14B35 F17210

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0125	<p>After the engine is warmed up, heated oxygen sensor output does not indicate RICH even once when conditions a) and b) continue for at least 2 minutes.</p> <p>a) Engine speed: 1,500 rpm or more b) Vehicle speed: 40 km/h (25 mph) or more</p>	<ul style="list-style-type: none"> • Open or short in heated oxygen sensor circuit. • Heated oxygen sensor.

HINT: After confirming DTC P0125 use the OBDII scan tool or TOYOTA hand-held tester to confirm voltage output of heated oxygen sensor from current data.

If voltage output of heated oxygen sensor is 0 V, heated oxygen sensor circuit may be open or short.

DIAGNOSTIC CHART

1

Connect the OBDII scan tool or TOYOTA hand-held tester and read value for voltage output of heated oxygen sensor.

OK

Check and replace ECM.

NG

2

Check for open and short in harness and connector between ECM and heated oxygen sensor.


NG

Repair or replace harness or connector.

OK

Replace heated oxygen sensor.


WIRING DIAGRAM



INSPECTION PROCEDURE

1

Connect the OBDII scan tool or TOYOTA hand-held tester and read value for voltage output of heated oxygen sensor.



FI7088

P

(1) Remove the fuse cover on the instrument panel.

(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.

(3) Warm up engine to normal operating temperature.

C

Read voltage output of heated oxygen sensor (bank 1,2 sensor 1) when engine is suddenly raced.

HINT

Perform quick racing to 4,000 rpm three times using accelerator pedal.

OK

Both heated oxygen sensors [(bank 1 sensor 1) (bank 2 sensor 1)] output a RICH signal (0.45 V or more) at least once.

NG**OK**

Check and replace ECM (See page [IN-36](#)).

2

Check for open and short in harness and connector between ECM and heated oxygen sensor (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

Replace heated oxygen sensor.

DTC P0130 P0150 Heated Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 1 Bank 2 Sensor 1)

CIRCUIT DESCRIPTION

Refer to "Insufficient coolant temp. for closed loop fuel control" on page [EG2-473](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0130 P0150	Voltage output of heated oxygen sensor remains at 0,4 V or more, or 0,55 V or less, during idling after the engine is warmed up. (2trip detection logic)	<ul style="list-style-type: none">• Heated oxygen sensor• Fuel trim malfunction


H I N T: Bank 1 refers to the bank that includes cylinder No.1.

Bank 2 refers to the bank that does not include cylinder No.1.

Sensor 1 refers to the sensor closer to the engine body.

The heated oxygen sensor's output voltage and the short-term fuel trim value can be read using the OBDII scan tool or TOYOTA hand-held tester.

CONFIRMATION DRIVING PATTERN



FI7130

- (1) Connect the TOYOTA hand-held tester to the DLC 3.
- (2) Switch the TOYOTA hand-held tester from normal mode to check mode (See page [EG2-403](#)).
- (3) Start the engine and warm it up with all accessory switches OFF.
- (4) After the engine is warmed up, drive at 50 – 65 km/h (31 – 40 mph) for 1 – 3 minutes to warm up the heated oxygen sensor.
- (5) After driving let the engine idle for 1 minute.

HINT: If a malfunction exists, the MIL will light up during step (5) .


NOTICE: If the conditions in this test are not strictly followed, detection of the malfunction will not be possible.

If you do not have a TOYOTA hand-held tester, turn the ignition switch OFF after performing steps (3) to (5), then perform steps (3) to (5) again.

DIAGNOSTIC CHART

1	Check for open and short in harness and connector between ECM and heated oxygen sensor.	NG	Repair or replace harness or connector.
OK			
2	Check heated oxygen sensor data.	OK	Check fuel trim system.
NG			
3	Check output voltage of heated oxygen sensor.	OK	Perform confirmation driving pattern.
NG			
	Replace heated oxygen sensor.		

WIRING DIAGRAM



INSPECTION PROCEDURE

1

Check for open and short in harness and connector between ECM and heated oxygen sensor (See page [IN-31](#)).


OK

NG

Repair or replace harness or connector.

2

Check for heated oxygen sensor data.



P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the OBD II scan tool or TOYOTA hand-held tester to the DLC 3.
- (3) Warm up engine to normal operating temperature.

C

Read the heated oxygen sensor output voltage and short-term fuel trim.

Hint

Read the values for the same bank.

Result

Pattern	Heated oxygen sensor output voltage	Short-term fuel trim
①	Lean condition (Changes at 0.55 V or less)	Changes at about +20%
②	Rich condition (Changes at 0.4 V or more)	Changes at about -20%
③	Except (1) and (2)	

F17088


③

(1),(2)

Check fuel trim system.
(See page [EG2-486](#)).

3

Check the output voltage of heated oxygen sensor during idling.



P

Warm up the heated oxygen sensor with the engine at 2,500 rpm for approx. 90 sec.

C

Use the OBD II scan tool or TOYOTA hand-held tester read the output voltage of the heated oxygen sensor during idling.

OK

Heated oxygen sensor output voltage:

Alternates repeatedly between less than 0.4 V and more than 0.55 V (See the adjacent table).

P18349

NG

OK

Perform confirmation driving pattern.
(See page [EG2-477](#)).

Replace heated oxygen sensor.

DTC P0133 P0153 Heated Oxygen Sensor Circuit Slow Response (Bank 1 Sensor 1 Bank 2 Sensor 1)

CIRCUIT DESCRIPTION

Refer to "Insufficient coolant temp. for closed loop fuel control" on page [EG2-473](#).


DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0133 P0153	Response time for the heated oxygen sensor's voltage output to change from rich to lean, or from lean to rich, is 1 sec. or more during idling after the engine is warmed up. (2 trip detection logic)	<ul style="list-style-type: none">• Heated oxygen sensor

HINT: Bank 1 refers to the bank that includes cylinder No.1.

Bank 2 refers to the bank that does not include cylinder No.1.

Sensor 1 refers to the sensor closer to the engine body.

DIAGNOSTIC CHART



DTC P0135 P0141 P0155 Heated Oxygen Sensor Heater Circuit Malfunction (Bank 1 Sensor 1 – Bank 1 Sensor 2 – Bank 2 Sensor 1)

CIRCUIT DESCRIPTION

Refer to "Insufficient coolant temp. for closed loop fuel control" on page [EG2-473](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0135 P0141 P0155	When the heater operates, heater current exceeds 2 A or voltage drop for the heater circuit exceeds 5 V. (2 trip detection logic)	<ul style="list-style-type: none">• Open or short in heater circuit of heated oxygen sensor.• Heated oxygen sensor heater• ECM
	Heater current of 0.25 A or less when the heater operates. (2 trip detection logic)	

H I N T: Bank 1 refers to the bank that includes cylinder No.1.

Bank 2 refers to the bank that does not include cylinder No.1.


Sensor 1 refers to the sensor closer to the engine body.

Sensor 2 refers to the sensor farther away from the engine body.


DIAGNOSTIC CHART

1	Check voltage of terminals HTR, HTS, HTL.	OK	Check and replace ECM.
NG			
2	Check resistance of heated oxygen sensor heater.	NG	Replace heated oxygen sensor.
OK			
Check and repair harness or connector between main relay and heated oxygen sensor and ECM.			

WIRING DIAGRAM



INSPECTION PROCEDURE

1**Check voltage between terminals HTR, HTS, HTL of ECM connector and body ground.**B66653
F17033**NG****P**


- (1) Remove glove compartment
(See page [EG2-309](#)).
- (2) Turn ignition switch ON.

C

Measure voltage between terminals HTR, HTS, HTL of ECM connector and body ground.

Hint

Connect terminal HTR to bank 1 sensor 1.
Connect terminal HTS to bank 1 sensor 2.
Connect terminal HTL to bank 2 sensor 1.

OK**Voltage: 9 –14 V****OK****Check and replace ECM (See page [IN-36](#)).****2****Check resistance of heated oxygen sensor heater.**

F16613

OK**P**

Disconnect heated oxygen sensor connector.

C

Measure resistance between terminals 1 and 2 of heated oxygen sensor connector.

OK**Resistance: 11 –16 at 20°C (68°F)****NG****Replace heated oxygen sensor.**

Check and repair harness or connector between main relay and heated oxygen sensor and ECM.

DTC P0136 Heated Oxygen Sensor Circuit Malfunction (Bank 1 Sensor 2)


CIRCUIT DESCRIPTION

Refer to "Insufficient coolant temp. for closed loop fuel control" on page [EG2-473](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P01 36	Voltage output of the heated oxygen sensor (bank 1 sensor 2) remains at 0.4 V or more or 0.5 V or less when the vehicle is driven at 50 km/h (31 mph) or more after the engine is warmed up. (2 trip detection logic)	<ul style="list-style-type: none"> Heated oxygen sensor

HINT: Bank 1 refers to the bank that includes cylinder No.1.
Sensor 2 refers to the sensor farther away from the engine body.

DIAGNOSTIC CHART



WIRING DIAGRAM

Refer to page [EG2-482](#) for the WIRING DIAGRAM.

INSPECTION PROCEDURE

1

Are there any other codes (besides DTC P0136) being output?

NO**YES**


Go to relevant diagnostic trouble code chart.

2Check for open and short in harness and connector between ECM and heated oxygen sensor (See page [IN-31](#)).**OK****NG**

Repair or replace harness or connector.

3

Check the output voltage of heated oxygen sensor (bank 1 sensor 2).

**P**

(1) Remove the fuse cover on the instrument panel.

(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.

(3) After warming up the engine, race the engine at 2,500 rpm for 3 mins.

C

Read the output voltage of heated oxygen sensor (bank 1 sensor 2) when racing the engine after 3 mins. have elapsed.

OK**Heated oxygen sensor output voltage:**
Alternates from 0.4 V or less to 0.5 V or more.

F17088

NG**OK**

Check that each connector is properly connected.

Replace heated oxygen sensor.

DTC P0171 System too Lean (Fuel Trim)

DTC P0172 System too Rich (Fuel Trim)

CIRCUIT DESCRIPTION

"Fuel trim" refers to the feedback compensation value compared against the basic injection time. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the air-fuel ratio at its ideal theoretical value. The signal from the heated oxygen sensor indicates whether the air-fuel ratio is RICH or LEAN compared to the ideal theoretical value, triggering a reduction in fuel volume if the air-fuel ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short-term fuel trim from the central value due to individual engine differences, wear over time and changes in the usage environment.

If both the short-term fuel trim and long-term fuel trim are LEAN or RICH beyond a certain value, it is detected as a malfunction and the MIL lights up.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0171	When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the RICH side. (2 trip detection logic)	<ul style="list-style-type: none">• Air intake (hose loose)• Fuel line pressure• Injector blockage• Heated oxygen sensor malfunction• Mass air flow meter• Engine coolant temp. sensor
P0172	When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the LEAN side. (2 trip detection logic)	<ul style="list-style-type: none">• Fuel line pressure• Injector leak, blockage• Heated oxygen sensor malfunction• Mass air flow meter• Engine coolant temp. sensor

HINT;

- When DTC P0171 is recorded, the actual air-fuel ratio is on the LEAN side. When DTC P0172 is recorded, the actual air-fuel ratio is on the RICH side,
- Fuel trim applies separately to bank 1 and bank 2, so the ECM lights up the MIL if a problem occurs with either bank.
- You can tell which bank is malfunctioning by looking at the short-term fuel trim and long-term fuel trim, thus allowing you to focus your inspection.
- If the total of the short-term fuel trim value and long-term fuel trim value for each bank is within $\pm 25\%$, the system is functioning normally.

DIAGNOSTIC CHART

1	Check air induction system.	NG	Repair or replace.
OK			
2	Check heated oxygen sensor data.	NG	Check heated oxygen sensor.
OK			
3	Check fuel pressure.	NG	Check and repair fuel pump, pressure regulator, fuel pipe line and filter.
OK			
4	Check injector injection.	NG	Replace injector.
OK			
5	Check mass air flow meter and engine coolant temp. sensor	NG	Repair or replace.
OK			
6	Check for spark and ignition.	NG	Repair or replace.
OK			
Check and replace ECM.			


INSPECTION PROCEDURE

1Check air induction system (See page [EG2-221](#)).**OK****NG**

Repair or replace.

2

Check for- heated oxygen sensor data.

**P**

(1) Remove the fuse cover on the instrument panel.

(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.

(3) Warm up engine to normal operating temperature.

C

Read the heated oxygen sensor output voltage and short-term fuel trim.


Read

Read the values for the same bank.

OK

Pattern	Heated oxygen sensor out put voltage	Short-term fuel trim
①	Lean condition Changes at 0.55 V or less	Changes at about + 20%
②	Rich condition Changes at 0.4 V or more	Changes at about - 20%

OK**NG**Check for heated oxygen sensor (See page [EG2-476](#)).

3**Check fuel pressure.**88663
P0003**OK****P**

(1) Install the SST (pressure gauge) to the fuel filter output (See page [EG2-231](#)).
SST 09268-45012

(2) Turn ignition switch ON.

(3) Connect the TOYOTA hand-held tester to data link connector 3 on the vehicle.

(4) Use ACTIVE TEST mode to operate the fuel pump.

Hint

Connecting terminals B and FP of data link connector 1 allows the fuel pump to be operated.

C

Measure the fuel pressure


OK

Fuel pressure: 265 – 304 kPa
(2.7 – 3.1 kg f/cm², 38 – 44 psi)

NG

Check and repair fuel pump, pressure regulator, fuel pipe line and filter.

(See page [EG2-230](#)).

4**Check injector injection.**P01077
P01010**OK****P**

Remove the delivery pipe and injectors from the bank that has the malfunction (See page [EG2-246](#)).

C

Check injection volume of injector
(See page [EG2-250](#)) .

OK

Injection volume:

56 – 69 cm³/15 sec. (3.4 – 4.2 cu in.)

Difference between each injector:

Less than 6 cm³ (0.4 cu in.)

Fuel drop (leakage):

One drop or less per minute.

NG

Replace injector.

5

Check mass air flow meter- and engine coolant temp. sensor
(See page [EG2-444](#), 457).

OK**NG**

Repair or replace.

6

Check for spark and ignition (See page IG-84).

OK**NG**

Repair or replace.

Check and replace ECM (See page [IN-36](#)).

DTC P0201 P0202 P0203 P0204 P0205 P0206 Injector Circuit Malfunction (Cylinder 1–6)

CIRCUIT DESCRIPTION

The injectors are located in the intake manifold. They inject fuel into the cylinders based on signals from the ECM.


The ECM detects a malfunction of the injector circuit by counting the number of misfires of a specific cylinder.

For an explanation of misfire detection requirements, see page DTC P0301.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0201 P0202 P0203 P0204 P0205 P0206	A specified cylinder misfire continuously. (2 trip detection logic)	<ul style="list-style-type: none">• Open or short in injector circuit• Injector blockage, seized• Ignition system• Valve clearance not to specification• Compression pressure

See the Diagnostic Chart and Inspection Procedure under "Misfiring".

WIRING DIAGRAM




FI6533

Reference INSPECTION USING OSCILLOSCOPE

INJECTOR SIGNAL WAVEFORM

- With the engine idling, measure between terminals #10 – #60 and E01 of ECM.

HINT: The correct waveform appears as shown in the illustration below.



FI6538 FI6538

DTC P0300 Random Misfire Detected

DTC P0301 P0302 P0303 P0304 P0305 P0306 Misfire Detected (Cylinder 1–6)

CIRCUIT DESCRIPTION

Misfire: The ECM uses the crankshaft position sensor and camshaft position sensor to monitor changes in the crankshaft rotation for each cylinder.


The ECM counts the number of times the engine speed change rate indicates that misfire has occurred. And when the misfire rate equals or exceeds the count indicating that the engine condition has deteriorated, the MIL lights up.

If the misfire rate is high enough and the driving conditions will cause catalyst overheating, the MIL blinks when misfiring occurs.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0300	Misfiring of multiple cylinders is detected during the same 200 or 1,000 revolutions.	<ul style="list-style-type: none"> • Ignition system • Injector • Fuel line pressure • EG R • Compression pressure • Valve clearance not to specification • Valve timing • Mass air flow meter • Engine coolant temp. sensor
P0301 P0302 P0303	For each 200 revolutions of the engine, misfiring is detected which can cause catalyst overheating. (This causes MIL to blink)	
P0304 P0305 P0306	For each 1,000 revolutions of the engine, misfiring is detected which causes emissions deterioration. (2 trip detection logic)	

HINT; When the code for a misfiring cylinder is recorded repeatedly but no Random Misfire code is recorded, it indicates that the misfires were detected and recorded at different times.

WIRING DIAGRAM




DIAGNOSTIC CHART

1	Check spark plug and spark of misfiring cylinder.	NG	Replace or check ignition system.
OK			
2	Check voltage of ECM terminal for injector of failed cylinder.	OK	Go to step 4
NG			
3	Check injector of misfiring cylinder.	NG	Replace injector.
OK			
Check for open and short in harness and connector between injector and ECM.			
4	Check fuel pressure.	NG	Repair or replace fuel pump.
OK			
5	Check injector injection.	NG	Replace injector.
OK			
6	Check EGR system.	NG	Repair EGR system.
OK			
7	Check mass air flow meter and engine coolant temp. sensor.	NG	Repair or replace.
OK			
Check engine mechanical systems.			

INSPECTION PROCEDURE

1

Check spark plug and spark of misfiring cylinder.



IG0317 IG0151
F17084

OK

- P** (1) Remove ignition coil (See page IG-87).
(2) Remove spark plug.

- C** (1) Check the carbon deposits on electrode.
(2) Check electrode gap.

OK (1) **No large carbon deposit present.**
Not wet with gasoline or oil.

(2) **Electrode gap: 1.1 – 1.3 mm**
(0.043 – 0.051 in.)

- P** (1) Install the spark plug to the ignition coil, and connect the ignition coil connector.
(2) Ground the spark plug.
(3) Disconnect injector connector.

- C** Check if spark occurs while engine is being cranked.

NOTICE: To prevent excess fuel being injected from the injectors during this test, don't crank the engine for more than 5–10 seconds at a time.

OK Spark jumps across electrode gap.

NG


Replace or check ignition system
(See page IG-84).

2

Check voltage of ECM terminal for injector of failed cylinder.



IG ON



8E8653
F17038

NG

- P** (1) Remove glove compartment
(See page EG2-309) .
(2) Turn ignition switch ON.

- C** Measure voltage between applicable terminal of ECM and body ground.


OK Voltage: 9 – 14 V

OK

Go to step **4**

3**Check injector of misfiring cylinder.**

Ohmmeter



PI4281

- P** Disconnect injector connector
(See page [EG2-243](#)) .
- C** Measure resistance of injector.
- OK** Resistance: 5 – 23 Ω at 20₂C (68₂F)

OK**NG****Replace injector.**

Check for open and short in harness and connector between injector and ECM
(See page [IN-31](#)).

4**Check fuel pressure.**

IG ON

265 – 304 kPa

B56653
P00053


- P** (1) Install the SST (pressure gauge) to the fuel filter outlet. (See page [EG2-231](#)) .
SST 09268-45012
- (2) Turn ignition switch ON.
- (3) Connect the TOYOTA hand-held tester to the DLC3.
- (4) Use ACTIVE TEST mode to operate the fuel pump.
- HINT: The fuel pump can be operated by connecting terminals B and FP of data link connector 1.

- C** Measure the fuel pressure.

- OK** Fuel pressure: 265 – 304 kPa
(2.7 – 3.1 kgf/cm², 38 – 44 psi)

OK**NG**

Check and repair fuel pump, pressure regulator, fuel pipe line and filter
(See page [EG2-230](#)).

5**Check injector injection.**

- P** Remove delivery pipe and injectors
(See page [EG2-246](#)) .
- C** Check injection volume of injector
(See page [EG2-250](#)) .
- OK** Injection volume:
56 – 69 cm³/15 sec. (3.4 – 4.2 cu in.)
Difference between each injector:
Less than 6 cm³ (0.4 cu in.)
Fuel drop (leakage):
One drop or less per minute.

OK**NG**

Replace injector.

6**Check EGR system (See page [EG2-207](#)).****OK****NG**

Repair EGR system.

7**Check mass air flow meter and engine coolant temp. sensor
(See page [EG2-444](#), 457).****OK****NG**

Repair or replace.

Check engine mechanical systems.

- Compression pressure (See page [EG2-36](#)).
- Valve clearance (See page [EG2-13](#)).
- Valve timing (See page [EG2-52](#)).

DTC P0325 P0330 Knock Sensor Circuit Malfunction (Knock Sensor 1 Knock Sensor 2)


CIRCUIT DESCRIPTION

Knock sensors are fitted one each to the right bank and left bank of the cylinder block to detect engine knocking. This sensor contains a piezoelectric element which generates a voltage when it becomes deformed, which occurs when the cylinder block vibrates due to knocking. If engine knocking occurs, ignition timing is retarded to suppress it.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0325	No knock sensor 1 signal to ECM with engine speed 2,000 rpm or more.	<ul style="list-style-type: none"> • Open or short in knock sensor 1 circuit. • Knock sensor 1 (looseness). • ECM
P0330	No knock sensor 2 signal to ECM with engine speed 2,000 rpm or more.	<ul style="list-style-type: none"> • Open or short in knock sensor 2 circuit. • Knock sensor 2 (looseness). • ECM


If the ECM detects the above diagnosis conditions, it operates the fail safe function in which the corrective retard angle value is set to the maximum value.

WIRING DIAGRAM



DIAGNOSTIC CHART

HINT: DTC P0325 is for the right bank knock sensor circuit.
DTC P0330 is for the left bank knock sensor circuit.



INSPECTION PROCEDURE


1

Connect the OBDII scan tool or TOYOTA hand-held tester and check the knock sensor circuit.




IG ON


TOYOTA Hand-Held Tester



DLC3



Male Connector Female Connector



8E6653
F1700B
F1700D
9e-4-1
9e-4-2

Type
I

- P** (1) Remove the fuse cover on the instrument panel.
(2) Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.
(3) Disconnect the wire to wire connector EE1.
(4) Connect the terminals of the disconnected EE1 male connector and EE1 female as follows.

Male connector ↔ Female connector

Terminal 1 ↔ Terminal 2

Terminal 2 ↔ Terminal 1

- (5) Turn ignition switch ON and OBDII scan tool or TOYOTA hand-held tester main switch ON.

- (6) After the engine is warmed up, perform quick racing (4,000 rpm) three times.

C Check the diagnostic trouble code.

Result

Type I	DTC same as when vehicle brought in. P0325→ P0325 or P0330→ P0330
Type II	DTC different to when vehicle brought in. P0325→ P0330 or P0330→ P0325

Type
II

Go to step **3**.

2

Check for open and short in harness and connector between EE1 connector and ECM (See page [IN-31](#)).

OK

NG


Repair or replace harness or connector.

Check and replace ECM (See page [IN-36](#)).

3


Check for open and short in harness and connector between EE1 connector and knock sensor (See page IN-31).

HINT: If DTC P0325 has changed to P0330, check the knock sensor circuit on the right bank side.
If DTC P0330 has changed to P0325, check the knock sensor circuit on the left bank side.

OK**NG****Repair or replace harness or connector.****Replace knock sensor.****Reference****INSPECTION USING OSCILLOSCOPE**

- With the engine racing (4,000 rpm) measure between terminals KNKR, KNKL of ECM and body ground.

HINT: The correct waveform appears as shown in the illustration on the left.



- Spread the time on the horizontal axis, and confirm that period of the wave is 141 μ sec. (Normal mode vibration frequency of knock sensor: 7.1 KHz).

HINT: If normal mode vibration frequency is not 7.1 KHz, the sensor is malfunctioning.

DTC P0335 Crankshaft Position Sensor Circuit Malfunction


CIRCUIT DESCRIPTION

Crankshaft position sensor (NE signal) consist of a signal plate and pick up coil.

The NE signal plate has 34 teeth and is mounted on the crankshaft. The NE signal sensor generates 34 signals for every engine revolution. The ECM detects the standard crankshaft angle based on the G22 signals, and the actual crankshaft angle and the engine speed by the NE signals.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P4335	No crankshaft position sensor signal to ECM during cranking. (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in crankshaft position sensor circuit. • Crankshaft position sensor. • Starter • ECM
	No crankshaft position sensor signal to ECM during engine running.	

WIRING DIAGRAM



DIAGNOSTIC CHART


HINT: Perform troubleshooting of diagnostic trouble code P0335 first. If no trouble is found, troubleshoot the following mechanical systems.

1	Check resistance of crankshaft position sensor.	NG	Replace sensor.
OK			
2	Check for open and short in harness and connector between ECM and crankshaft position sensor.	NG	Repair or replace harness or connector.
OK			
3	Inspect sensor installation and teeth of signal plate.	NG	Tighten the sensor. Replace signal plate.
OK			
Check and replace ECM.			

INSPECTION PROCEDURE

1**Check resistance of crankshaft position sensor.**

Crankshaft Position Sensor

FI7087
FI7086

- P** Disconnect crankshaft position sensor connector.
- C** Measure resistance of crankshaft position sensor.


OK

	Resistance
Cold	1,630 – 2,740 Ω
Hot	2,065 – 3,225 Ω

"Cold" is from -10_2C (14_2F) to 50_2C (122_2F) and
 "Hot" is from 50_2C (122_2F) to $1\ 00_2\text{C}$ (212_2F).

Reference **INSPECTION USING OSCILLOSCOPE**


G22, NE signal waveforms



20 m sec/Division (Idling)

- During cranking or idling, check between terminals G22(+) and G22 (-) , NE(+) and NE (-) of engine control module.

HINT: The correct waveforms appear as shown in the illustration on the left.



10 m sec/Division (Idling)

FI7089
FI7080**OK****NG****Replace crankshaft position sensor.**

2

Check for open and short in harness and connector between ECM and crankshaft position sensor (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

3

Inspect sensor installation and teeth of signal plate.

OK**NG**

Tighten the sensor.
Replace signal plate.

Check and replace ECM (See page [IN-36](#)).


DTC P0336 Crankshaft Position Sensor Circuit Range Performance

CIRCUIT DESCRIPTION

Refer to crankshaft position sensor circuit malfunction on page [EG2-503](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0336	Deviation in crankshaft position sensor signal and camshaft position sensor signal. (2 trip detection logic)	<ul style="list-style-type: none">• Mechanical system malfunction. (Skipping teeth of timing belt, belt stretched.)• ECM

DIAGNOSTIC CHART



DTC P0340 Camshaft Position Sensor Circuit Malfunction

CIRCUIT DESCRIPTION

Camshaft position sensor (G22 signal) consist of a signal plate and pick up coil.


The G22 signal plate has one tooth, on its outer circumference and is mounted on the left bank camshafts.

When the camshafts rotate, the protrusion on the signal plate and the air gap on the pick up coil change, causing fluctuations in the magnetic field and generating an electromotive force in the pick up coil.


The NE signal plate has 34 teeth and is mounted on the crankshaft. The NE signal sensor generates 34 signals for every engine revolution. The ECM detects the standard crankshaft angle based on the G22 signal and the actual crankshaft angle and the engine speed by the NE signals.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0340	No camshaft position sensor signal to ECM during cranking. (2 trip detection logic)	<ul style="list-style-type: none">• Open or short in camshaft position sensor circuit.• Camshaft position sensor.• Starter.• ECM
	No camshaft position sensor signal to ECM during engine running.	

DIAGNOSTIC CHART




WIRING DIAGRAM



INSPECTION PROCEDURE

1
Check resistance of camshaft position sensor.

Camshaft Position Sensor


P

Disconnect camshaft position sensor connector.


C

Measure resistance of camshaft position sensor.

OK


	Resistance
Cold	835 – 1,400Ω
Hot	1,060 – 1,645Ω

"Cold" is from -10°C (140°F) to 50°C (122°F) and
 "Hot" is from 50°C (122°F) to 100°C (212°F).




Reference INSPECTION USING OSCILLOSCOPE

G22 NE signal waveforms



- During cranking or idling, check between terminals G 22(+) and G22(-), NE(+) and NE (-) of engine control module.

HINT: The correct waveforms appear as shown in the illustration on the left.


OK
NG
Replace camshaft position sensor.

2

Check for open and short in harness and connector between ECM and camshaft position sensor (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

3

Inspect sensor installation.

OK**NG**

Tighten the sensor.

Check and replace ECM (See page [IN-36](#)).

DTC P0401 Exhaust Gas Recirculation Flow Insufficient Detected


CIRCUIT DESCRIPTION

The EGR system recirculates exhaust gas, which is controlled to the proper quantity to suit the driving conditions, into the intake air mixture to slow down combustion, reduce the combustion temperature and reduce NOx emissions. The amount of EGR is regulated by the EGR vacuum modulator according to the engine load.

If even one of the following conditions is fulfilled, the VSV is turned ON by a signal from the ECM. This results in atmospheric air acting on the EGR valve, closing the EGR valve and shutting off the exhaust gas (EGR cut-off).

Under the following conditions, EGR is cut to maintain driveability.


- Coolant temp. below 60°C (140°F).
- During deceleration (throttle valve closed).
- Light engine load (amount of intake air very small).
- Engine racing.



FI4825

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0401	After the engine is warmed up and run at 80 km/h (50 mph) for 3 to 5 minutes, the EGR gas temperature sensor value does not exceed 40°C (104°F) above the ambient air temperature. (2 trip detection logic)	<ul style="list-style-type: none"> • EGR valve stuck closed. • Short in EGR VSV circuit. • Open in EGR gas temp. sensor circuit. • EGR hose disconnected. • ECM

SYSTEM CHECK DRIVING PATTERN



#17131

- ① Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC 3.
- ② Start and warm up the engine with all accessories switched OFF.
- ③ After the engine is warmed up, run the vehicle at 70 – 90 km/h (43 – 56 mph) for 3 min, or more.
- ④ After driving, idle the engine for about 2 mins.
- ⑤ After idling, check the "READINESS TESTS". If "COMPL" (test completed) is displayed and the MIL does not light up, the system is normal. If "INCPL" is displayed, run the vehicle again and check it.
HINT: If a malfunction exists, the MIL will light up during step (4).

DIAGNOSTIC CHART

TOYOTA hand-held tester

1	Connect the TOYOTA hand-held tester and read value of EGR gas temperature.	OK	Go to step 4
NG			
2	Check for open in harness or ECM.	OK	Confirm good connection at sensor. If OK, replace EGR gas temp. sensor.
NG			
3	Check for open in harness or ECM.	OK	Open in harness between terminals E2 or THG. Repair or replace harness.
NG			
	Confirm connection at ECM, If OK, replace ECM.		
4	Check connection of vacuum hose, EGR hose.	NG	Repair or replace.
OK			
5	Check the VSV for EG R,	OK	Go to step 7
NG			
6	Check operation of the VSV for EG R.	NG	Replace VSV for EG R.
OK			
	Check for short in harness and connector between VSV and ECM.		

7

Check EGR Vacuum modulator.

NG

Repair or replace.

OK**8**

Check EGR Valve.

NG

Repair or replace.

OK**9**

Check value of EGR gas temp. sensor.

NG

Replace EGR gas temp. sensor.

OK

Check and replace ECM.

OBD II scan tool (excluding TOYOTA hand-held tester)**1**

Check resistance of EGR gas temp. sensor.

NG

Check and replace EGR gas temp. sensor.

OK**2**

Check for open in harness or ECM.

OKGo to step **4****NG****3**

Check for open in harness or ECM.

OK

Open in harness between terminals E2 or THG. Repair or replace harness.

NG

Confirm connection at ECM. If OK, replace ECM.

4

Check connection of vacuum hose, EGR hose.

NG

Repair or replace.

OK**5**

Check the VSV for EG R.

OKGo to step **7****NG****6**

Check operation of the VSV for EG R.

NG

Replace VSV for EG R.

OK

Check for open in harness and connector between J/B No.2 and ECM.

7

Check EGR vacuum modulator.

NG

Repair or replace.

OK**8**

Check EGR valve.

NG

Repair or replace.

OK**9**

Check resistance of EGR gas temp. sensor.


NG

Replace EGR gas temp. sensor.

OK

Check and replace ECM.

WIRING DIAGRAM



INSPECTION PROCEDURE


TOYOTA hand-held tester

1

Connect the TOYOTA hand-held tester and read value of EGR gas temperature value.



IG ON

8E6653
F17088

NG

P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the DLC 3.
- (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.

C

Read EGR gas temperature on the TOYOTA hand-held tester.

OK

EGR gas temp.: 10₂C (50₂F) or more.

Hint

If there is an open circuit, the TOYOTA hand-held tester indicates 3.1₂C (37.6₂F).

OK


Go to step 4

2

Check for open in harness or ECM.



IG ON

EGR Gas Temp.
Sensor8E6653
F17065

NG

P

- (1) Disconnect the EGR gas temp. sensor connector.
- (2) Connect sensor wire harness terminals together.
- (3) Turn ignition switch ON.

C

Read EGR gas temperature on the TOYOTA hand-held tester.

OK


EGR gas temp.: 159.3₂C (318.7₂F)

OK

Confirm good connection at sensor.
If OK, replace EGR gas temp. sensor.

3**Check for open in harness or ECM.**

IG ON

886853
F17057
F17104**NG**

Confirm connection at ECM.
If OK, replace ECM.

P

(1) Remove glove compartment

(See page [EG2-309](#)).

(2) Connect between terminals THG and E2 of ECM E8 and E9 connectors.

HINT: EGR gas temp. sensor connector is disconnected.

Before checking, do a visual check and contact pressure check for the ECM connector (See

Cpage [EG2-418](#)).

Read EGR temperature on the TOYOTA hand-held tester.

OK**EGR gas temp.: 159.3₂C (318.7₂F)****OK**

Open in harness between terminals E2 or
THG. Repair or replace harness.


4**Check the connection of the vacuum hose, EGR hose
(See page [EG2-287](#)).****OK****NG**

Repair or replace.

5**Check the VSV for EGR.**

IG ON

TOYOTA Hand-Held Tester




DLC3


P Select the active test mode on the TOYOTA hand-held tester.

C Check operation of EGR VSV, when it is operated by the TOYOTA hand-held tester.

OK **EGR system is OFF:**
The air from pipe E is flowing out through the air filter.
EGR system is ON:
The air from pipe E is flowing out pipe G.




System: OFF



System: ON

 BE6653
 F17088
 F17076
 F17075
NG**OK**Go to step **7**

6**Check operation of the VSV for EGR.****P**



(1) Remove EGR VSV.

(2) Disconnect EGR VSV connector.

C

(1) Measure resistance between terminals.

(2) Measure resistance between each terminal and the body.

OK(1) Resistance: 26 – 46 Ω at 20 $^{\circ}$ C (68 $^{\circ}$ F)(2) Resistance: 1 M Ω or higher.**C**


Check operation of EGR VSV when battery voltage is applied, and is not applied to the terminals of EGR VSV connector.

OK**Battery voltage is applied:**

The air from pipe E flows out through the air filter.

Battery voltage is not applied:

The air from pipe E flows out through pipe G.

EC2939
EC2940
EC2941
EC2942**OK****NG****Replace VSV for EGR.**Check for short in harness and connector between VSV and ECM (See page [IN-31](#)).

7Check EGR vacuum modulator (See page [EG2-210](#)).**OK****NG**

Repair or replace.

8Check EGR valve (See page [EG2-211](#)).**OK****NG**


Repair or replace.

9

Check value of EGR gas temp. sensor.



IG ON

**P**

(1) Connect the TOYOTA hand-held tester to the DLC3.

(2) Turn ignition switch ON and TOYOTA hand-held tester main switch ON'

(3) Select the active test mode on the TOYOTA hand-held tester.

(EGR system ON)

(4) Race the engine at 4,000 rpm for 3 mins.

C

Measure the EGR gas temp. while racing engine at 4,000 rpm.

OKEGR gas temp. after 3 mins.: **140₂C (284₂F)**
or moreBE6653
F17068**OK****NG**


Replace EGR gas temp. sensor.

Check and replace ECM (See page [IN-36](#)).

OBDII scan tool (excluding TOYOTA hand-held tester)

1

Check resistance of EGR gas temp. sensor.



FI7087

OK

P

Disconnect EGR gas temp. sensor connector.

C

Measure resistance between terminals of EGR gas temp. sensor connector.

OK

Resistance: 600 k or less.

Hint


If there is open circuit, ohmmeter indicates 720 kΩ or more.

NG

Check and replace EGR gas temp. sensor
(See page [EG2-303](#)).

2

Check for open in harness or ECM.



FI7088

NG

P

Disconnect EGR gas temp. sensor connector.

C

Measure voltage between terminals of EGR gas temp. sensor wire harness side connector.

OK


Voltage: 4.5 – 5.5 V

OK

Go to step **4**

3

Check for open in harness or ECM.

BE663
FI7036

NG

P

(1) Remove glove compartment (See page EG2-309).

(2) Turn ignition switch ON.

C

Measure voltage between terminals THG and E2 of ECM.

HINT: EGR gas temp. sensor connector is disconnected.

OK

Voltage: 4.5 – 5.5 V

OK

Open in harness between terminals E2 or THG. repair or replace harness.


Confirm connection at ECM.
If OK, replace ECM.

4Check connection of vacuum hose, EGR hose (See page [EG2-287](#)).**OK****NG**

Repair or replace.

5

Check the VSV for EGR.

 IG ON
**NG****OK**Go to step **7****6**Check operation of the VSV for- EGR (See page [EG2-522](#), step **6**).**OK****NG**

Replace VSV for EGR.

Check for open in harness and connector
between J/B No.2 and ECM (See page [IN-31](#)).

7Check EGR vacuum modulator (See page [EG2-210](#)).

OK

NG

Repair or replace.

8Check EGR valve (See page [EG2-211](#)).


OK

NG

Repair or replace.

9

Check resistance of EGR gas temp. sensor.



- P** (1) Disconnect EGR gas temp. sensor connector.
(2) Start the engine and warm it up.
(3) Disconnect EGR VSV connector.
(4) Race the engine at 4,000 rpm for 3 mins.
- C** Measure the resistance of the EGR gas temp. sensor while racing the engine at 4,000 rpm.
- OK** **Resistance of EGR gas temp. sensor after 3 mins:**
4.3 kΩ or less
- Hint** Resistance: 188.6 – 439.0 kΩ at 20°C (68°F)

FI7176

OK

NG

Replace EGR gas temp. sensor.

Check and replace ECM (See page [IN-36](#)).

DTC P0402 Exhaust Gas Recirculation Flow Excessive Detected

CIRCUIT DESCRIPTION


Refer to Exhaust gas recirculation flow insufficient detected on page [EG2-512](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0402	EG R gas temp. sensor value is high during EG R cut-off when engine is cold (Race engine at about 4,000 rpm without load so that vacuum is applied to port E). (2 trip detection logic)	<ul style="list-style-type: none">• EGR valve stuck open• EGR VSV open malfunction• Open in EGR VSV circuit• Short in EGR gas temp. sensor circuit• ECM
	EG R valve is always open (2 trip detection logic)	

See DTC P0401 for System Check Driving Pattern and Wiring Diagram.

DIAGNOSTIC CHART

TOYOTA hand-held tester



OBD II scan tool (excluding TOYOTA hand-held tester)**1**

Check resistance of EGR gas temp. sensor.

NG

Replace EGR gas temp. sensor.

OK**2**

Check for short in harness and connector between EGR gas temp. sensor and ECM.

NG

Repair or replace harness or connector.

OK**3**

Check the VSV for EG R.

OK

Check EGR valve.

NG**4**

Check operation of the VSV for EG R.

NG

Replace VSV for EG R.

OK**5**

Check for open in harness and connector between J/B No.2 and ECM.

NG

Repair or replace harness or connector.

OK

Check and replace ECM.

INSPECTION PROCEDURE

TOYOTA hand-held tester

1

Connect the TOYOTA hand-held tester and read EGR gas temperature value.



IG ON

TOYOTA Hand-Held Tester



DLC3

BE0663
FI7053**NG****P**

(1) Remove the fuse cover on the instrument panel.

(2) Connect the TOYOTA hand-held tester to the D LC 3.

(3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.

C

Read EGR gas temperature on the TOYOTA hand-held tester.

OK

EGR gas temp.: 150₂C (302₂F) or less.

(Not immediately after driving)

Hint

If there is a short circuit, the TOYOTA hand-held tester indicates 159.3₂C (318.7₂F) .


OKGo to step **4****2**

Check for short in harness and ECM.



IG ON

EGR Gas Temp. Sensor

BE0663
FI7054**NG****P**

Disconnect the EGR gas temperature sensor connector.

C


Rear EGR gas temperature on the TOYOTA hand-held tester.

OK

EGR gas temp.: 3.1₂C (37.6₂F)

OK


Replace EGR gas temp. sensor.

3**Check for short in harness or ECM.****NG**

- P** (1) Remove glove compartment
(See page [EG2-309](#)) .
(2) Disconnect the E9 connector of ECM.
HINT: EGR gas temp. sensor is disconnected.

- C** Read EGR gas temp. on the TOYOTA hand-held tester.

- OK** EGR gas temp.: 3.1 ₂C (37.6₂F)

OK**Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).****4****Check the VSV for EGR.**

- P** Select the active test mode on the TOYOTA hand-held tester.


- C** Check operation of EGR VSV, when it is operated by the TOYOTA hand-held tester.

- OK** EGR system is OFF:

The air from pipe E flows out through the air filter.



EGR system is ON:

The air from pipe E flows out through pipe G.




BE6653
F17088
F17076
F17075

NG**OK****Check EGR valve (See page [EG2-211](#)).**


5**Check operation of the VSV for EGR.**

- P** (1) Remove EGR VSV.
 (2) Disconnect EGR VSV connector.
- C** (1) Measure resistance between terminals.
 (2) Measure resistance between each terminal and the body.
- OK** (1) Resistance: 26 – 46 Ω at 20°C (68°F)
 (2) Resistance: 1 M Ω or higher.




- C** Check operation of EGR VSV when battery voltage is applied, and not applied to the terminals of EGR VSV connector or not.

- OK** **Battery voltage is applied:**
 The air from pipe E flows out through the air filter.
- Battery voltage is not applied:**
 The air from pipe E flows out through pipe G.


 EC2939
 EC2940
 EC2941
 EC2942
OK**NG****Replace VSV for EG R.**

Check for open in harness and connector
 between J/B No.2 and ECM (See page [IN-31](#)).

OBDII scan tool (excluding TOYOTA hand-held tester)**1****Check resistance of EGR gas temp. sensor.**

FI7176

OK**P**Disconnect EGR gas temp. sensor connector (See page [EG2-303](#)).**C**

Measure resistance between terminals of EGR gas temp. sensor connector.

OK**Resistance: 2.5 k Ω or more.****(Not immediately after driving)****Hint**If there is short circuit, ohmmeter indicates 200 Ω or less.**NG****Replace EGR gas temp. sensor.****2****Check for short in harness and connector between EGR gas temp. sensor and ECM (See page [IN-31](#)).****OK****NG****Repair or replace harness or connector.****3****Check the VSV for EGR (See page [EG2-525](#), step **5**).****NG****OK****Check EGR valve (See page [EG2-211](#)).****4****Check operation of the VSV for EGR (See page [EG2-532](#), step **5**).****OK****NG****Replace VSV for EGR.****5****Check for open in harness and connector between J/B No.2 and ECM (See page [IN-31](#)).****OK****NG****Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).**

DTC P0420 Catalyst System Efficiency Below Threshold


CIRCUIT DESCRIPTION

The ECM compares the waveform of the oxygen sensor located before the catalyst with the waveform of the oxygen sensor located after the catalyst to determine whether or not catalyst performance has deteriorated.

Air-fuel ratio feedback compensation keeps the waveform of the oxygen sensor before the catalyst repeatedly changing back and forth from rich to lean.

If the catalyst is functioning normally, the waveform of the oxygen sensor after the catalyst switches back and forth between rich and lean much more slowly than the waveform of the oxygen sensor before the catalyst.

But when both waveforms change at a similar rate, it indicates that catalyst performance has deteriorated.




F17081

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0420	After the engine is warmed up and the vehicle driven for 5 min. at 32 – 80 km/h (20 – 50 mph), the waveforms of the heated oxygen sensors, bank 1, 2 sensor 1 and bank 1 sensor 2 have the same amplitude.	<ul style="list-style-type: none">• Three-way catalytic converter• Open or short in heated oxygen sensor circuit• Heated oxygen sensor

HINT: Only on U.S. vehicles does the MIL light up when a malfunction is detected.

SYSTEM CHECK DRIVING PATTERN



FI7132

- ① Connect the OBDII scan tool or TOYOTA hand-held tester to the DLC3.
- ② Start and warm up the engine with all accessories switched OFF.
- ③ After the engine is warmed up, run the vehicle at 50 – 65 km/h (31 – 40 mph) for 5 – 10 min.
HINT: If a malfunction exists, the MIL will light up during step (3) .


DIAGNOSTIC CHART

1	Are there any other codes (besides DTC P0420) being output?	YES	Go to relevant diagnostic trouble code chart.
NO			
2	Check heated oxygen sensor. (See page EG2-476).	NG	Repair or replace.
OK			
Replace three-way catalytic converter.			

DTC P0500 Vehicle Speed Sensor Malfunction

CIRCUIT DESCRIPTION


The vehicle speed sensor outputs a 4-pulse signal for every revolution of the rotor shaft, which is rotated by the transmission output shaft via the driven gear. After this signal is converted into a more precise rectangular waveform by the waveform shaping circuit inside the combination meter, it is then transmitted to the ECM. The ECM determines the vehicle speed based on the frequency of these pulse signals.



Q00515 Q00514

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0500	No vehicle speed sensor signal to ECM under conditions (a) and (b). (a) Park/neutral position switch is OFF. (b) Vehicle is being driven.	<ul style="list-style-type: none"> • Open or short in vehicle speed sensor circuit. • Vehicle speed sensor • Combination meter • ECM

WIRING DIAGRAM



F1713B

DIAGNOSTIC CHART

1	Check operation of speedometer.	NG	Check speedometer circuit
OK			
2	Check for short in harness and connector between terminal SP1 and body ground.	NG	Repair or replace harness or connector.
OK			
3	Check voltage of terminal SP1.	NG	Check for open in harness and connector between J/B No.3 and ECM.
OK			
4	Check for open in harness and connector between J/6 No.3 and combination meter.	NG	Repair or replace harness or connector.
OK			
Check and replace ECM.			

INSPECTION PROCEDURE

1 Check operation of speedometer.


- C** Drive the vehicle and check if the operation of the speedometer in the combination meter is normal,
HINT: The vehicle speed sensor is operating normally if the speedometer display is normal.

OK

NG

Check speedometer circuit. See combination meter troubleshooting on page [BE-66](#).

2 Check for short in harness and connector between terminal SP1 of ECM and body ground.



F17024

OK


NG

Repair or replace harness or connector.

3 Check voltage between terminal SP1 of ECM and body ground.



IG ON

BE0653
F17129

OK

NG

- P** Turn ignition switch ON.
C Measure voltage between terminal SP1 of ECM and body ground.
OK Voltage: 9 –14 V

Check for open in harness and connector between J/B No.3 and ECM (See page [IN-31](#)).

4

Check for open in harness and connector between J/B No.3 and combination meter (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

Check and replace ECM (See page [IN-36](#)).


DTC P0505 Idle Control System Malfunction

CIRCUIT DESCRIPTION

The rotary solenoid type IAC valve is located in front of the intake air chamber and intake air bypassing the throttle valve is directed to the IAC valve through a passage.


In this way the intake air volume bypassing the throttle valve is regulated, controlling the engine speed.

The ECM operates only the IAC valve to perform idle-up and provide feedback for the target idling speed and a VSV for idle-up control is also added (for air conditioning).



DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0505	Idle speed continues to vary greatly from the target speed. (2 trip detection logic)	<ul style="list-style-type: none"> IAC valve is stuck or closed open or short in IAC valve circuit Air conditioner idle up VSV Air intake (hose loose)

WIRING DIAGRAM



DIAGNOSTIC CHART

1	Check air induction system.	NG	Repair or replace.
OK			
2	Check A/C idle up VSV.	NG	Repair or replace.
OK			
3	Check voltage terminals RSO, RSC.	OK	Go to step 5
NG			
4	Check IAC valve.	NG	Replace IAC valve.
OK			
Check for open and short in harness and connector between J/B No.2 and IAC valve, IAC valve and ECM.			
5	Check operation of the IAC valve.	NG	Repair or replace IAC valve.
OK			
Check and replace ECM.			

INSPECTION PROCEDURE

1Check air induction system (See page [EG2-221](#)).**OK****NG**


Repair or replace.

2Check A/C idle up VSV (See page [EG2-570](#)).**OK****NG**

Repair or replace.

3

Check voltage terminals RSO, RSC.

BE6853
F7080**P**

- (1) Remove glove compartment (See page [EG2-309](#)).
- (2) Disconnect the ECM connector (P).
- (3) Turn ignition switch ON.

C

Measure voltage between terminals RSO, RSC of ECM connector and body ground.


OK

Voltage: 9 –14 V

NG**OK**Go to step **5**.

4

Check IAC valve.



F/7083
F/7082

OK

- P** Disconnect the IAC valve connector.
- C** Check continuity between terminals RSO, RSC and B of IAC valve connector.

OK	<table><tr><td>Terminals RSO and B</td><td>Continuity (Reference value 10 – 30Ω)</td></tr><tr><td>Terminals RSC and B</td><td>Continuity (Reference value 10 – 30Ω)</td></tr></table>	Terminals RSO and B	Continuity (Reference value 10 – 30Ω)	Terminals RSC and B	Continuity (Reference value 10 – 30Ω)
Terminals RSO and B	Continuity (Reference value 10 – 30Ω)				
Terminals RSC and B	Continuity (Reference value 10 – 30Ω)				



NG

Replace IAC valve.

Check for open and short in harness and connector between J/B No.2 and IAC valve, IAC valve and ECM (See page [IN-31](#)).

5

Check operation of the IAC valve

F15039
F15771

P Remove IAC valve (See page [EG2-274](#)).



C (1) Connect the positive (+) lead from the battery to terminal B and negative (-) lead to terminal RSC, and check that the valve is closed.

(2) Connect the positive (+) lead from the battery to terminal B and negative (-) lead to terminal RSO, and check that the valve is open.

OK (1) The valve moves to close direction.

(2) The valve moves to open direction.

Hint The ACTIVE TEST mode of the TOYOTA hand-held tester can be used to change the duty of the IAC valve as desired.

F15039
F15772

OK

NG

Repair or replace IAC valve.

Check and replace ECM (See page [IN-36](#)).

DTC P0510 Closed Throttle Position Switch Malfunction

CIRCUIT DESCRIPTION


Refer to throttle Position Circuit on page [EG2-463](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P0510	The closed throttle position switch does not turn ON even once when the vehicle is driven, (2 trip detection logic)	<ul style="list-style-type: none"> Open in closed throttle position switch circuit. Closed throttle position switch. ECM

HINT: After confirming DTC P0510 use the TOYOTA hand-held tester to confirm the closed throttle position switch signal from "CURRENT DATA".

Throttle Valve	Closed throttle position switch signal	Malfunction
Fully Closed	OFF	Open Circuit
Fully Open	ON	Short Circuit

WIRING DIAGRAM




F16873


DIAGNOSTIC CHART

HINT: If diagnostic trouble codes "P0110" (intake air temp. circuit malfunction), "P0115" (engine coolant temp. circuit malfunction) and "P0120" (throttle position circuit malfunction) are output simultaneously, E2 (sensor ground) may be open.

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)



INSPECTION PROCEDURE



HINT: If diagnostic trouble codes P0110, P0115 and P0120 are output simultaneously, E2 (sensor ground) may be open.

TOYOTA hand-held tester

1
Check for open in harness or ECM.


IG ON

Throttle Position Sensor


 BE0653
FI7058

NG
P




- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the DLC 3.
- (3) Disconnect the throttle position sensor connector.
- (4) Connect sensor wire harness terminals between terminals 1 and 2.
- (5) Turn ignition switch ON.

C

Read CTP switch signal on the TOYOTA hand-held tester.

OK
CTP switch signal: ON
OK
Confirm good connection at sensor. If OK, replace throttle position sensor.
2
Check for open in harness or ECM.


IG ON


 BE0653
FI7064
FI7043

NG
P

- (1) Remove glove compartment.
(See page BO-309)

- (2) Connect between terminals IDL and E2 of ECM connectors.

H I N T: Throttle position sensor connector is disconnected. Before checking, do a visual check and contact pressure -check for the connector.

(See page [EG2-418](#))

- (3) Turn ignition switch ON.

C


Read CTP switch signal on the TOYOTA hand-held tester.

OK
CTP switch signal: ON
OK
Open in harness between ECM and throttle position sensor, repair or replace harness.
Confirm connection at ECM. If OK, replace ECM.

OBDII scan tool (excluding TOYOTA hand-held tester)

1

Check for open in harness or ECM.



P (1) Disconnect the throttle position sensor connector.

(2) Turn ignition switch ON.

C Measure voltage between terminals 1 and 2 of throttle position sensor connector.

OK Voltage: 9 –14 V

NG

OK

Confirm good connection at sensor.
If OK, replace throttle position sensor.

2

Check for open in harness and connector between throttle position sensor and ECM (See page [IN-31](#)).

OK

NG

Open in harness between ECM and throttle position sensor.

Confirm connection at ECM. If OK, replace ECM.

DTC P1300 Igniter Circuit Malfunction

CIRCUIT DESCRIPTION

The ECM determines the ignition timing, turns on Tr1 at a predetermined angle ("CA) before the desired ignition timing and outputs an ignition signal (IGT) "1" to the igniter.

Since the width of the IGT signal is constant, the dwell angle control circuit in the igniter determines the time the control circuit starts primary current flow to the ignition coil based on the engine rpm and ignition timing one revolution ago, that is, the time the Tr2 turns on.


When it reaches the ignition timing, the ECM turns Tr1 off and outputs the IGT signal "0".

This turns Tr2 off, interrupting the primary current flow and generating a high voltage in the secondary coil which causes the spark plug to spark. Also, by the counter electromotive force generated when the primary current is interrupted, the igniter sends an ignition confirmation signal (IGF) to the ECM.

The ECM stops fuel injection as a fail safe function when the IGF signal is not input to the ECM.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P1300	No IGF signal to ECM for 6 consecutive IGT signals during engine running.	<ul style="list-style-type: none"> Open or short in IGF or IGT circuit from igniter to ECM. Igniter ECM

WIRING DIAGRAM



* Terminal IG ⊖ of DLC1

DIAGNOSTIC CHART

1	Check voltage igniter power source.	NG	Check and repair igniter power source circuit.
OK			
2	Check voltage between terminals 2 – 7 of igniter connector (12) and body ground.	OK	Go to step 4
NG			
3	Check ignition coil.	NG	Replace ignition coil.
OK			
Check for open and short in harness and connector between J/B No.1 and ignition coil, ignition coil and igniter.			
4	Check continuity between terminal 7 of igniter and body ground.	NG	Repair or replace harness or connector.
OK			
5	Check voltage between terminal 8 of igniter connector (115) and body ground.	OK	Go to step 7
NG			
6	Check for open and short in IGF circuit.	NG	Repair or replace harness or connector.
OK			
Check and replace ECM.			

7

Check for open and short in IGT circuit.

NG

Repair or replace harness or connector.

OK**8**

Check voltage between terminals IGT 1 – 6 of ECM and body ground.

OK

Replace igniter.


NG

Check and replace ECM.

INSPECTION PROCEDURE

1

Check voltage between terminal 1 of igniter connector (12) and body ground.

BE6653
F17051

OK

- P** (1) Disconnect igniter connector (12)
(2) Turn ignition switch ON.

- Hint** Connector 12 color is dark gray
C Measure voltage between terminal 1 of igniter connector 12 and body ground.


OK Voltage: 9 – 14 V

NG

Check and repair igniter power source circuit.

2

Check voltage between terminals 2 – 7 of igniter connector and body ground.

BE6653
F17150


NG

- C** Measure voltage between terminals 2 – 7 of igniter connector (12) and body ground.

OK Voltage: 9 – 14 V

OK

Go to step **4**

3**Check ignition coil.**F17079
F17086**OK**

P Disconnect ignition coil connector.
(See page IG-87).

Hint Refer to the wiring diagram and inspect the ignition coil connected to the terminal which was without voltage in step (2) .

C Measure resistance between terminals of ignition coil connector.


OK

	Resistance
Cold	0.54 – 0.84Ω
Hot	0.68 – 0.98Ω

"Cold" is from -10°C (14°F) to 50°C (122°F) and
"Hot" is from 50°C (122°F) to 100°C (212°F).

NG**Replace ignition coil.**

Check for open and short in harness and connector between J/B No.1 and ignition coil, ignition coil and igniter (See page IN-31).

4**Check continuity between terminal 7 of igniter connector (I15) and body ground.**

F17149

OK

P Disconnect igniter connector(I15)

Hint Connector (I15) is black.


C Check continuity between terminal 7 of igniter connector (I15) and body ground.

OK Continuity (1 or less)

NG**Repair or replace harness or connector.**

5**Check voltage between terminal 8 of igniter connector (I15) and body ground.**

IG ON

**P**

Turn ignition switch ON.

C

Measure voltage between terminal 8 of igniter connector (I15) and body ground.

OK

Voltage: 4.5 – 5.5 V

BEG663
F7151**NG****OK**

Go to step (7)

6**Check for open and short in harness and connector between terminal IGF of ECM and igniter (See page [IN-31](#)).****OK****NG**

Repair or replace harness or connector.

Check and replace ECM (See page [IN-36](#)).

7


Check for open and short in harness and connector between terminals IGT1 – of ECM and igniter (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

8

Check voltage between terminals IGT1 – 6 of ECM and body ground.

**P**

Remove glove compartment (See page [EG2-309](#)).

Hint

Leave igniter connector 115 disconnected.

C

Measure voltage between terminals IGT1 – 6 of ECM and body ground when engine is cranked.

OK


Voltage: 0.5 – 1.0 v (Neither 0 v nor 5 v)

NG**OK**

Replace igniter.

Check and replace ECM (See page [IN-36](#)).

Reference INSPECTION USING OSCILLOSCOPE



F10502

- During idling, check waveform between terminal IGT1, IGF and E1 of ECM.

HINT: The correct waveform appears as shown in the illustration on the left, with rectangular waves.

IGT2, IGT3, IGT4, IGT5 and IGT6 signal waveforms are the same as the IGT1 signal waveform.

DTC P1500 Starter Signal Circuit Malfunction

CIRCUIT DESCRIPTION


When the engine is cranked, the intake air flow is slow, so fuel vaporization is poor. A rich mixture is therefore necessary in order to achieve good startability. While the engine is being cranked, the battery voltage is applied to terminal STA of the ECM. The starter signal is mainly used to increase the fuel injection volume for the starting injection control and after-start injection control.

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P1500	No starter signal to ECM.	<ul style="list-style-type: none"> Open or short in starter signal circuit. Open or short in ignition switch or starter relay circuit. ECM


HINT: In this circuit, diagnosis can only be made in the check mode.

DIAGNOSTIC CHART

HINT: This diagnostic chart is based on the premise that the engine is cranked normally. If the engine is not cranked, proceed to the matrix chart of problem symptoms on page [EG2-435](#).



WIRING DIAGRAM



INSPECTION PROCEDURE

1

Connect the TOYOTA hand-held tester and check STA signal.



NG

- P

(1) Remove the fuse cover on the instrument panel.
(2) Connect the TOYOTA hand-held tester to the DLC 3.
(3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.
- C

Read STA signal on the TOYOTA hand-held tester while starter operates.
- OK

Ignition Switch Position	STA Signal
ON	OFF
START	ON

OK

Proceed to next circuit inspection shown on matrix chart (See page EG2-435).

2

Check for open in harness and connector between ECM and starter relay (See page IN-31).

OK

NG

Repair or replace harness or connector.

Check and replace ECM (See page IN-36).

DTC P1600 EMC BATT Malfunction


CIRCUIT DESCRIPTION

Battery voltage is supplied to terminal BATT of the ECM even when the ignition switch is OFF for use by the diagnostic trouble code memory and air-fuel ratio adaptive control value memory, etc.


DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P1600	Open in back up power source circuit.	<ul style="list-style-type: none"> Open in back up power source circuit. ECM

HINT: If DTC P1600 appear, the ECM does not store another diagnostic trouble code.

DIAGNOSTIC CHART



WIRING DIAGRAM




INSPECTION PROCEDURE

1

Check voltage between terminal BATT of ECM connector and body ground.



IG OFF



BE6653
F16807

NG

P

Remove glove compartment.
(See page [EG2-309](#))

C

Measure voltage between terminal BATT of ECM connector and body ground.

OK


Voltage: 9 -14 V

OK

Check and replace ECM (See page [IN-36](#)).

2

Check EFI fuse.



J/B No.2

F17078

OK

P

Remove EFI fuse from J/B No.2.

C

Check continuity of EFI fuse.

OK

Continuity

NG

Check for short in all the harness and components connected to EFI fuse.

Check and repair harness or connector between battery, EFI fuse and ECM.

DTC P1605 Knock Control CPU Malfunction

CIRCUIT DESCRIPTION


Refer to knock sensor 1 circuit malfunction on page [EG2-499](#).

DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P1605	Engine control computer malfunction. (for knock control)	<ul style="list-style-type: none">ECM

WIRING DIAGRAM

Refer to knock sensor 1 circuit malfunction on page [EG2-499](#).

DIAGNOSTIC CHART



DTC P1780 Park Neutral Position Switch Malfunction

CIRCUIT DESCRIPTION

The park/neutral position switch goes on when the shift lever is in the N or P shift position. When it goes on terminal NSW of the ECM is grounded to body ground via the starter relay thus the terminal NSW voltage becomes 0 V, When the shift lever is in the D, 2, L or R position, the park/neutral position switch goes off, so the voltage of ECM terminal NSW becomes battery voltage, the voltage of the ECM internal power source.

If the shift lever is moved from the N position to the D position, this signal is used for air–fuel ratio correction and for idle speed control (estimated control), etc.


DTC No.	Diagnostic Trouble Code Detecting Condition	Trouble Area
P1780	Two or more switches are ON simultaneously for "N", "2" and "L" position. (2 trip detection logic)	<ul style="list-style-type: none">• Short in park/neutral position switch circuit.• Park/neutral position switch.• ECM
	When driving under conditions a) and b) for 30 sec. or more the park/neutral position switch is ON (N position). (2 trip detection logic) a) Vehicle speed; 70 km/h (44 mph) or more b) Engine speed; 1,500 – 2,500 rpm	

HINT: After confirming DTC P1780 use the TOYOTA hand–held tester to confirm the PNP switch signal from "CURRENT DATA".

DIAGNOSTIC CHART

1	Check park/neutral position switch.	NG	Replace park/neutral position switch.
OK			
2	Check voltage between terminal NSW of ECM connector and body ground.	OK	Check and replace ECM.
NG			
Check for open and short in harness and connector between ECM and park/neutral position switch.			


WIRING DIAGRAM



INSPECTION PROCEDURE

1

Check park/neutral position switch.



Q03164

P Disconnect park/neutral position switch connector.

C Check continuity between each terminal shown below when the shift lever is positioned to each range.

OK

		Continuity									
Shift Position	Terminal	5	6	2	7	8	9	10	3	4	
P		○	○	○	○						
R				○	○	○					
N		○	○	○	○		○				
D				○	○			○			
2				○	○				○		
L				○	○					○	

OK


NG

Replace park/neutral position switch.

2

Check voltage between terminal NSW of ECM connector and body ground.

IG ON

BE6053
F17041

NG

P Remove glove compartment.

(See page [EG2-309](#))

C

(1) Turn ignition switch ON.

(2) Measure voltage between terminal NSW of ECM connector and body ground when the shift lever is positioned to the following positions.

OK

Shift lever position	P or N	L,2,D or R
Voltage	0 V	9-14V

OK

Check and replace ECM (See page [IN-36](#)).


Check for open and short in harness and connector between ECM and park/neutral position switch (See page [IN-31](#)).

ECM Power Source Circuit

CIRCUIT DESCRIPTION

When the ignition switch is turned ON, battery voltage is applied to the coil, closing the contacts of the EFI main relay and supplying power to the terminals + B and + B1 of the ECM.

WIRING DIAGRAM



F17014


DIAGNOSTIC CHART

1	Check voltage of ECM power source.	OK	Proceed to next circuit inspection shown on matrix chart .
NG			
2	Check continuity between terminal E1 and body ground.	NG	Repair or replace harness or connector.
OK			
3	Check EFI main relay.	NG	Replace EFI main relay.
OK			
4	Check EFI fuse.	NG	Check for short in all the harness and components connected to EFI fuse.
OK			
5	Check for open in harness and connector between main relay and battery, main relay and ECM.	NG	Repair or replace harness or connector.
OK			
6	Check I G N fuse.	NG	Check for short in all the harness and components connected to IGN fuse.
OK			
7	Check ignition switch.	NG	Replace ignition switch.
OK			
Check for open in harness and connector between IG switch and main relay, main relay and body ground.			

INSPECTION PROCEDURE

1**Check voltage between terminals + B, + B1 and E1 of ECM connector.**

IG ON

BE6653
FI7025**NG****P**(1) Remove glove compartment.
(See page [EG2-309](#))




(2) Turn ignition switch ON.

C

Measure voltage between terminals + B, + 1B and E1 of ECM connector.

OK**Voltage: 9 –14 V****OK**Proceed to next circuit inspection shown on matrix chart (See page [EG2-435](#)).**2****Check for open in harness and connector between terminal E1 of ECM and body ground (See page [IN-31](#)).****OK****NG**

Repair or replace harness or connector.

3**Check EFI main relay.**BE1841
P04590
P04591**OK****P**

Remove EFI main relay from J/B No-2.

C

Check continuity between terminals of EFI main relay shown below.

OK

Terminals 3 and 5	Open
Terminals 1 and 2	Continuity (Reference value 72Ω)


C

(1) Apply battery voltage between terminals 1 and 2.

(2) Check continuity between terminals 3 and 5.

OK

Terminals 3 and 5	Continuity
-------------------	------------

NG**Replace EFI main relay.****4****Check EFI fuse.**

J/B No.2

F17078

P

Remove EFI fuse from J/B No.2.

C

Check continuity of EFI fuse.

OK**Continuity****OK****NG****Check for short in all the harness and components connected to EFI fuse.**

5


Check for open in harness and connector between main relay and battery, main relay and ECM (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

6

Check IGN fuse.



N01B03

P

Remove IGN fuse from J/B No-1

C

Check continuity of IGN fuse.

OK

Continuity

OK**NG**

Check for short in all the harness and components connected to IGN fuse.

7

Check ignition switch (See page [BE-14](#)).

OK**NG**

Replace ignition switch.


Check for open in harness and connector between IG switch and main relay, main relay and body ground (See page [IN-31](#)).

AC Idle Up Circuit

CIRCUIT DESCRIPTION


When the air conditioning operates (increased engine load), this circuit switch is on the VSV and increases the amount of bypass air to increase the idle speed, thus maintaining driveability.

WIRING DIAGRAM




DIAGNOSTIC CHART

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)




INSPECTION PROCEDURE

TOYOTA hand-held tester

1**Connect the TOYOTA hand-held tester and check operation of A/C idle-up VSV.**

IG ON

88003
FI7088
FI7071 FI7072**NG****P**

(1) Remove the fuse cover on the instrument panel.

(2) Connect the TOYOTA hand-held tester to the DLC 3.

(3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.

(4) Select the active test mode on the TOYOTA hand-held tester.


C

Check operation of A/C idle-up VSV when A/C idle-up VSV is operated by the TOYOTA hand-held tester.




OK**A/C idle-up VSV is ON:****The air from port E is flowing out through port F.****A/C idle-up VSV is OFF:****The air does not flow from port E to port F.****OK****Check and repair air hose and air pipe.****(See page [EG2-295](#))**

2**Check A/C idle-up VSV.**

Ohmmeter



Ohmmeter

P0411B
P04117
P04276
P04278**OK****P**

(1) Remove A/C idle-up VSV.

(2) Disconnect A/C idle-up VSV connector.

C

(1) Measure resistance between terminals.

(2) Measure resistance between each terminal and the body.

OK(1) **Resistance: 22 – 42 at 20₂C (68₂F)**(2) **Resistance: 1 M or higher****C**

Check operation of A/C idle-up VSV when battery positive voltage is applied to the terminals of A/C idle-up VSV connector or not.

OK**Battery positive voltage is applied:****The air from pipe E is flowing out through pipe F.****Battery positive voltage is not applied:****The air from pipe E is not flowing out through pipe F.****NG****Replace A/C idle-up VSV.****3****Check for open and short in harness and connector between EFI main relay and ECM (See page [IN-31](#)).****OK****NG****Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).**

INSPECTION PROCEDURE


OBDII scan tool (excluding TOYOTA hand-held tester)

1Check A/C idle-up VSV (See page [EG2-573](#), step 2)**OK****NG**

Replace A/C idle-up VSV.

2

Check voltage between terminal ACV of ECM connector and body ground.

B85653
FI7029**P**

(1) Remove glove compartment.

(See page [EG2-309](#))

(2) Turn ignition switch ON.

C

Measure voltage between terminal ACV of ECM connector and body ground.

OK

Voltage: 9 –14 V

OK**NG**Check for open and short in harness and connector between EFI main relay and ECM (See page [IN-31](#)).**3**Check air hose and air pipe (See page [EG2-295](#)).**OK****NG**

Repair or replace.

Check and replace ECM (See page [IN-36](#)).

Fuel Pump Control Circuit


CIRCUIT DESCRIPTION

Fuel pump control


The fuel pump is switched on (low voltage at terminal FC) when STA is on or while the NE signal is input to the ECM.

In the diagram below, when the engine is cranked, current flows from terminal ST of the ignition switch to the starter relay coil, the starter relay switches on and current flows to coil L1 of the circuit opening relay. Thus the circuit opening relay switches on, power is supplied to the fuel pump and the fuel pump operates. When the STA signal and NE signal are input to the ECM, Tr is turned ON, current flows to coil L2 of the circuit opening relay, the relay switches on and the fuel pump operates.

While the NE signal is generated (engine running), the ECM keeps Tr ON (circuit opening relay ON) and the fuel pump also keeps operating.



WIRING DIAGRAM



DIAGNOSTIC CHART

TOYOTA hand – held tester

1	Check fuel pump operation.	OK	Go to step 4
NG			
2	Check for ECM power source circuit.	NG	Repair or replace.
OK			
3	Check fuel pump.	NG	Repair or replace fuel pump.
OK			
Check for open in harness and connector between terminal FP of DLC1 and fuel pump. fuel pump and body ground.			
4	Connect the TOYOTA hand – held tester and check operation of fuel pump.	OK	Go to step 7
NG			
5	Check circuit opening relay.	NG	Replace circuit opening relay.
OK			
6	Check voltage terminal FC.	OK	Check and replace ECM.
NG			
Check for open in harness and connector between ER main relay and circuit opening relay, circuit opening relay and ECM.			

7

Check circuit opening relay.

NG

Replace circuit opening relay.

OK**8**

Check voltage terminal 3 of circuit opening relay.

NG

Check for starter signal circuit.

OK


Check for open in harness and connector between terminal 6 of circuit opening relay and body ground,

OBD II scan tool (excluding TOYOTA hand – held tester)

1	Check fuel pump operation.	OK	Go to step 4
NG			
2	Check for ECM power source circuit.	NG	Repair or replace.
OK			
3	Check fuel pump.	NG	Repair or replace fuel pump.
OK			
Check for open in harness and connector between terminal FP of DLC1 and fuel pump, fuel pump and body ground.			
4	Check circuit opening relay.	NG	Replace circuit opening relay.
OK			
5	Check voltage terminal FC.	OK	Check and replace ECM.
NG			
6	Check for open in harness and connector between EFI main relay and ECM.	NG	Repair or replace harness or connector.
OK			
7	Check voltage terminal 3 of circuit opening relay.	NG	Check for starter signal circuit.
OK			
Check for open in harness and connector between terminal 6 of circuit opening relay and body ground.			

INSPECTION PROCEDURE

TOYOTA hand-held tester

1**Check fuel pump operation.****P**

- (1) Be sure that enough fuel is in the tank.
- (2) Turn ignition switch ON.
- (3) Using SST, connect terminals FP and + B of DLC 1, SST 09843-18020

C

Check that pulsation damper screw rises up when terminals are connected.

Caution

Never make a mistake with the terminal connection position as this will cause a malfunction.

OK

The pulsation damper screw rises up.

NG**OK****Go to step 4****2****Check for ECM power source circuit (See page [EG2-565](#)).****OK****NG****Repair or replace.****3****Check fuel pump (See page [EG2-234](#)).****OK****NG****Repair or replace fuel pump.**


Check for open in harness and connector between terminal FP of DLC 1 and fuel pump, fuel pump and body ground (See page [IN-31](#)).

4**Connect the TOYOTA hand-held tester and check operation of fuel pump.**

IG ON

TOYOTA Hand-Held
Tester

DLC3

BE6653
F17088
F17093**NG****P**

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the DLC 3.
- (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.
- (4) Select the active test mode on the TOYOTA hand-held tester.


C

Check that pulsation damper screw rises up when fuel pump is on by TOYOTA hand-held tester.

OK

The pulsation damper screw rises up.

OKGo to step **7**

5**Check circuit opening relay.**F17063
F17068**P**

Remove circuit opening relay from R/B No.6.

C

(1) Apply battery voltage between terminals 2 and 4.

(2) Measure voltage between terminals 1 and 4.


OK

Terminals 1 and 4

Same as battery

OK**NG****Replace circuit opening relay.****6****Check voltage between terminal FC of ECM and body ground.**

IG ON

B6653
F17030**P**(1) Remove glove compartment (see page [EG2-309](#)).



(2) Turn ignition switch ON.

C

Measure voltage between terminal FC of ECM and body ground.

OK**Voltage: 9 -14 V****NG****OK****Check and replace ECM (See page [IN-36](#)).**

Check for open in harness and connector between EFI main relay and circuit opening relay, circuit opening relay and ECM (See page [IN-31](#)).

7**Check circuit opening relay.**F17053
F11909**OK****P**

(1) Remove glove compartment

(See page [EG2-309](#)).**C**

(2) Remove circuit opening relay from R/B No.6.


(1) Apply battery voltage between terminals 3 and 6.

(2) Check continuity between terminals 1 and 2.

OK

Terminals 1 and 2

Continuity

NG**Replace circuit opening relay.****8****Check voltage between terminal 3 of R/B No.6 (for circuit opening relay) and body ground.****STA ON**B26853
F17152**OK****C**

Measure voltage between terminal 3 of R/B No.6 (for circuit opening relay) and body ground when engine is cranked.

OK**Voltage: 9 –14 V****NG****Check for starter signal circuit**
(See page [EG2-557](#)).

Check for open in harness and connector between terminal 6 of R/B No.6 (for circuit opening relay) and body ground (See page [IN-31](#)).

OBDII scan tool (excluding TOYOTA hand-held tester)

1

 Check fuel pump operation (See page [EG2-580](#), step

NG
OK

 Go to step **4**
2

 Check for ECM power source circuit (See page [EG2-565](#)).

OK
NG

Repair or replace.

3

 Check fuel pump (See page [EG2-234](#)).


OK
NG

Repair or replace fuel pump.

Check for open in harness and connector between terminal FP of DLC1 and fuel pump, fuel pump and body ground (See page [IN-31](#)).

4

Check circuit opening relay.


P

(1) Remove glove compartment

 (See page [EG2-309](#)).

C

(2) Remove circuit opening relay from R/B No.6.

Check continuity between terminals of circuit opening relay shown below.

OK

Terminals 1 and 2	Open
Terminals 3 and 6	Continuity (Reference value 30Ω)

C

(1) Apply battery voltage between terminals 3 and 6.

(2) Check continuity between terminals 1 and 2.

OK

Terminals 1 and 2	Continuity
-------------------	------------

OK
NG

Replace circuit opening relay.

5

Check voltage between terminal FC of ECM and body ground
(See page [EG2-582](#), step 6).

NG**OK**

Check and replace ECM (See page [IN-36](#)).

6

Check for open in harness and connector between ER main relay and circuit opening relay, circuit opening relay and ECM (See page [IN-31](#)).

OK**NG**

Repair or replace harness or connector.

7

Check voltage between terminal 3 of R/B No-6 (for circuit opening relay) and body ground (See page [EG2-583](#), step 8).

OK**NG**

Check for starter signal circuit
(See page [EG2-557](#)).

Check for open in harness and connector
between terminal 6 of circuit opening relay and
body ground (See page [IN-31](#)).


Fuel Pressure Control VSV Circuit

CIRCUIT DESCRIPTION


The ECM turns on a VSV (Vacuum Switching Valve) to draw the air into the diaphragm chamber of the pressure regulator if it detects that the temperature of the engine coolant is too high during engine starting.

The air drawn into the chamber increases the fuel pressure to prevent fuel vapor lock at high engine temperature in order to help the engine start when it is warm.

Fuel pressure control ends approx. 120 sec. after the engine is started.




WIRING DIAGRAM




DIAGNOSTIC CHART

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)




INSPECTION PROCEDURE


TOYOTA hand-held tester

1


Connect the TOYOTA hand-held tester and check operation of fuel pressure control VSV.



ON



OFF



8E8653
F17068
F17076
F17075

NG

P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the DLC 3.
- (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.
- (4) Select the active test mode on the TOYOTA hand-held tester.

C

Check operation of fuel pressure control VSV when fuel pressure control VSV is operated by the TOYOTA hand-held tester.

OK

Fuel pressure control VSV is ON:





The air from pipe E is flowing out through the air filter.

Fuel pressure control VSV is OFF:

The air from pipe E is flowing out through pipe G.

OK

Check and repair fuel pressure regulator
(See page [EG2-240](#)).

2**Check fuel pressure control VSV.**EC2939
EC2940
EC2941
EC2942**OK****P**

- (1) Remove fuel pressure control VSV.
- (2) Disconnect fuel pressure control VSV connector.

C

- (1) Measure resistance between terminals.
- (2) Measure resistance between each terminal and the body.

OK

- (1) **Resistance: 26 – 46 at 20°C (68°F)**
- (2) **Resistance: 1 M or higher**

C

Check operation of fuel pressure control VSV when battery positive voltage is applied to the terminals of fuel pressure control VSV connector or not.

OK

Battery positive voltage is applied:
The air from pipe E is flowing out through the air filter.

Battery positive voltage is not applied:
The air from pipe E is flowing out through pipe G.

NG**Replace fuel pressure control VSV.****3****Check for open and short in harness and connector between EFI main relay and ECM (See page [IN-31](#)).****OK****NG****Repair or replace harness or connector.****Check and replace ECM (See page [IN-36](#)).**

INSPECTION PROCEDURE

OBDII scan tool (excluding TOYOTA hand-held tester)

1Check fuel pressure control VSV (See page [EG2-589](#), step**OK****NG**


Replace fuel pressure control VSV.

2

Check voltage between terminal FPU of ECM connector and body ground.



IG ON

BE6653
F17028**P**(1) Remove glove compartment
(See page [EG2-309](#)).

(2) Turn ignition switch ON.

CMeasure voltage between terminal FPU of ECM
connector and body ground.**OK**

Voltage: 9 -14 V

OK**NG**Check for open and short in harness and
connector between EFI main relay and
ECM (See page [IN-31](#)).**3**Check fuel pressure regulator (See page [EG2-240](#)).**OK****NG**

Repair or replace.


Check and replace ECM (See page [IN-36](#)).

AC Cut Control Circuit

CIRCUIT DESCRIPTION

This circuit cuts air conditioning operation during vehicle acceleration in order to increase acceleration performance. During acceleration with the vehicle speed at 25 km/h (16 mph) or less, engine speed at 1,600 rpm or less and throttle valve opening angle at 60° or more, the A/C magnet switch is turned OFF for several seconds.


WIRING DIAGRAM




FI7012

DIAGNOSTIC CHART

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)




INSPECTION PROCEDURE

TOYOTA hand-held tester

1

Connect the TOYOTA hand-held tester and check operation of air conditioning cut control.



NG

P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the DLC3.
- (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.
- (4) Start the engine and air conditioning switch ON.
- HINT: A/C magnet clutch is turned ON.
- (5) Select the active test mode on the TOYOTA hand-held tester.

C

Check operation of A/C magnet clutch cut when air conditioning cut control is operated by the TOYOTA hand-held tester.

OK

A/C magnet clutch is turned OFF.

OK

Proceed to next circuit inspection shown on matrix chart (See page EG2-435).

2

Check for open and short in harness and connector between ECM and A/C amplifier (See page IN-31).


OK

NG

Repair or replace harness or connector.

3

Check voltage between terminal ACT of ECM and body ground.



OK

P

- (1) Remove glove compartment (See page EG2-309).
- (2) Start the engine.

C

Measure voltage between terminal ACT of ECM connector and body ground when A/C switch is turned to ON and OFF.

OK

A/C switch condition	Voltage
ON	4.5 – 5.5 V
OFF	0 – 2 V

NG

Check and replace A/C amplifier.

Check and replace ECM (See page IN-36).

INSPECTION PROCEDURE**OBDII scan tool (excluding TOYOTA hand-held tester)****1**

Check voltage between terminal ACT of ECM and body ground
(See page [EG2-593](#), step 3.)

NG**OK**

Check and replace ECM (See page [IN-36](#)).

2

Check for open and short in harness and connector between ECM
and A/C amplifier (See page [IN-31](#)).

OK**NG**


Repair or replace harness or connector.

Check and replace A/C amplifier.


47017

DIAGNOSTIC CHART

TOYOTA hand-held tester



OBDII scan tool (excluding TOYOTA hand-held tester)




INSPECTION PROCEDURE


TOYOTA hand-held tester

1


Connect the TOYOTA hand-held tester and check operation of IACV control VSV.



ON



OFF



B60653
P17088
P17073
P17074

NG

P

- (1) Remove the fuse cover on the instrument panel.
- (2) Connect the TOYOTA hand-held tester to the D LC3.
- (3) Turn ignition switch ON and TOYOTA hand-held tester main switch ON.
- (4) Select the active test mode on the TOYOTA hand-held tester.

C

Check operation of IACV control VSV when IACV control VSV is operated by TOYOTA hand-held tester.

OK

IACV control VSV is ON:




The air from port E is flowing out through port F.

IACV control VSV is OFF:


The air from port E is flowing through the air filter.

OK

Check for vacuum tank (See page [EG2-277](#)).

2**Check IACV control VSV.**

F16360
F16348
F16392
F16393

**OK****P**

(1) Remove IACV control VSV.

C

(2) Disconnect IACV control VSV connector.

(1) Measure resistance between terminals.

(2) Measure resistance between each terminal and the body.

OK(1) Resistance: 26 – 46 Ω at 20 $^{\circ}$ C (68 $^{\circ}$ F)(2) Resistance: 1 M Ω or higher.**C**

Check operation of IACV control VSV when battery positive voltage is applied to the terminals of IACV control VSV connector or not.

OK**Battery positive voltage is applied:**

The air from pipe E is following out through pipe F.

Battery positive voltage is not applied:

The air from pipe E is flowing out through the air filter.

NG**Replace IACV control VSV.****3****Check for open and short in harness and connector between EFI main relay and ECM (See page IN-31).****OK****NG****Repair or replace harness or connector.****Check and replace ECM (See page IN-36).**

INSPECTION PROCEDURE

OBDII scan tool (excluding TOYOTA hand-held tester)

1Check IACV control VSV (See page [EG2-598](#), step 2)**OK****NG**


Replace IACV control VSV.

2

Check voltage between terminal ACIS of ECM connector and body ground.



IG ON

**P**(1) Remove glove compartment
(See page [EG2-309](#)).

(2) Turn ignition switch ON.

C

Measure voltage between terminal ACIS of ECM connector and body ground.

OK

Voltage: 9 –14 V

BE0653
FI7026**OK****NG**Check for open and short in harness and connector between EFI main relay and ECM (See page [IN-31](#)).**3**Check for vacuum tank (See page [EG2-277](#)).**OK****NG**

Repair or replace.

Check and replace ECM (See page [IN-36](#)).