

INSTALLATION

Installation is in the reverse order of removal (See page [CL-11](#)).

HINT:

After installation, bleed clutch system.