



INSPECTION

INSPECT LOWER BALL JOINT FOR ROTATION CONDITION

- (a) As shown in the illustration, flip the ball joint stud back and forth 5 times, before installing the nut.
- (b) Using a torque wrench, turn the nut continuously one turn per 2 – 4 seconds and take the torque reading on the 5th turn.

Turning torque:

0.8 – 2.5 N·m (8 – 25 kgf·cm, 7.0 – 22.0 in.-lbf)