

DISASSEMBLY

REMOVE BLOWER MOTOR

Remove the 3 screws and blower motor.