



## Countershaft Index

### NOTE:

- Clean all parts thoroughly in solvent and dry with compressed air.
- The 28 mm spacers should be marked as they are removed, so that can be reinstalled correctly.



Lubricate all parts with oil before reassembly.

