

REASSEMBLY

1. INSTALL LOWER INSULATOR ONTO SHOCK ABSORBER

2. INSTALL COIL SPRING AND SUSPENSION SUPPORT

(a) Using SST, compress the coil spring.

SST 09727-30021

NOTICE:

Do not use an impact wrench. It will damage the SST.

(b) Install the spring bumper to the piston rod.

(c) Install the coil spring to the shock absorber.

HINT:

Fit the lower end of the coil spring into the gap of the spring seat of shock absorber.

(d) Install the spring seat with the upper insulator.

(e) Install the dust seal and suspension support.

(f) Temporality install a new nut in the center of the suspension support.

(g) Remove the SST.

SST 09727-30021

(h) Pack the suspension support with MP grease.

