



## DISPOSAL

1. **FULLY EXTEND SHOCK ABSORBER ROD**
2. **DRILL HOLE TO DISCHARGE GAS FROM CYLINDER**

Using a drill, make a hole in the cylinder, as shown in the illustration to discharge the gas inside.

### CAUTION:

The discharging gas is harmless, but be careful of chips which may fly up when drilling.