

# Abbreviation



2WS	Front Wheel Steering
4WS	Four Wheel Steering
A/C	Air Conditioner
ALB	Anti Lock Brake
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
B or BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	Electronic Control Unit for Fuel-Injection System
EGR	Exhaust Gas Recirculation
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV	Positive Crankcase Ventilation
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SW	Switch
SOL.V	Solenoid Valve
TDC	Top Dead Center

P	Parking
R	Reverse
N	Neutral
D <sub>4</sub>	Drive Position (1st—4th)
D <sub>3</sub>	Drive Position (1st—3rd)
2	Fixed 2nd speed
1	Fixed 1st speed
S	S Signal/S Switch