

Label Locations

Fuel-Injected Engine:

BONNET

INSULATOR
(Standard for
some types)

COOLANT
CAUTION and
PRECAUTION

ALB CAUTION
(Standard for
some types)

AIR CLEANER,
OIL and FILTER SERVICE

SPARK PLUG CAUTION

SERVICE
INFORMATION

RADIATOR CAP
CAUTION

EMISSION LABEL

KU Model only

COOLING FAN
CAUTION

TIRE INFORMATION

RHD

LHD



Carbureted Engine:

