


Parking Brake



Disassembly and Reassembly



Disconnect the parking brake cable from the lever on the caliper by removing the lock pin.

