

ALB

Special Tools	13-42	Installation.....	13-68
Illustrated Index	13-43	Piston	
Circuit Diagram	13-44	Removal.....	13-69
ALB Checker		Installation.....	13-70
Function Test	13-45	Power Unit	
Wheel Sensor Signal		Index/Inspection	13-71
Confirmation.....	13-47	Disassembly/Reassembly	13-72
Troubleshooting		Accumulator Unit	
Dash Warning Light	13-48	Index	13-73
Symptom-to-System Chart.....	13-50	Accumulator/Pressure Switch ...	13-74
Flowcharts.....	13-51	Accumulator Disposal	13-74
Hydraulic System		Master Cylinder	
Hydraulic Connections	13-63	Overhaul/Inspection	13-75
Relieving Accumulator/		Disassembly	13-76
Line Pressure	13-64	Reassembly	13-77
Modulator		Bleeding	13-79
Index/Inspection	13-65	Electronic Components	
Solenoid		Control Unit Replacement	13-80
Solenoid Leak Test.....	13-66	Relays Inspection	13-81
Removal.....	13-67	Pulsers/Sensors	13-81
Inspection	13-68		



Special Tools

Special Tools

Ref. No.	Tool Number	Description	Q'ty	Page Reference
①	07HAA—SG00100	Bleeder T-Wrench	1	13-53, 13-64, 13-79
②	07HAJ—SG00601 or 07508—SB00000 —07HAJ—SG00400	ALB Checker ALB Checker Adaptor	1 1 1	13-45, 13-47 13-45, 13-47 13-45, 13-47

