



INTERMITTENT WIPER RELAY
(Located under the relay box
Wire colors: BLU/WHT, BLU/WHT
GRN/RED and BLK)


SPEED SENSOR

DIM-DIP RESISTOR
(KE model only)

Relays and Control Unit Locations


Dashboard

NOTE: RHD type is symmetrical to LHD type.








CIGARETTE LIGHTER RELAY
(Wire colors: WHT/BLU, YEL/RED)
WHT/RED and BLK




**SERVICE
CHECK
CONNECTOR**




DELAY RELAY
(Carbureted engine)




**ENGINE MOUNT CONTROL
UNIT (A/T only)**



HEADLIGHT WASHER CONTROL UNIT
(European model only)



SEAT HEATER MAIN RELAY
(KS, KW and KX models only)
(Wire colors: YEL/BLK, WHT/BLK)
BLK/GRN and BLK




Relays and Control Unit Locations

Floor and Door

NOTE: RHD type is symmetrical to LHD type.


Fuel-injected engine: PGM-FI ECU

Carbureted engine: PGM-CARB. CONTROL UNIT (Except KP and KT models)






Seat




Relays and Control Unit Locations

Trunk



Wire Harness and Ground Locations

Engine Compartment



(cont'd)