

PGM-CARB Control System

Troubleshooting Flow Chart — Ignition Coil Signal

- ⑧ Self-diagnosis LED indicator blinks eight times: A problem in the ignition coil signal circuit.

