


Relay and Control Unit Locations


Door and Floor

NOTE: RHD type is symmetrical to LHD type, except of the ABS CONTROL UNIT.



Wire Harness and Ground Locations

Engine Compartment



(cont'd)