

Intake Air System

System Troubleshooting Guide

NOTE: Across each row in the chart, the sub-systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.

PAGE	SUB-SYSTEM	THROTTLE CABLE	THROTTLE BODY	AIR CLEANER AND INTAKE AIR DUCT
SYMPTOM		11-97	11-98	11-96
WHEN COLD FAST IDLE OUT OF SPEC			①	
WHEN WARM IDLE SPEED TOO HIGH		②	①	
LOSS OF POWER			①	②