

Carburetor

Replacement

CAUTION:

- As the carburetor parts are small always use hand tools that specifically correspond to the sizes of the fasteners to be removed.
- The primary and secondary parts must be set aside separately in groups. Take care not to lose them.
- The carburetor must be disassembled in a clean area and washed in gasoline.
- Use compressed air to clean jet orifices and fuel passages. Do not use a wire.
- Do not disassemble the throttle and choke valves and their shafts.
- Replace with new parts as a set if so required in the parts list.

NOTE: After cleaning the carburetor, apply a coat of silicon oil.

