


Circuit Diagram

Description:

When the lighting switch is set to the first position (•) with the ignition switch ON, the headlights will rise and light up as the DIM-DIP headlights. The light is dimmed to approx. ten percent of the headlights' brightness in the second position (●) of the lighting switch.



G1: Left/Right front engine compartment
G2: Right trunk area