


Heater

Heater Door Positions









Front View

Side View

(HI/LO)



(VENT)



NOTE: This diagram shows the air mix door in the most appropriate position for each heater position. The position of the air mix door is controlled by the temperature control and is independent of the heater control position.