


Ignition System

Component Location Index

- **IGNITION TIMING CONTROL SYSTEM**

Troubleshooting, section 6

Inspection and Setting, page 16-50





Circuit Diagram

