

insider info.

1995/96 Subaru Legacy Blows Fuse SBF-2

If you encounter a 1995 or 1996 Subaru Legacy that blows fuse SBF-2 (M/B) intermittently, check to see if the yellow 9 pin diagnostic connector for the Select Monitor (B78) is loose and hanging down where it can get kicked around by the driver's foot. Also, check to be certain the two grounding probes (B81) that are used in conjunction with the black 6 pin diagnostic connector (B82), are not hanging where they might come in contact with the yellow Select Monitor connector.

Carefully examine the wiring to the connector for damage. If such damage is present, repair the insulation and secure the connector where it will not interfere with normal foot travel during vehicle operation.

If the two grounding probes for the diagnostic connector are hanging near the Select Monitor connector, relocate them to an area where they will not contact any wiring in the yellow Select Monitor connector.