

FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the AVENSIS VERSO / PICNIC.

Applicable models: AMC20, CLM20 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
● AVENSIS VERSO / PICNIC Chassis and Body Repair Manual	RM864E
● 1AZ-FE Engine Repair Manual	RM865E
● 1CD-FTV Engine Repair Manual	RM866E
● AVENSIS VERSO / PICNIC New Car Features	NCF206E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.