


G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[LHD]



B12 Back Door Courtesy SW

Back Door Lock Motor

B13 Back Door Opener SW

C13 Curtain Shield Airbag Squib LH

C14 Curtain Shield Airbag Squib RH

D 8 Door Courtesy SW Front LH

D 9 Door Courtesy SW Front RH

D10 Door Courtesy SW Rear LH

D11 Door Courtesy SW Rear RH

D14 Door Key Lock and Unlock SW Front LH

Door Lock Motor Front LH

Door Unlock Detection SW Front LH

D19 Door Lock Control SW Front RH

Power Window SW Front RH

D20 Door Lock Control SW

Power Window Master SW

D22 Door Lock Motor Front RH

D23 Door Lock Motor Rear LH

D24 Door Lock Motor Rear RH

F 16 Front Door Speaker LH

F 17 Front Door Speaker RH

F 18 Fuel Pump
Fuel Sender

H16 High Mounted Stop Light

I 15 Interior Light (Front)

I 16 Interior Light (Rear)

J 32 Junction Connector

J 33 Junction Connector

J 34 Junction Connector

J 35 Junction Connector

J 36 Junction Connector

J 37 Junction Connector

L 1 License Plate Light LH

L 2 License Plate Light RH

L 3 Luggage Compartment Light

M 1 Mirror Heater LH

Remote Control Mirror LH

M 2 Mirror Heater RH

Remote Control Mirror RH

M 3 Moon Roof Control Relay

Moon Roof Control SW

M 4 Moon Roof Limit SW

Moon Roof Motor