


Position of Parts in Instrument Panel

[RHD]



D 2 Diode
D 3 Diode
D 4 Diode (Fan)
D 5 Diode
D 6 DLC3
D 7 Double Door Lock ECU

E 7 Engine and ECT ECU (A/T)
Engine ECU (M/T)
E 8 Engine and ECT ECU (A/T)
Engine ECU (M/T)
E 9 Engine and ECT ECU (A/T)
Engine ECU (M/T)
E 10 Engine and ECT ECU (A/T)
Engine ECU (M/T)
E 11 Engine and ECT ECU (A/T)
Engine ECU (M/T)

F 15 Front Fog Light Relay
F 19 Fuse Holder

H 13 Headlight Beam Level Control SW
H 15 Heater Control Panel

I 11 Idle-Up SW
I 12 Ignition Key Cylinder Light
I 13 Ignition Key Cylinder Light
Transponder Key Amplifier
I 14 Ignition SW