

D RELAY LOCATIONS

○ : Center J/B No.2

Near the Steering Column (See Page 9)

