


E ELECTRICAL WIRING ROUTING

Position of Parts in Body

[RHD]



B12 Back Door Courtesy SW
Back Door Lock Motor
B13 Back Door Opener SW

C13 Curtain Shield Airbag Squib LH
C14 Curtain Shield Airbag Squib RH

D 8 Door Courtesy SW Front LH
D 9 Door Courtesy SW Front RH
D10 Door Courtesy SW Rear LH
D11 Door Courtesy SW Rear RH
D12 Door Key Lock and Unlock SW Front LH
Door Lock Motor Front LH
Door Unlock Detection SW Front LH
Double Door Lock Motor Front LH
Double Lock Position SW Front LH
D13 Door Key Lock and Unlock SW Front RH
Door Lock Motor Front RH
D15 Door Key Lock and Unlock SW Front RH
Door Lock Motor Front RH
Door Unlock Detection SW Front RH
Double Door Lock Motor Front RH
Double Lock Position SW Front RH
D16 Door Key Lock and Unlock SW Rear LH
Door Lock Motor Rear LH
Door Unlock Detection SW Rear LH
Double Door Lock Motor Rear LH
Double Lock Position SW Rear LH
D17 Door Key Lock and Unlock SW Rear RH
Door Lock Motor Rear RH
Door Unlock Detection SW Rear RH
Double Door Lock Motor Rear RH
Double Lock Position SW Rear RH

D18 Door Lock Control SW Front LH
Power Window SW Front LH
D19 Door Lock Control SW Front RH
Power Window SW Front RH
D20 Door Lock Control SW
Power Window Master SW
D21 Door Lock Motor Front LH
D22 Door Lock Motor Front RH
D23 Door Lock Motor Rear LH
D24 Door Lock Motor Rear RH

F 16 Front Door Speaker LH
F 17 Front Door Speaker RH
F 18 Fuel Pump
Fuel Sender

G 3 Glass Breakage Sensor
G 4 Glass Breakage Sensor Microphone

H16 High Mounted Stop Light

I 15 Interior Light (Front)
I 16 Interior Light (Rear)

J 32 Junction Connector
J 33 Junction Connector
J 34 Junction Connector
J 35 Junction Connector
J 36 Junction Connector
J 37 Junction Connector