


EQUIPMENT


Wireless Door Lock Remote Control System

- The wireless door lock remote control system is standard equipment on all models.
- A key-integrated type transmitter with LOCK switch, UNLOCK switch, and indicator light has been adopted.
- With the added “answer back” function, the hazard lights will flash once when the door is locked with the transmitter, and twice when it is unlocked.
- With the added illuminated entry function, the interior light will come on when the door is unlocked with the transmitter, and go out when it is locked.
- A double locking system is provided on Europe RHD models. By pressing the transmitter’s lock switch twice within 5 seconds, it has been set the double locking system. Once set, this system prevents all the side doors and back door from being unlocked from either inside or outside of the vehicle.

Key-Integrated Type Transmitter



206MO58



206MO59

Power Window System

The front and rear power windows are provided with key-off operation function and one-touch auto up and down with jam protection function.

Theft Deterrent System

When any attempt is made to forcibly enter the vehicle, open the engine hood, unlock any door without a key, or when the battery terminal are removed and reconnected, this system sounds the vehicle horn and self power siren, flashes hazard lights, illuminates the interior light, to deter illegal or mischievous activities. At the same time it locks all doors, if any of the door is unlocked during alarm.

Engine Immobiliser System

This system is constructed so that the engine will only start when the ID code of the transponder chip embedded in the key matches the code registered in the transponder key ECU.