

HOW TO PROCEED WITH TROUBLESHOOTING

The Intelligent Tester II can be used at step 3, 6, 9 and 12.

1 Vehicle Brought to Workshop



2 Customer Problem Analysis (SEE PAGE 05-608)



3 Check and Clear DTCs and Freeze Frame Data (SEE PAGE 05-625 and 05-627)



4 Problem Symptom Confirmation

Symptom does not occur: Go to step 5

Symptom occurs: Go to step 6

5 Symptom Simulation (SEE PAGE 01-22)



6 DTC Check (SEE PAGE 05-625)

There is no output: Go to step 7

There is output: Go to step 8

7 Problem Symptoms Table (SEE PAGE 05-620)

Check for fluid leakage and go to step 10

8 DTC Chart (SEE PAGE 05-633)



9 Circuit Inspection (SEE PAGE 05-636 to 05-740)



10 Identification of Problem



11	Repair
----	--------

12	Confirmation Test
----	-------------------

End
