


DISPLAY PANEL DOES NOT OPEN, TILT, OR TILTS IMPROPERLY**INSPECTION PROCEDURE****1 CHECK RADIO AND NAVIGATION ASSY**

- (a) Check for foreign matter or obstructions caught in the moving parts of the panel.

OK: No obstruction or foreign matter is found.

NG

REMOVE ANY OBSTRUCTION OR FOREIGN MATTER FOUND

OK

2 OPERATION CHECK

- (a) Check if the navigation and audio systems function properly.

OK: Navigation and audio systems function properly.

OK

**REPLACE RADIO AND NAVIGATION ASSY
(SEE PAGE 67-1)**

NG

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1094)**