

# W/PULLEY COMPRESSOR ASSY (2AZ-FE)

## ON-VEHICLE INSPECTION

551DK-01

### 1. INSPECT W/PULLEY COMPRESSOR ASSY

- (a) Check the operation.
- (1) Start the engine.
  - (2) Inspect the weight hub.

**Standard: The weight hub rotates along with the pulley**

