


TELEVISION CAMERA CONTROLLER REPLACEMENT

6719U-01

HINT:

Installation is in the reverse order of removal.

1. REMOVE GLOVE COMPARTMENT DOOR STOPPER SUB-ASSY (SEE PUB. No. RM864E, PAGE 71-10)
2. REMOVE GLOVE COMPARTMENT DOOR ASSY (SEE PUB. No. RM864E, PAGE 71-10)
3. REMOVE GLOVE COMPARTMENT PANEL (RHD STEERING POSITION TYPE) (SEE PUB. No. RM864E, PAGE 71-10)



4. REMOVE TELEVISION CAMERA CONTROLLER

- (a) Disconnect the connectors.
- (b) Remove the 2 nuts and television camera controller.

5. CHECK AND INSPECTION STEERING WHEEL CENTER POINT AND MAXIMUM STEERING WHEEL ANGLE (SEE PAGE 05-1182)