


IDENTIFICATION INFORMATION

VEHICLE IDENTIFICATION AND SERIAL NUMBERS

0107E-01





1. VEHICLE IDENTIFICATION NUMBER

- (a) The vehicle identification number is stamped in the engine compartment, as shown in the illustration. This number has also been stamped on the manufacturer's plate.

A: Vehicle Identification Number

B: Manufacturer's Plate



2. ENGINE SERIAL NUMBER AND TRANSAXLE SERIAL NUMBER

- (a) The engine serial number is stamped on the cylinder block of the engine and transaxle serial number is stamped on the transaxle, as shown in the illustration.

A: 1AZ-FE

B: 1CD-FTV

C: E355, E356, U241E