












MANUAL TRANSMISSION/TRANSAXLE



PREPARATION

0201Y-01

SST

	09249-63010	Torque Wrench Adaptor	FLOOR SHIFT TRANSMISSION CONTROL CABLE ASSY
	09308-00010	Oil Seal Puller	FRONT DIFFERENTIAL OIL SEAL
	09520-01010	Drive Shaft Remover Attachment	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	09520-24010	Differential Side Gear Shaft Puller	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	(09520-32040)	Shocker Set	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	09608-10010	Steering Knuckle Oil Seal Replacer	FRONT DIFFERENTIAL OIL SEAL
	09608-32010	Steering Knuckle Oil Seal Replacer	FRONT DIFFERENTIAL OIL SEAL
	09628-62011	Boll Joint Puller	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	09930-00010	Drive Shaft Nut Chisel	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	09950-70010	Handle Set	FRONT DIFFERENTIAL OIL SEAL
	(09951-07200)	Handle 200	FRONT DIFFERENTIAL OIL SEAL

Recommended Tools

	09011-12301 Socket Wrench 30 mm	FRONT DIFFERENTIAL OIL SEAL MANUAL TRANSAXLE ASSY(1AZ-FE) MANUAL TRANSAXLE ASSY(1CD-FTV)
	09040-00011 Hexagon Wrench Set	

Equipment

Dial indicator with magnetic base	
Slide calipers	
Torque wrench	

Lubricant

Item	Capacity	Classification
E355,E356 Manual transaxle oil (w/ Differential oil)	2.5 liters (2.6 US qts, 2.2 Imp. qts)	API GL-4 or GL-5 SAE 75W-90