

# STARTING & CHARGING

## SERVICE DATA

03084-01

### 1AZ-FE

|                                   |                |                        |
|-----------------------------------|----------------|------------------------|
| Starter assy<br>Specified current |                | 90 A or less at 11.5 V |
| Battery<br>Voltage                | at 20°C (68°F) | 12.5 – 12.9 V          |

### 1CD-FTV

|  |                |   |
|--|----------------|---|
| Starter assy<br>Specified current      | 1.4kw<br>2.2kw | 90 A or less<br>120 A or less               |
| Battery<br>Voltage<br>Specific gravity | at 20°C (68°F) | 12.5 – 12.9 V at 20°C (68°F)<br>1.25 – 1.29 |
| Glow plugs<br>Resistance               | at 20°C (68°F) | Approx. 0.72 Ω                              |