

## TORQUE SPECIFICATION

Part Tightened	N·m	kgf·cm	ft·lbf
Bleeder plug	8.3	85	73 in·lbf
Brake pedal bracket sub-assy No.3 x Instrument panel reinforcement assy	19	195	14
Brake pedal bracket sub-assy No.3 x Brake pedal support sub-assy	34.3	350	25.3
Brake pedal support sub-assy x Brake pedal	34.3	350	25.3
Brake pedal support sub-assy x Body	12.7	130	9.4
Column shift parking lock cable assy x Brake pedal support sub-assy	8.0	82	71 in·lbf
Brake master cylinder x Piston stopper bolt	10	102	7
Brake master cylinder union x Brake master cylinder	1.7	17.5	15.2 in·lbf
Brake master cylinder x Brake booster	12.5	128	9.2
Brake tube x Brake master cylinder	15.0	153	11.1
Brake master cylinder reservoir sub-assy x Body	8.8	90	78 in·lbf
Brake master cylinder push rod clevis lock nut	26.0	265	19.2
Vacuum warning switch assy x Brake booster assy	13.7	140	10.1
Brake booster assy x Body	12.7	130	9.4
Pressure feed tube assy x Vane pump assy	51.5	525	38.0
Pressure feed tube clamp	7.8	80	69 in·lbf
Charcoal canister assy x Body	7	71	62 in·lbf
Vacuum pump assy x Engine	21	214	15
Check valve x End cover	74	750	54
Union bolt x Check valve	13.7	140	10
End cover x Casing	7.8	80	69 in·lbf
Front disc brake cylinder mounting x Steering knuckle	106	1,080	79
Front disc brake cylinder x Front disc brake cylinder mounting	34.3	350	25.3
Flexible hose x Front disc brake cylinder	29	296	22
Rear disc brake cylinder mounting x Axle hub	88.3	900	65
Disc brake cylinder assy rear x Rear disc brake cylinder mounting	34.3	350	25.3
Rear flexible hose x Disc brake cylinder assy rear	23	235	17
Rear flexible hose x Rear brake tube	15.0	153	11
Wheel nut	103	1,050	76
Brake actuator assy x Bracket	5.4	55	48 in·lbf
Brake actuator assy x Body	19	194	14
Power steering tube clamp x Body	7.8	80	69 in·lbf
Brake line x Brake actuator assy	15	153	11
Front speed sensor x Steering knuckle	7.8	80	70 in·lbf
Front speed sensor wire harness clamp x Shock absorber	18.5	189	13.6
Front speed sensor wire harness clamp x Body	7.8	80	70 in·lbf