

TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Steering column assembly set bolt	21	214	15
Steering column assy x Steering Intermediate shaft assy No. 2	36	367	27
Steering Intermediate shaft x Steering Intermediate shaft assy No. 2	36	367	27
Steering Intermediate shaft x Control valve shaft	36	367	27
Steering wheel set nut	50	510	37
Steering wheel pad set screw (Torx screw)	8.8	90	78 in·lbf
Steering wheel hole cover sub-assy No. 1	36	367	27
Control shaft assy set nut (A/T transaxle)	8.0	82	71 in·lbf
Transmission control cable bracket set nut (A/T transaxle)	13	133	10