

LIGHT REMINDER WARNING BUZZER DOES NOT SOUND

INSPECTION PROCEDURE

1 CHECK BUZZER

- (a) Check that the light reminder warning buzzer sound.

NG

REPLACE COMBINATION METER ASSEMBLY

OK

2 INSPECT FRONT DOOR COURTESY LAMP SWITCH ASSY

- (a) Check continuity between front door courtesy lamp switch assy and body ground.

OK:

Front door courtesy lamp switch ON	Continuity
Front door courtesy lamp switch OFF	No continuity

NG

REPLACE FRONT DOOR COURTESY LAMP SWITCH ASSY

OK

3 CHECK HARNESS AND CONNECTOR(BETWEEN FRONT DOOR COURTESY LAMP SWITCH ASSY AND BODY GROUND)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK HARNESS AND CONNECTOR(BETWEEN FRONT DOOR COURTESY LAMP SWITCH ASSY AND COMBINATION METER)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE COMBINATION METER ASSEMBLY