

DRIVE SHAFT, PROPELLER SHAFT, AXLE

3005C-01

PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Wander	1. Wheel alignment	26-4
	2. Steering linkage (Loosen or worn)	27-3
	3. Hub bearing (Worn)	51-29
	4. Stabilizer bar	30-2
Front wheel shimmy	1. Wheel balance	26-22
	2. Shock absorber	28-1
	3. Suspension arm lower (Worn)	26-7
	4. Coil spring	27-11
	5. Hub bearing (Worn)	26-14
Noise (Drive shaft)	1. Inbord joint (Worn)	26-20
	2. Outbord joint (Worn)	27-4
		30-2
		30-7
		30-7