


ON-VEHICLE INSPECTION



1. CHECK STEERING WHEEL FREEPLAY

- (a) Stop the vehicle and face the wheels straight ahead.
- (b) Rock the steering wheel gently up and down with your hand, check the steering wheel freeplay.

Maximum freeplay: 30 mm (1.18 in.)