


REAR LAMP LENS & BODY LH

REPLACEMENT

65099-02

1. REMOVE BACK WINDOW GARNISH
(See Page 75-21)
2. REMOVE REAR WINDOW SIDE GARNISH RH
(See Page 75-21)
3. REMOVE REAR WINDOW SIDE GARNISH LH
(See Page 75-21)
4. REMOVE ASSIST GRIP SUB-ASSY
(See Page 75-21)
5. REMOVE BACK DOOR TRIM BOARD ASSY
(See Page 75-21)



6. REMOVE REAR LAMP LENS & BODY LH

- (a) Disconnect the connector.
- (b) Remove the 4 nuts and rear light assy.
- (c) w/ Rear Fog:
Remove the 2 bulbs.
- (d) w/o Rear Fog:
Remove the bulb.