

WIPER AND WASHER SYSTEM

66031-01

PROBLEM SYMPTOMS TABLE

1. WIPER AND WASHER SYSTEM

| Symptom | Suspect Area | See page |
|---|---|--|
| Front wiper and washers do not operate. | 1. IG1 Relay 2. WIPER Fuse (I/P J/B) 3. Front Wiper Switch 4. Wire Harness | – – 66-3 – |
| Front wipers do not operate in LO or HI. | 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness | 66-3 66-3 – |
| Front wipers do not operate in INT. | 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness | 66-3 66-3 – |
| Front Washer motor does not operate. | 1. WIPER Fuse (I/P J/B) 2. Front Washer Switch 3. Front Washer Motor 4. Wire Harness | – 66-3 66-3 – |
| Front Wipers do not operate when washer switch in ON. | 1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness | 66-3 66-3 – |
| Rear wiper and washers do not operate. | 1. IG1 Relay 2. WIPER Fuse (I/P J/B) 3. Rear Wiper Switch 4. Wire Harness | – – 66-3 – |
| Rear wipers do not operate in INT. | 1. Rear Wiper Switch 2. Rear Wiper Motor 3. Wire Harness | 66-3 66-3 – |
| Rear washer motor does not operate. | 1. WIPER Fuse (I/P J/B) 2. Rear Washer Switch 3. Rear Washer Motor 4. Wire Harness | – 66-3 66-2 – |
| Rear wipers do not operate when washer switch in ON. | 1. Rear Wiper Switch 2. Rear Wiper Motor 3. Wire Harness | 66-3 66-3 – |
| Washer fluid does not operate. | 1. Washer Hose and Nozzle | – |
| <ul style="list-style-type: none"> When the wiper switch is OFF, the wiper blade does not retract or the retract position wrong. | 1. *1Wiper Switch | |

*1: Inspect wiper arm and blade set position