

WASHER NOZZLE

ADJUSTMENT

6603P-01

1. ADJUST WASHER NOZZLE

- (a) With the engine running, check that the point where the washer fluid hits the windshield and the rear window is within the range indicated by the hatched line.

