


REAR SPEAKER ASSY REPLACEMENT

6705Y-01

HINT:

COMPONENTS: [See page 67-1](#)

1. REMOVE POWER WINDOW REGULATOR SWITCH ASSY REAR
([See page 75-14](#))
2. REMOVE REAR DOOR TRIM BOARD SUB-ASSY LH
([See page 75-14](#))



3. REMOVE REAR SPEAKER ASSY

- (a) Disconnect the connector.
- (b) Using a drill, remove the 3 rivets and rear speaker assy.

4. INSTALL REAR SPEAKER ASSY

- (a) Using a air riveter, install the front No.1 speaker assy with 3 rivets.
- (b) Connect the connector.