

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Horn does not sound	1. HORN fuse	-
	2. Horn switch	-
	3. HORN relay	69-3
	4. Low pitched horn	-
	5. High pitched horn	-
	6. Wire harness	-