

LOW PITCHED HORN ASSY REPLACEMENT

6901R-01

1. REMOVE LOW PITCHED HORN ASSY

- (a) Disconnect the connector.
- (b) Remove the bolt and the low pitched horn assembly.

2. INSTALL LOW PITCHED HORN ASSY

- (a) Install the low pitched horn assembly with the bolt.
- (b) Connect the connector.