


WATER PUMP ASSY (1CD-FTV)

INSPECTION

1606V-01



1. INSPECT WATER PUMP ASSY

- (a) Visually check the drain hole for coolant leakage.
- (b) Turn the pulley, and check that the water pump bearing moves smoothly and quietly.