


SHIFT LOCK



SERVICE HINTS

S3 SHIFT LOCK CONTROL ECU

5-GROUND : Approx. **12** volts with the ignition SW at **ON** position

1-GROUND : Always continuity

3-GROUND : Approx. **12** volts with the brake pedal depressed

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
S3	37	S8	37		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
II	25	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Brace RH)
IK		
IN	25	Floor Wire and Instrument Panel J/B (Instrument Panel Brace RH)

: GROUND POINTS

Code	See Page	Ground Points Location
IF	44	Instrument Panel Brace RH